

SECTION 10-H

SIGNAL SYSTEMS

Paragraph	Subject	Page	Paragraph	Subject	Page
10-58	Stop Lights and Switch.....	10-76	10-62	Direction Signal Lamps and Switch.....	10-79
10-59	Horns, Relay, and Button.....	10-76	10-63	Timing Adjustment of Signal Switch Cam.....	10-81
10-60	Adjustment of Horns.....	10-78	10-64	Replacement of Signal Switch Parts.....	10-82
10-61	Adjustment of Horn Relay....	10-78			

SERVICE BULLETIN REFERENCE

Bulletin No.	Page No.	SUBJECT

10-58 STOP LIGHTS AND SWITCH

The stop lights are incorporated in the combination tail, stop, and direction signal lamps. These lamps and the replacement of bulbs are covered in paragraph 10-56.

The stop lights are controlled by a hydraulic switch mounted on the brake pipe distributor fitting near the master cylinder. The switch is closed by hydraulic pressure when the brakes are applied. It requires no adjustment or attention except to make sure that the wire connections are tight and that the switch is tightly screwed into the distributor fitting to avoid fluid leaks that would affect operation of the brakes.

The stop lights are independent of the lighting switch. The stop light circuit is protected by the 14 ampere "Direction Signal" fuse mounted on the fuse block under the cowl.

a. Replacement of Stop Light Switch

When replacing stop light switch have new switch ready to install as soon as old switch is removed from distributor fitting. Before installing new switch make sure that port in distributor fitting is filled with brake fluid. Have a helper *gently* depress brake pedal to fill the fitting from master cylinder, if necessary, then immediately install new switch.

If brake pedal has springy, spongy action after installation of stop light switch, air has entered brake pipes and it will be necessary to bleed the hydraulic system (par. 8-9).

10-59 HORNS, RELAY AND BUTTON

a. Horns and Relay

Two Delco-Remy electrically operated vibrator type horns are mounted on the radiator mounting strap. Both horns are operated simultaneously by a horn relay mounted on radiator mounting strap; the relay is controlled by the horn button on steering wheel.

The left hand horn is high pitched (380-400 cycles) and the right hand horn is low pitched (302-323 cycles), so that together they produce a pleasing blended tone. The horns have been made exceptionally compact by a spiral air column cast into the base and collar. See figure 10-95.

The horn relay is an electrical switch which closes the circuit between the battery and the horns when the horn button is pressed, and opens the circuit when the button is released. The relay permits control of the horns with a small amount of current passing through the horn button contacts. The high current required by the horns would cause arcing and burning of these contacts.

When the horn button contacts are closed, a small amount of current flows through the relay winding to ground at the horn button. This magnetizes the relay core, which attracts the flat steel relay armature. The armature has a contact point which makes contact with a stationary point to close the horn circuit. When




Figure 10-93—Horn Button in Flexible Spoke Steering Wheel—Sectional View

horn button is released, current stops flowing through relay winding so that the core loses its magnetism; the armature spring then causes contact points to be separated.

b. Horn Button—Flexible Spoke Steering Wheel

The horn button used with the flexible spoke steering wheel includes an operating ring and a contact plate mounted in the steering wheel cap base. A spring holds the wire connection against the center of the contact plate which is insulated from the wheel cap base. When the operating ring is pressed it touches the contact plate to close the circuit to ground, thus completing the relay circuit and causing the horns to operate. Springs cause the operating ring to move away from the contact plate and open the relay circuit when the operating ring is released. See figure 10-93.

The monogram and bezel assembly is held in the steering wheel cap base by three springs. The assembly may be removed by inserting a small screw driver in a notch provided in the cap base and prying against the bezel. When the monogram and bezel assembly are removed, the operating ring and wheel base assembly may be removed by removing the three screws which

attach the wheel base to the steering wheel hub. See figure 10-93.

c. Horn Button—Solid Spoke Steering Wheel

The horn button assembly used in the solid spoke steering wheel consists of a horn button cap with contact strap, a contact cup, a horn blowing spring, a contact plate, and attaching screws with insulating fibre spacer bushings.

The horn button cap has a rubber retainer which snaps over the rim of the contact cup and the contact strap bridges between the horn wire connector in steering shaft and the rim of contact cup. The contact cup is attached to steering




Figure 10-94—Horn Button Parts in Solid Spoke Steering Wheel

wheel hub by three screws and insulating fibre spacer bushings which permit movement of the cup when button cap is pressed. The screws and bushings hold the flat steel contact plate tight against the wheel hub. The dished steel horn blowing spring is placed between the cup and contact plate, with outer rim of spring resting on a shoulder of the plastic material of wheel, which provides insulation. See figure 10-94. Normally, the dished spring holds the contact cup outward so that no contact is made, but when the cap is pressed the cup pushes the raised inner edge of the spring down into contact with the plate, thereby completing a grounding connection between the horn wire connector and the steering shaft.

Whenever horn button parts are assembled into the steering wheel the dished horn blowing spring must be installed so that clearance exists between inner edge of spring and the contact plate. See figure 10-94. The contact cup must be installed with the locating notch in rim in line with lower spoke of steering wheel so that the horn button cap emblem will be properly located when cap is installed.

10-60 ADJUSTMENT OF HORNS

When horns fail to blow first check wiring circuit (par. 10-12, c) before attempting to adjust horns. If horns are at fault, or tone is poor, adjust each horn for specified current draw as follows:

1. Remove horn from car and remove the back shell, which is crimped over the collar at four points.

2. Inspect air gap between armature and core for steel burrs or other foreign matter; clean out if present. This may correct the trouble. If it does not, proceed as follows:

3. Connect an ammeter in series with the horn and a *fully charged* 6-volt battery to measure the current draw when horn blows. Current draw should be as follows:

Left (high note) horn . . . 16 to 18 amperes

Right (low note) horn . . . 17 to 19 amperes

4. Adjust to specified current draw, if necessary, by loosening lock nut and turning contact point adjusting nut clockwise to decrease or counterclockwise to increase current draw. See figure 10-95. This adjustment is very sensitive, and adjusting nut should not be moved more than one-tenth turn at a time, then locked with nut each time before trying the horn.

Increasing the current draw increases the horn volume. Too much current will produce a




Figure 10-95—Horn Contact Point Adjustment

high cut-in voltage, which will cause a sputtering sound and may cause horn to stick in cold weather.

5. After each horn has been adjusted individually, sound both horns together to check for proper blend of tone.

6. After horn adjustment is completed install the back shell. Make sure that back shell is seated against horn collar all around, then crimp tangs of shell over collar at four points.

7. When horns are reinstalled, connect a voltmeter between each horn terminal and ground to check voltage when horns are blown. Voltage at each horn should be at least 5.25.




Figure 10-96—Horn Contact Point Adjustment

10-61 ADJUSTMENT OF HORN RELAY

Three checks and adjustments are required on the horn relay: air gap, point opening, and closing voltage. These should be made in the following order:

1. Remove horn relay from car then remove relay cover.

2. Push relay armature down until contact points just touch, then check air gap between

armature and end of core using feeler gauges. Air gap should be .015". Adjust gap to .015", if necessary, by bending the lower point support. See figure 10-96.

3. With armature free, check contact point opening, using feeler gauges. Point opening should be .025". Adjust opening to .025", if necessary, by bending the upper armature stop. See figure 10-97.




Figure 10-97—Relay Contact Point Adjustment

4. Connect the positive terminal of a 6-volt battery to the battery (middle) terminal of horn relay.

5. Using a variable rheostat of 10 ohms minimum and a capacity of 2 amperes, connect one lead to the negative post of battery. Set rheostat to provide full resistance, then connect the other lead to the "S" terminal of relay.

6. Connect a 6-volt test lamp between negative post of battery and the "H" terminal of relay.

7. Connect positive lead of low reading voltmeter to the battery (middle) terminal of horn relay and connect negative lead of voltmeter to the "S" terminal of relay.

8. Slowly decrease resistance until the test lamp lights, note the voltmeter reading, then turn rheostat to full resistance. Closing voltage should be 2.75 to 4 volts.

9. If closing voltage is not within specified limits, bend the armature spring post as required. Bend down to increase closing voltage or bend up to decrease closing voltage. See figure 10-98.

10. After proper closing voltage is obtained, install relay cover. Install relay on car and connect wires as shown in wiring circuit diagram in Section 10-J.




Figure 10-98—Adjustment of Horn Relay Closing Voltage

10-62 DIRECTION SIGNAL LAMPS AND SWITCH

a. Direction Signal Lamps and Indicators

The directional signal lamps are incorporated in the front parking lamps and the rear combination tail, stop and signal lamps.

Each front parking lamp contains a 21-3 CP lamp bulb; the 3 CP bulb filament is used for parking and the 21 CP bulb filament is used for the directional signal light. Each rear lamp contains a separate 21 CP lamp bulb for the direction signal light, which operates independently of the tail and stop lights.

When the ignition switch is turned on and the direction signal switch is manually operated to indicate a turn, the front and rear signal lights flash on and off on the side of car for which a turn is indicated. The flashing of signal lights is caused by a Tungsol flasher which is connected into the proper signal light circuit by contacts made in the direction signal switch when switch is set for a turn.

When the direction signal lights are flashing, a signal indicator bulb on instrument panel also flashes, producing a small arrow of green light to indicate the direction for which the signal has been set. For a left turn the green light flashes in the left side of the charge indicator, and for a right turn the green light flashes in the right side of the gasoline gauge.

b. Direction Signal Switch Operation

The direction signal switch and its operating mechanism is enclosed in a housing on steering column just below steering wheel.

The switch must be manually set by moving switch control lever down to indicate a right turn or moving lever up to indicate a left turn.

ming of the steering wheel by the signal switch mechanism.

c. Direction Signal Lamp Circuits

Since the direction signal lights are independent of the headlamp lighting switch and thermo circuit breaker, the wiring circuits are protected by a "Direction Signal" fuse on the fuse block under the cowl. The Tungsol flasher is also mounted on the fuse block, which serves as a terminal block between the signal switch and the chassis wiring.

The direction signal lights are independent of the parking and stop light circuits, and the indicator lamp bulb sockets are grounded to the instrument panel.

Figures 10-99, 10-100, and 10-101 show the direction signal circuits when signal switch is set for No Turn, Right Turn, and Left Turn. Direction signal switch wiring is also shown in the chassis wiring circuit diagrams in Section 10-J.

10-63 TIMING ADJUSTMENT OF SIGNAL SWITCH CAM

If the direction signal switch cam is correctly located on the hub of steering wheel, the switch will automatically return to the "off" position following a turn, provided that the steering wheel has been turned at least one-third revolution. If the wheel has been turned less than one-third revolution, the switch must be manually returned to the "off" position.

The actual returning of switch to the "off" position takes place as the steering wheel returns to the straight-ahead position. If the switch does not operate as described, the switch cam is not in proper relation to the trigger. See figure 10-102, view A.

The switch cam may be adjusted for correct timing as follows:

1. Make certain that steering wheel is installed on steering shaft so that the lower spoke is straight down when front wheels are in




Figure 10-100—Direction Signal Lamp Circuit Diagram, Right Turn Indicated




Figure 10-102—Timing of Direction Signal Switch Cam

brass washers are in good condition, or install new ones.

4. Install cam and washers on steering wheel hub in the following order: brass washer, spring washer, brass washer, cam, brass washer, and snap ring. See figure 10-103. **CAUTION:** Use care when installing parts to avoid distorting and weakening the spring washer.

5. Install steering wheel (par. 7-5) and set the timing of signal switch cam (par. 10-63).

b. Replacement of Signal Switch

1. Disconnect signal switch wires from fuse block under the cowl.

2. Set direction signal switch in "off" position and remove steering wheel (par. 7-5).

3. Insert a small rod through hole in lever plate, pry up on lever retaining spring and pull switch control lever out. See figure 10-103.

4. Remove spring, then remove rollers from outer ends of both spring post levers.

5. Remove the ball retainers from the upper

and right ball bearing seats on lever plate by prying on one end of retainer. Slide the three steel balls out of their grooves.

6. Pry the lever plate lower guide out far enough to clear edge of plate then remove the lever plate, tilting it to clear the upper guide.

7. Lift out the two spring post levers, which have flat washers on the lower pins between levers and switch cover.

8. Remove two switch cover attaching screws, then carefully work the switch wiring through opening in steering column jacket while lifting the signal switch and cover plate assembly far enough to provide access to switch terminals.

9. Unsolder wires from old switch terminals and solder them to terminals of new switch, using rosin core solder. *Do not use acid core solder.* See chassis wiring circuit diagrams in Section 10J for wire color codes and proper connections to switch.

10. Work switch and wiring down into place and install switch cover attaching screws with lockwasher.