

## GROUP 3

# ENGINE FUEL AND EXHAUST SYSTEMS

### SECTIONS IN GROUP 3

Section	Subject	Page	Section	Subject	Page
3-A	Specifications and Description..	3-1	3-D	Fuel and Vacuum Pump.....	3-17
3-B	Trouble Diagnosis.....	3-6	3-E	Carter Carburetor and Climatic Control.....	3-25
3-C	Adjustments and Replacements—Except in Pump and Carburetor Assemblies.....	3-10	3-F	Stromberg Carburetor and Automatic Choke.....	3-38

### SECTION 3-A

## SPECIFICATIONS AND DESCRIPTION

### CONTENTS OF SECTION 3-A

Paragraph	Subject	Page	Paragraph	Subject	Page
3-1	Specifications.....	3-1	3-3	Description of Intake and Exhaust System.....	3-4
3-2	Description of Fuel System.....	3-2			

### SERVICE BULLETIN REFERENCE

Bulletin No.	Page No.	SUBJECT

## 3-1 SPECIFICATIONS

### a. Tightening Specifications

Use a reliable torque wrench to tighten the parts listed, to insure proper tightness without straining or distorting parts. These specifications are for *clean and lightly lubricated threads only*; dry or dirty threads produce increased friction which prevents accurate measurement of tightness.

Part	Name	Thread Size	Torque Ft. Lbs.
Bolt	Fuel Pump to Crankcase.....	$\frac{3}{8}$ -16	25-30
Nut	Manifold.....	$\frac{3}{8}$ -24	25-30
Nut	Exhaust Manifold to Valve Body..	$\frac{3}{8}$ -24	25-30
Bolt	Intake Manifold to Valve Body...	$\frac{3}{8}$ -16	15-20
Nut	Exhaust Pipe Flange to Valve Body Bolt.....	$\frac{3}{8}$ -24	18-20
Nut	Exhaust Pipe Clamp Bolt.....	$\frac{5}{16}$ -18	7-10
Nut	Muffler Support Clamp Bolt.....	$\frac{5}{16}$ -18	7-10
Nut	Muffler Support to Frame Bolt...	$\frac{5}{16}$ -18	7-10
Nut	Tail Pipe Hanger Clamp Bolt....	$\frac{5}{16}$ -18	7-10
Bolt	Tail Pipe Front Hanger to Frame	$\frac{5}{16}$ -18	7-10
Screw	Tail Pipe Rear Hanger to Frame.	$\frac{5}{16}$ -18	15-18

### b. General Specifications

Items	Series 40-44-50	Series 70
Gasoline Tank Capacity (gal.)...	19	19
Gasoline Gauge—Make and Type...	AC, Electric	AC, Type, AJ
Fuel Pump—Make and Type....	AC, Type, AJ, Comb. Fuel and Vacuum	AC, Type, AJ, Comb. Fuel and Vacuum
Fuel Pump Drive.....	Direct from Camshaft	Direct from Camshaft
Fuel Pump Location on Engine...	Right Side Front	Right Side Front
Fuel Pump Pressure, Pounds:		
At Pump Outlet Port.....	4 1/2 to 5 1/2	4 1/2 to 5 1/2
At Carburetor.....	4 to 5	4 to 5
Fuel Filter—Make.....	Moraine	Moraine
Fuel Filter Location.....	At Carburetor Inlet	At Carburetor Inlet
Carburetor Make.....	Carter or Stromberg	Carter or Stromberg
Carburetor Type.....	Downdraft—Dual	Downdraft—Dual
Air Cleaner—Make and Type...	AC Heavy Duty Oil Bath	AC Heavy Duty Oil Bath
Air Cleaner Sump Capacity,		
Grade of Oil Used.....	1 pt. S.A.E. 50	1 pt. S.A.E. 50
Intake Manifold Heated by.....	Exhaust Gas	Exhaust Gas
Manifold Heat Control.....	Valve and Thermostat	Valve and Thermostat
Wind Up of Valve Thermostat at 70° F, with Valve Closed.....	1/4 Turn	1/4 Turn
Exhaust Pipes, O. D.....	2"	2 1/4"

Tail Pipe, O. D. ....	2"	2"
Muffler, Type .....	← Straight Thru Resonance →	
Muffler, Diam. x Length .....	← 5 $\frac{1}{16}$ " x 37 $\frac{1}{8}$ " →	

### c. Carter Carburetor and Choke Calibrations

**IMPORTANT:** Calibrations are identified by the CODE NUMBER and not by model number. Carburetors of same model number but different code numbers are not interchangeable.

Carburetor Model .....	WCD	WCD
Code Number .....	725SA	726SA
Large Venturi Diameter .....	1 $\frac{1}{16}$ "	1 $\frac{1}{16}$ "
Float Bowl Fuel Level .....	← At Bottom of Sight Hole →	
Float Setting .....	← $\frac{1}{2}$ " Cover to Float →	
Metering Rod Jet .....	← .082" →	
Metering Rod (see note below)		
Production .....	75-685	75-677
High Altitude .....	75-703	75-718
Low Speed Jet, Drill Size .....	#65	#68
By-Pass .....	← .0531" →	
Economizer, Drill Size .....	#65	#60
Idle Adjust. Screw Initial Setting, Turns Open .....	← One →	
Idle Bleed .....	← .0531" →	
Idle Discharge Port .....	.030" x .100"	.030" x .115"
Idle Adjustment Screw Port .....	← .0615"-.0655" →	
Float Needle Seat, Drill Size .....	#42	#38
Pump Discharge Jet, Drill Size .....	#74	#74
Pump Intake, Drill Size .....	#32	#32
Pump Discharge Channel (Needle Seat) Drill Size .....	#50	#50
Pump Relief, Drill Size .....	#55	#55
Vacuum Spark Control Port .....	← .039"-.041" →	
Choke Thermostat Setting .....	← 1 Point Rich →	
Choke Suction Hole, Drill Size .....	#42	#42
Fast Idle Setting, F.I. Cam to Boss, Choke Valve Closed .....	.020"	.020"
Fast Idle Setting, Throttle Valve to Barrel Wall .....	.015"	.018"
Choke Unloader Setting, Edge of Valve to Air Horn Wall .....	$\frac{1}{16}$ "	$\frac{1}{16}$ "

**NOTE:** Use production metering rods for altitudes up to 3500 feet. Use high altitude metering rods for altitudes above 3500 feet.

### d. Stromberg Carburetor Calibrations

**IMPORTANT:** Calibrations are identified by the CODE NUMBER and not by model number. Carburetors of same model number but different code numbers are not interchangeable.

Carburetor Model .....	AAUVB-	AAVB-
Code Number .....	267	267
Size .....	7-88B	7-89B
Primary Venturi Diameter .....	1 $\frac{1}{8}$ "	1 $\frac{1}{8}$ "
Float Bowl Fuel Level .....	← See Paragraph 3-10 (c) →	
Float Setting with Gauge .....	← $\frac{1}{4}$ " Above Ends of Gauge →	
Main Discharge Jet .....	#32-28	#32-28
Main Metering Jet (See note below)		
Production .....	.047"	.051"
High Altitude .....	.044"	.049"
Power By-Pass Jet .....	#54	#56

(2 holes)

High Speed Bleeder .....	#70	#70
Float Needle Seat .....	.101"	.101"
Idle Air Bleeder		
Main Body .....	#58	#65
Throttle Valve Body .....	#40	#42
Idle Tube Feed Hole .....	#65	#68
Idle Discharge Holes		
Upper .....	#58	#60
Lower .....	#54	#54
Idle Needle Valve Initial Setting, Turns Open .....	1 $\frac{1}{2}$	1 $\frac{1}{2}$
Pump Discharge Nozzle Holes .....	#68	#68
Pump Blow-off Hole .....	#60	#56
Pump Rod Location in Throttle Lever .....	← Middle Hole →	
Vacuum Spark Control Port .....	#58	#58
Choke Thermostat and Cover Identification No. ....	23	23
Choke Thermostat Setting .....	← At Index Mark →	
Drill Size for Setting Piston and Choke Valve .....	#29	#29
Drill Size for Checking Fast Idle Cam Setting .....	#26	#26
Drill Size for Checking Start Aid Lever .....	#53	#53
Drill Size for Checking Choke Unloader Setting .....	#29	#29

**NOTE:** Use production main metering jet for altitudes up to 3500 feet. Use high altitude jet for 3500 to 9000 feet. Above 9000 feet use jet .002" smaller than specified for high altitude.

## 3-2 DESCRIPTION OF FUEL SYSTEM

### a. Gasoline Tank and Feed Pipes

The gasoline tank is made of two halves ribbon-welded together at the central flanges. Two internal braces spot-welded to the upper half on the centerline of tank at the support seats act as struts to maintain the shape of tank and prevent its flexing from the weight of gasoline and pull of supporting straps.

The filler is securely soldered into an opening in upper half of tank and is supported by an upper and a lower brace soldered to filler and tank. An external vent pipe soldered into the highest point of tank and into the upper end of the filler, and a groove formed in the upper end of filler where the filler cap seats, provide a protected air vent for the tank.

The gasoline tank is attached by two strap type supports to the body under the trunk compartment, where it is seated against strips of anti-squeak material. The rear feed pipe, which is connected to the gasoline gauge tank unit is supported by clips on the body. The rear feed pipe and the front feed pipe, which is connected to the fuel pump, are joined by a rubber hose which provides the flexibility required by movement of the engine on its rubber mountings. Flared type fittings are used at all other feed pipe connections.

### b. Fuel Pump and Gasoline Filter

The combination fuel and vacuum pump is mounted on the right side of crankcase at the front end and is driven directly from the engine camshaft. The construction and operation of the pump assembly is described in Section 3-D (par. 3-14).

A Moraine gasoline filter is located at the gasoline inlet of the carburetor for the purpose of removing any dirt and water which may pass the filter contained in the fuel pump. The filter contains a porous bronze filtering disk and is provided with a plug for draining out the accumulated dirt and water. See figure 3-7.

### c. Carburetor and Automatic Choke Assembly

Engines on all series are equipped in production with either Stromberg or Carter carburetors of the dual-barrel down draft type. *Either make of carburetor is considered "standard" and it is not intended that these units be interchanged to provide "optional" equipment.*

The carburetor assembly incorporates an automatic choke and an accelerator vacuum switch. The construction and operation of the Carter carburetor and choke assembly is described in Section 3-E (par. 3-19 and 3-20) and the Stromberg assembly is described in Section 3-F (par. 3-26 and 3-27). The accelerator vacuum switches on both carburetors are described in Section 10-E (par. 10-32 and 10-33).

A thick fibre gasket is used between the carburetor and the intake manifold to insulate the carburetor from the heat of the manifold.

### d. Air Cleaner and Intake Silencer

All series engines are equipped with heavy duty oil bath air cleaners combined with intake silencers. The air cleaner removes abrasive dust and dirt from the air before it enters the engine through the carburetor. The intake silencer reduces to a very low level the roaring noise made by the air as it is drawn through the intake system. The cleaner and silencer also functions as a flame arrester in event of "back-fire" through the intake system.

On Series 40-~~44~~50, the air cleaner and silencer is mounted crosswise of engine, with the silencer supported by a bracket on the rocker arm cover. On Series 70, the air cleaner and silencer is mounted lengthwise of engine, with air cleaner supported on intake manifold.

The air cleaner consists of an oil sump and a




Figure 3-1—Air Cleaner and Silencer—Series 40-~~44~~50

cleaner element containing a filtering mesh which nests down into the sump above the oil level. The sump is filled with S.A.E. 50 engine oil to a predetermined level.

Incoming air passes downward through the passage between the oil sump and cleaner element, impinges on the surface of the oil and turns upward into the cleaner element. The air carries oil into the element to coat the finely divided filtering mesh. The air is thus exposed to a large oil wetted surface to which the dirt and impurities adhere. The cleaned air then passes through the silencer and into the carburetor. See figure 3-1.

When the throttle is closed, any excess oil on the filtering mesh drips back into the sump carrying the collected dirt with it. This dirt then settles to the bottom of the sump.

### e. Carburetor Throttle Control Linkage

The carburetor throttle control linkage is designed to provide positive control of the throttle valves through their entire range without being affected by movement of the engine in its rubber mountings. The linkage also serves to operate the accelerator vacuum switch when cranking the engine.

The accelerator pedal is connected by a rod and ball joint to an accelerator lever on the lower end of a vertically mounted equalizer shaft. The equalizer shaft is supported at the lower end by a bracket attached to the dash and supported at upper end by a bracket attached to the intake manifold. A throttle operating lever on upper end of equalizer shaft is connected by a rod and ball joint to the throttle shaft lever on carburetor. The throttle return spring is connected to the throttle operating lever on equalizer shaft

and to a boss on intake manifold. See figure 3-8.

On cars equipped with *Dynaflow Drive*, a dash pot is included in the throttle control linkage to prevent engine stalling when the accelerator pedal is suddenly released while driving. The dash pot cushions the closing of the throttle to prevent sudden shut off. The dash pot operating lever and adjusting screw are mounted on the lower end of accelerator equalizer shaft so that the adjusting screw contacts the plunger of dash pot, which is mounted on the equalizer shaft lower bracket. See figure 3-9.

The dash pot is an atmospheric type in which a diaphragm and calibrated by-pass controls the closing of the throttle valves. The dash pot is sealed at assembly and no adjustment or other service is required.

### **3-3 DESCRIPTION OF INTAKE AND EXHAUST SYSTEM**

#### **a. Intake and Exhaust Manifolds**

The intake and exhaust manifolds are separate units jointed together by a valve body through which hot exhaust gasses may be directed into a heat jacket cast on the intake manifold to heat the area below the carburetor.

The intake manifold is of dual type with the carburetor mounted at the middle. The outside barrel of the carburetor feeds into the outside branch of the manifold to supply fuel to Nos. 1, 2, 7, and 8 cylinders while the inside barrel feeds into the inside branch to supply fuel to Nos. 3, 4, 5, and 6 cylinders. See figure 3-2.




Figure 3-2—Fuel Distribution Through Intake Manifold

#### **b. Intake Manifold Heat Control**

The amount of heat supplied to the intake manifold below the carburetor is regulated in accordance with operating requirements by means of the exhaust manifold valve. The valve is controlled by a bi-metal thermostat wound around the valve shaft so as to act as a spring to close the valve when engine is cold. The inner end of the thermostat engages a slot in valve shaft and the hooked outer end engages an anchor stud on the valve body.

When the engine is cold, the valve is held in closed position by the thermostat. Hot exhaust gasses strike the valve and are deflected upward into the heat jacket on intake manifold, where they pass around the intake passages and then pass downward to the exhaust pipe. See figure 3-3.




Figure 3-3—Exhaust Manifold Valve Operation—Sectional View

As the engine warms up, heat conducted to the thermostat through the valve shaft as well as by the increasing air temperature under the hood causes the thermostat to lose spring tension and allow the valve to move toward the open position, thereby reducing the amount of exhaust gas deflected into the heat jacket and consequently reducing the amount of heat to the intake manifold. See figure 3-3.

The exhaust manifold valve is offset or longer on the lower side of the shaft. This allows exhaust gas pressure to force the valve open when the engine is accelerated or operated with wide open throttle, thus reducing the heat to the intake manifold.

The valve is prevented from fluttering by a counterweight on the shaft. An anti-rattle spring is provided to prevent the valve from fluttering and rattling against the valve body in the open and closed position.

#### **c. Exhaust Pipes, Muffler, and Tail Pipe**

The muffler is a "straight through" type with resonance chambers which absorb and dampen out the exhaust sound waves. A slip joint at one end allows for expansion and contraction due to temperature changes. See figure 3-4.

The word "Front" is stamped on one end of the outer shell of muffler to indicate the end to place toward front of car during installation. The drain hole in outer shell should always be located at the bottom.

The exhaust pipe is connected to the exhaust manifold by a bolted flange and a gasket. The




Figure 3-4—Muffler—Sectional View

exhaust pipe and tail pipe connect to the muffler through slip joints provided with clamps. All exhaust system parts are flexibly mounted to allow for engine movement and for expansion and contraction due to temperature changes. All supports have fabric straps which provide the required flexibility and also serve to insulate exhaust system vibration from the chassis. See figure 3-5.




Figure 3-5—Exhaust System and Mountings—All Series