

GROUP 1

LUBRICARE AND BEARING SERVICE

SECTIONS IN GROUP 1

Section	Subject	Page	Section	Subject	Page
1-A	Lubricare Instructions.....	1-1	1-B	Bearing Service.....	1-10

SECTION 1-A

LUBRICARE INSTRUCTIONS

CONTENTS OF SECTION 1-A

Paragraph	Subject	Page	Paragraph	Subject	Page
1-1	Every 1000 Miles—Lubricare..	1-1	1-4	Lubricare as Required.....	1-7
1-2	Every 5000 Miles—Lubricare..	1-5	1-5	Engine Oil Recommendations..	1-8
1-3	Every 25,000 Miles—Dynaflow Transmission.....	1-6	1-6	Rear Axle Lubricant Recommendations.....	1-9

NOTES

1-1 EVERY 1000 MILES—LUBRICARE

a. Chassis Lubricare

1. *Engine.* Check engine oil level only after engine has been stopped for at least three to five minutes to allow oil to drain down.

The oil level should be maintained between the "FULL" and "ADD 1 QT" marks on gauge rod; the space between marks represents 1 quart. It is best to maintain the oil level within one quart of the "FULL" mark. Do not fill above the "FULL" mark. See figure 1-2.

See paragraph 1-5 for engine oil recommendations and when to change oil.

2. *Front suspension, Brake, Clutch and Transmission Controls.* Wipe dirt from lubrication fittings, then apply a good grade of water resistant chassis lubricant, under pressure, at the following points (fig. 1-1):

Lower Control Arms, inner ends

Upper and Lower Ball Joints

Tie Rod Ends, Intermediate Rod, and Idler Arm Support Bushing.

Clutch Release Equalizer

Clutch Pedal Linkage Pins, lubricate with engine oil.

3. *Oil Filter.* Change original oil filter element at *first 1000 miles*. See instructions in paragraph 1-2.

4. *Synchromesh Transmission.* Check oil level, after allowing time for oil to settle. Clean the surrounding area before removing filler plug. Level should be maintained at filler plug opening by adding Multi-Purpose Gear Lubricant (MIL-2105). Use SAE 90 for temperatures not lower than 0°, for temperatures not lower than -25° F. use SAE 80, and for temperatures lower than -25° F. use SAE 80 + 10% kerosine or No. 75. NOTE: *Seasonal changes are necessary.*




Figure 1-1—Chassis Lubricare Chart—All Series

5. *Rear Axle.* Check oil level, after allowing time for oil to settle. Clean the surrounding area before removing filler plug. Level should be maintained at filler plug opening by adding SAE 80 Passenger Car Duty Hypoid Gear Lubricant. **NOTE:** *Draining and flushing is not necessary at any time unless the lubricant has been removed to perform repairs.* When complete refilling is required use only Factory Hypoid Lubricant as specified in paragraph 1-6.




Figure 1-2—Engine and Dynaflo Oil Gauge Rods

6. *Dynaflo Transmission.* Check transmission oil level, *with transmission oil warm, transmission in Parking, and engine idling.* Remove gauge rod located under right side of hood (fig. 1-3), wipe dry with clean cloth then reinstall to full depth. Remove rod and note oil level.

If oil level is more than one inch below the "FULL" mark on gauge rod, add oil specified in paragraph 1-3 but do not fill above the "FULL" mark. Distance between the "FULL" and "ADD OIL" mark is one inch and represents approximately one pint.

7. *Distributor.* Fill oil cup with SAE 10W engine oil.

8. *Air Cleaner.* Normally serviced every 5000 miles. If car is operating in dusty territory, however, check condition of air cleaner and clean it if dirty. See instructions in paragraph 1-2.

9. *Generator; Fan Belt.* Fill front and rear oilers to the caps with light engine oil. Wipe off excess or spilled oil. *Never lubricate the commutator and do not lubricate generator while it is operating.*

If oil reserve in commutator end bearing is exhausted due to failure to lubricate at proper

intervals, the rear oil cup should be filled 3 times, allowing time for each filling to soak down.

Inspect fan belt for cracks and for proper tension. See figure 2-37.




Figure 1-3—Radiator Filling Level—Cold

10. *Radiator.* Check coolant level when engine is cold and add water to line marked "Filling Level—Cold" stamped on head tank. See figure 1-3. **CAUTION:** *Radiator cap should not be removed when engine is hot because relieving the pressure may cause the cooling system to boil, with resultant loss of water or anti-freeze solution. Filling radiator when hot, or filling above level line may result in loss of water or anti-freeze solution through overflow pipe.*




Figure 1-4—Battery Filler Well

11. *Battery.* Add distilled water to bring level to split ring at bottom of filler well. See figure 1-4. **WARNING:** *Do not overfill.* Clean top of battery; if wet with acid, neutralize with soda and wash clean.




Figure 1-5—Manifold Valve

12. *Manifold Valve Shaft.* Place a few drops of graphited kerosene on shaft at each end and rotate shaft to work lubricant into bearings. See figure 1-5. If shaft is frozen, free up by tapping ends of shaft lightly with hammer.

13. *Manual Steering Gear.* Clean adjacent area, then remove gear housing filler plug. Add lubricant only as required to bring level to bottom of filler opening, using Multi-Purpose Gear Lubricant as specified for synchromesh transmissions (step 4). Seasonal or periodic change of lubricant is unnecessary.

14. *Power Steering Gear.* Thoroughly clean dirt from reservoir on top of oil pump then remove cover. Add oil specified for Dynaflo



Figure 1-6—Oil Pump Reservoir

Drive (par. 1-4) as required to bring oil level to mark in reservoir. Make certain that gasket is good before installing reservoir cover. See figure 1-6.

15. *Throttle Control Linkage.* Place a few drops of engine oil at connections. If the accel-

erator equalizer shaft squeaks in the support brackets, work Lubriplate or chassis lubricant into the bearings and wipe off excess lubricant.

16. *Brake Master Cylinder (or Power Brake Reservoir).* On manual brake jobs and on power brake jobs, reservoir is under hood on left side.

Thoroughly clean filler cap nut before removal to avoid getting dirt into reservoir. Add fluid as required to bring level to $\frac{1}{2}$ " to 1" below top of filler opening. Use G.M. or Delco Super No. 11 Hydraulic Brake Fluid. *Never use reclaimed fluid or any mineral oil.* On Bendix Power Brake units bring fluid level to within $\frac{1}{4}$ " of threads on low side of filler opening.

17. *Tires.* Inflate all tires according to tire temperatures, as follows:

24 lbs. *Starting Pressure*—after car has been standing for 3 hours or driven less than one mile.

26 lbs. *City Pressure*—after car has been driven 3 miles or more BELOW 40 MPH.

28 lbs. *Highway Pressure*—after car has been driven 3 miles ABOVE 40 MPH.

WARNING: *It is impossible to inflate tires correctly when HOT. Pressure normally increases as tires heat up when driving. Do not deflate tires to offset this increase in pressure.*




Figure 1-7—Bendix Power Brake Reservoir

b. Body Lubricare

1. *Hood Latch and Hinges.* Lightly coat hood latch, lever, and dovetail bolt with Lubriplate. Apply engine oil to hood hinge pins.




Figure 1-8—Door Lock and Striker

2. *Door locks and Strikers.* Remove dirt and old lubricant from door locks and strikers. Apply one or two drops of SAE 10 engine oil to lock roller pins, and apply a light coat of G.M. Door-Ease Lubricant to top surface of lock roller housings and to teeth in strikers. Wipe off excessive lubricant. See figure 1-8.

3. *Dome Lamp Door Switches.* Coat end of switch plunger and contact point on door with G.M. Door-Ease Lubricant.

4. *Glove Box Door.* Apply a few drops of 10W engine oil to door hinge pins and wipe off surplus. Sparingly coat lock striker with G.M. Door-Ease Lubricant.

5. *Rear Compartment Lid Lock.* Lightly coat lock latch and striker with Lubriplate or chassis lubricant.

6. *Gas Tank Filler Door.* Apply a few drops of 10W engine oil or penetrating oil to hinge pins. Wipe off excess oil to prevent accumulation of dirt.

7. *Lock Cylinders.* If key operates roughly in any lock cylinder blow powdered graphite into key slot. **DO NOT USE OIL.**

8. *Rubber Parts.* Rubber parts such as door weatherstrips and cowl ledge lacing do not require Lubricare unless they are causing squeaks. If Lubricare becomes necessary, *sparingly* apply DC4 Compound, made by Dow-Corning Corp., Midland, Michigan.

9. *Upper Roof Rail Seal.* Models 43-63-53-73. Add silicon oxide powder on lip of seal — full length of seal.

1-2 EVERY 5000 MILES—LUBRICARE

1. *Oil Filter.* Change original filter at first 1000 miles, the second element at first 5000 miles, then change element at each 5000 mile interval thereafter.




Figure 1-9—Oil Filter

Loosen the container bolt and allow oil to drain out. Remove container, element, old gasket. See figure 1-9. Wash and dry container and make sure that gasket surfaces are clean. Install new type G-270 gasket in undercut in filter base; then install new AC Type PF-122 element and old container, tightening bolt securely. Check for oil leaks after engine has run for 5 minutes.

2. *Air Cleaner and Oil Filler Caps.* Every 5000 miles (more often under dusty operating conditions) remove the air cleaner element and the oil filler caps and wash the filtering elements in a non-inflammable solvent. **DO NOT USE KEROSENE.** Allow elements to drain until dry. *Do not use air blast on filtering element.* Oil the filler cap elements.

Wash and dry the air cleaner reservoir then fill to point marked "OIL LEVEL," using one pint of SAE 50 engine oil. See figure 1-10. *Do*

not oil the cleaner element because oil will drain down into reservoir and over-fill it.

Make sure that gasket at center of cleaner element is in good condition before parts are installed. Wipe all oil from outer surface of air cleaner and filler caps.




Figure 1-10—Air Cleaner Element and Reservoir—Series 40

3. *Pump Operating Countershaft — Carter Carburetor Only.* On 2-barrel carburetors, remove dust cover and apply oil in two oil holes above countershaft. See figure 1-11.




Figure 1-11—Countershaft Lubrication—Carter

4. *Gasoline Filter.* Remove drain plug and filter to drain out any accumulation of dirt and water from gas tank. Install new filter.

5. *Horn Cable Connector.* Pull out plunger of horn cable connector on steering column jacket and apply a small amount of Lubriplate. Work plunger in and out to work lubricant in between plunger and the bakelite insulator.

6. *Door Checks and Hinges.* Apply Lubriplate to hold-open springs in front door hinges per figure 1-12. Apply lubriplate solution (*) to rear door lower hinges at pivot points indicated by arrows in figure 1-13.

*Prepare Lubriplate solution by dissolving $\frac{1}{4}$ pound of No. 630 AA Lubriplate in one pint of mineral spirits.




Figure 1-12—Door Hinge Hold-Open Springs




Figure 1-13—Rear Door Lower Hinge

1-3 EVERY 25,000 MILES—DYNAFLOW TRANSMISSION

At 25,000 mile intervals the transmission should be completely drained, the oil pan and screen should be removed and cleaned, and the transmission should be refilled with fresh oil. Transmission **MUST NOT BE FLUSHED** when oil is changed.

a. Approved Oils for Dynaflo Transmission

The following oils are approved for Dynaflo Drive and no other fluid should be used.

1. GMC Automatic Transmission Fluid type A for Dynaflo Drive, available from all authorized General Motors Dealers.

2. Automatic Transmission Fluid, Type A, available through petroleum suppliers. This fluid must have an AQ-ATF number embossed in lid of the can for identification.

b. Draining and Refilling Dynaflo Transmission

1. Warm up transmission, then remove bell housing cover.

2. Loosen one converter drain plug, through opening in flywheel, then turn flywheel until opposite drain plug is straight down and remove this plug to allow converter to drain completely. See figure 1-14.




Figure 1-14—Dynaflo Transmission Drain Plugs

3. Remove filler pipe fitting from oil pan and allow oil pan to drain completely. *Do not remove accumulator caps.* See figure 1-14.

4. Remove oil pan and oil screen, clean thoroughly, and reinstall. Install and tighten all drain plugs and filler pipe, then install bell housing cover.

5. Put $2\frac{1}{2}$ quarts of specified oil (subpar. a.) in transmission. With engine idling and transmission in Parking (P) complete the refilling to bring oil level to $1\frac{3}{4}$ " below "FULL" mark on gauge rod. When transmission oil is warmed up, the oil level should then be at "FULL" mark on gauge rod.

A transmission refill requires approximately $9\frac{1}{4}$ quarts total. A completely dry transmission requires an additional $1\frac{1}{2}$ pints.

1-4 LUBRICARE—AS REQUIRED

a. Clutch Internal Lubricare

Lubrication of internal working parts of the clutch is usually required only at time clutch is assembled and installed; however, if lubrication becomes necessary to eliminate squeaks or correct excessive pedal pressure, follow instructions given in paragraph 4-4.

b. Brake Lubricare

Lubrication of all metal contact points at wheel brake assemblies is normally performed during the major brake adjustment or may be performed whenever a brake drum is removed.

Lubrication of parking brake cables is also performed during the major brake adjustment; however, operation under conditions where mud and water are frequently encountered may require more frequent lubrication. See paragraph 9-9.

c. Rear Wheel Bearing Lubricare

Rear wheel bearings are lubricated by gear lube splash from the differential housing and need no other lubrication. Whenever rear brakes are relined, or axle shafts are removed for other work, it is advisable to inspect rear wheel bearings and oil seals. Replace seals if leaking or worn.

d. Speedometer Cable Lubricare

The speedometer cable is factory lubricated with special all-season grease and normally requires no further service unless it becomes noisy. In extremely hot climates or where considerable dirt and water are encountered, however, it may be necessary to lubricate the cable at intervals of approximately 20,000 miles or every two years. See paragraph 10-58.

e. Sunshade Lubricare

If the sunshade rod turns hard in the support as sunshade is moved up and down, remove retainer screw, pull rod from support and apply G. M. Door-Ease Lubricant. *Do not use oil, which may soil body trim.* Install rod in support and adjust retainer screw to proper tension.




Figure 1-15—Sealing Strip Lubricare

f. Roof Side Rail Sealing Strip

The mechanical ("flipper") type sealing strips mounted on the roof side rails above the doors on some models should be lubricated occasionally to insure proper operation and minimum wear.

1. Open the door and apply a coat of Lubriplate No. 107 or No. 110 to entire length of hinge indicated in figure 1-15. Wipe off any excess. Do not apply this lubricant to the awning gasket.

2. Close the door and apply a thin coat of "DC-4" Silicone Compound or "DC-7" Silicone Emulsion to both sides along length of the awning gasket indicated in figure 1-15. Wipe off excess compound to avoid accumulation of dust.

3. Open the door and operate the sealing strip by hand 10 or 15 times to work lubricants into the hinge.

1-5 ENGINE OIL RECOMMENDATIONS

a. Choice of Engine Oil

(1) *Brand of Oil.* In the selection of the proper brand of oil it is essential to consider the reputation of the refiner or marketer. *It is imperative that the same brand of oil be used at all times.*

(2) *Type of Oil.* There are several types of oil manufactured for use in internal combustion engines. For use in the Buick engine we recommend that a *heavy duty type* oil marked "For Service MS" or "For Service DG" be used

for maximum protection under all driving conditions. Oils marked "For Service MM" or "For Service ML" are not recommended for any Buick engine.

(3) *Grade or Viscosity.* The grade or viscosity (SAE number) of engine oil should be selected for the lowest anticipated temperature at which *cold* engine starting will be required as recommended in the temperature-viscosity chart below.

(4) *Break-in Oils.* Break-in oils or compounds are not necessary in Buick engines and their use is not recommended. Some of these break-in oils contain certain materials which may be harmful. GM HD Concentrate (sub-par. d) is not a break-in oil.

b. When to Change Engine Oil

The crankcase should be completely drained and refilled with new oil of proper viscosity at the end of the first 1,000 miles and every 2,000 to 3,000 miles thereafter. Adverse driving conditions may require more frequent draining and refilling. Adverse driving conditions are those which may cause early contamination of engine oil, such as operation under unusual dust conditions or short runs with a cold engine in very cold weather.

The color of "Service MS" type oil does not indicate its condition since it normally becomes dark (black or gray) after only a few hundred miles of driving. This is because the detergent content envelopes and holds in suspension extremely fine but harmless soot (soft carbon) and lead particles. The oil filter element does not remove this harmless material but it does remove all harmful particles such as road dust, metal chips and hard carbon.

Engine crankcase oils have a definite effect on ease of starting, oil economy, combustion chamber deposits and engine wear. Many commercial crankcase oils contain heavy non-volatile deposits forming components which make the type of combustion chamber deposits that greatly increase detonation and particularly pre-ignition, even though these oils may be designated "For Service MS" or "For

Temperature	Recommended Single Viscosity	Suggested Multi-Viscosity
Not lower than +32° F	SAE 20 or 20W	SAE 10W-30 or SAE 10W-20
Not lower than -10° F	SAE 10W	SAE 10W-30 or SAE 10W-20
Below -10° F	SAE 5W	SAE 5W-10 or SAE 5W-20

Temperature—Viscosity Chart

Service DG." Some commercial crankcase oils are deficient in anti-wear characteristics and may contribute to rapid wear of camshafts, valve lifter assemblies and other highly stressed engine parts. Owners should be urged to use only crankcase oils that have been proven to produce ease of starting, satisfactory oil economy, minimum combustion chamber deposits and adequate protection against wear.

c. Crankcase Flushing

Flushing the crankcase with oils or solutions other than a good grade of 10-W engine oil is not recommended. When flushing to remove contamination appears advisable, use 3 quarts 10-W oil (4 quarts if filter is drained) and idle the engine at 1000 RPM (equivalent to 20 MPH) until the oil is hot, then drain crankcase and oil filter immediately after stopping engine. Fill crankcase with correct quantity and seasonal grade of oil.

d. Use of Buick HD Concentrate

GM HD Concentrate, available through Parts Department is a compound of the materials used by oil refiners to manufacture high detergency motor oils. It is intended for use in engines operating under aggravated conditions where engine deposits, rust and corrosion cannot be adequately retarded by motor oils readily available to the average motorist. It is especially recommended for engines operated under restricted conditions such as frequent stops, short trips and

slow speeds where such symptoms as sticking valves, valve lifters and rings are noticed.

Although HD Concentrate may be used continually it is normally unnecessary to use it with every crankcase refill. When used, the instructions on the container should be carefully observed.

1-6 REAR AXLE LUBRICANT RECOMMENDATIONS

a. Lubricant Recommendations

Buick rear axles are filled at the factory with a special hypoid gear lubricant. It is not necessary to remove the original lubricant at any time except when it has become contaminated, or when it is required for inspection of parts or for repairs. Therefore there is no longer a drain hole in the rear axle housing.

Under no circumstances should the factory lubricant be removed from the rear axle to be replaced with any other type of lubricant.

In all cases of complete refilling of rear axle only *Passenger Car Duty Hypoid Gear Lubricant* is recommended. This is the same lubricant (lead soap—active sulphur type) as furnished with Buick replacement ring and pinion gear sets, and it may be obtained from any GM Parts Warehouse.

When adding lubricant to bring it to proper level *Passenger Car Duty Hypoid Gear Lubricant* is recommended.