

SECTION 6-B

REAR AXLE SERVICE PROCEDURES

CONTENTS OF SECTION 6-B

Paragraph	Subject	Page	Paragraph	Subject	Page
6-4	Removal and Installation of Rear Axle Assembly.....	6-6	6-9	Disassembly and Assembly of Rear Universal Joint.....	6-10
6-5	Replacement of Rear Axle Strut Rod.....	6-7	6-10	Removal and Installation of Propeller Shaft Bearing or Torsional Damper.....	6-12
6-6	Replacement of Axle Shaft, Wheel Bearing, or Oil Seal.....	6-7	6-11	Installation of Carrier Assembly, Propeller Shafts and Torque Tubes.....	6-12
6-7	Removal of Torque Tubes, Propeller Shafts, and Carrier Assembly.....	6-9	6-12	Disassembly of Carrier Assembly.....	6-14
6-8	Cleaning and Inspection of Rear Axle Parts.....	6-10	6-13	Assembly of Carrier Assembly.....	6-16

6-4 REMOVAL AND INSTALLATION OF REAR AXLE ASSEMBLY

It is not necessary to remove the rear axle assembly for repair or replacement of a strut rod, an axle shaft, a wheel bearing, or a wheel bearing seal; however, the rear axle assembly should be removed for any other repairs.

a. Removal of Rear Axle Assembly

1. Place car stands solidly under frame so that rear end of car is high enough to permit working underneath and place a floor jack under center of axle housing so it just supports weight of rear axle assembly.

2. Disconnect lower ends or rear springs.

3. Disconnect track bar at axle end.

4. Disconnect lower ends of rear shock absorbers.

5. Disconnect parking brake cable at rear cable sheave and at bracket on torque tube. Disconnect brake hose from pipe at torque tube bracket and remove yoke. Cover hose and brake pipe openings to prevent entrance of dirt.

6. Remove two opposite torque tube flange bolts, replacing them with two 3" guide pins. Remove other flange bolts. See Figure 6-3.

7. Roll rear axle assembly out from under car.

b. Installation of Rear Axle Assembly

The driven yoke of the universal joint fluc-

tuates in speed as torque is being transmitted through the joint. In other words, although the driving yoke rotates at a constant speed, the driven yoke speeds up and slows down twice per revolution. With only one universal joint, the effect of this velocity fluctuation isn't noticeable. However, with two universal joints, a serious vibration will be set up if the joints are not properly aligned in relation to each other.

To eliminate this condition, the forward end of the front propeller shaft and the rear yoke of the front universal joint each have two blind splines 180° apart. *The two propeller shaft blind splines must be carefully aligned with the two universal joint blind splines or the propeller shaft will not slide into the universal joint. This insures that the rear axle cannot be installed unless the two*




Figure 6-3—Removing Torque Tube from Torque Ball

universal joints are properly aligned. See Figure 4-14 for these blind splines.

1. Check torque ball for evidence of oil leaking and for wear of universal joint bushing. If torque ball needs repair or replacement, see paragraph 4-12.

2. Check propeller shaft seal for oil leaks or damage. Install a new seal and O-ring if necessary. Seal should be installed in torque tube flange with O-ring over seal O.D.

3. Rest car solidly on stands placed under frame, with rear end of car high enough to permit working underneath. Roll rear axle assembly under car.

4. Carefully move axle assembly into place, guiding propeller shaft and torque tube into proper alignment with torque ball using two 3" guide pins to avoid damage to propeller shaft seal. Rotate rear wheel to align propeller shaft and universal joint blind splines. See figure 4-14.

5. Connect torque tube to torque ball, tightening bolts to 50 ft. lbs.

6. Connect rear springs to rear axle assembly.

7. Connect shock absorber and track bar lower ends loosely to axle.

8. Connect brake hose to brake pipe at torque tube bracket and lock in place with yoke. Connect parking brake cable through bracket on torque tube and to brake cable sheave. Bleed rear wheel cylinders and adjust parking brake as described in paragraphs 9-7 and 9-9.

9. Lower car on wheel stands. Then tighten shock absorber lower ends, and track bar lower end.

NOTE: Normal weight must be on rear wheels when tightening these parts so that rubber bushings will be clamped in neutral position.

10. Lower car to floor. Fill axle housing to filler plug hole using approved gear lubricant.

6-5 REPLACEMENT OF REAR AXLE STRUT ROD

The rear ends of the strut rods are attached to the axle housing by nuts. The front ends of both strut rods are bolted through rubber compression bushings to a bracket welded on the torque tube. Strut rods may be replaced with-




Figure 6-4—Removing Rear Axle Shaft

out removing rear axle assembly. When installing a strut rod, always tighten the mounting bolt at the front end first to allow the elongated hole in the rear end to slide to normal position.

CAUTION: When a strut rod is damaged, there is a good possibility that the rear axle housing is sprung.

6-6 REPLACEMENT OF AXLE SHAFT, WHEEL BEARING, OR OIL SEAL

a. Removal of Axle Shaft Assembly

1. Place car stands solidly under rear axle housing so that wheels are clear of floor.




Figure 6-5—Removing Rear Wheel Bearing Retainer Ring

2. Remove rear wheel and brake drum.
3. Remove nuts holding wheel bearing retainer plate to brake backing plate, leaving bolts in place to support backing plate.
4. Pull out axle assembly using Puller J-6176 with a slide hammer. Be careful not to disturb brake backing plate. See Figure 6-4.
5. Replace two opposite nuts finger tight to hold brake backing plate in position.

b. Replacement of Wheel Bearing or Oil Seal

The oil seal is located on the outer side of the bearing between the inner and outer races of the wheel bearing.

1. Nick the wheel bearing retaining ring.

NOTE: The ring need not be completely split, but nicked deep enough in 3 or 4 places to spread it. Retaining ring will then slip off with light pressure. See Figure 6-5.

2. Press the wheel bearing off, using Remover J-6525 either in a press or in a set-up using Ram and Yoke Assembly J-6180 and Adapter J-6258 as shown in figure 6-6.




Figure 6-6—Removing Rear Wheel Bearing

3. If seal only is defective, pry old seal from bearing. Examine seal lip surface of bearing for smoothness, then install new seal using Guide J-6213. Push seal in carefully with fingers until lip is over bearing inner race; then




Figure 6-7—Installing Rear Wheel Bearing Oil Seal




Figure 6-8—Installing Rear Wheel Bearing or Retaining Ring

remove installing guide and drive seal in flush with a flat wood block. See Figure 6-7.

4. Press bearing and seal assembly against shoulder on axle shaft using Installer J-6257 either in a press or in a set-up using Ram and Yoke Assembly J-6180 and Holder J-6407 with Ring J-6407-2 shown in figure 6-8.

NOTE: Bearing retainer plate must be on axle shaft before bearing is installed.

5. Press retaining ring against bearing.

c. Installation of Axle Shaft

Rear axle shafts are not interchangeable between sides; the right shaft is longer than the left.




Figure 6-11—Removing Bearing from Front Yoke

6. Rotate shaft 180° and again apply force around bearing in which washers were installed. This will completely remove bearing from yoke.

7. Remove front yoke from spider. Remove remaining bearing using a brass drift.

8. Clamp or support rear yoke in vise. Drive bearing out until snap ring groove is visible using a drift applied to center part of spider. See figure 6-12.

9. Rotate shaft assembly 180° and repeat Step 8 to partially remove opposite bearing.

10. Hold spider up and place flat washers in lower end of bearing. Drive down on spider using a drift until bearing comes out of yoke.

11. Remove spider from yoke.

12. Drive remaining bearing out using a brass drift.

b. Assembly of Rear Universal Joint

Make sure each round bearing assembly has a full set of needle rollers (25), has a cork packing and retainer washer, and is well lubricated with high melting point lubricant.

1. Drive a bearing in one side of yoke welded to shaft only as far as snap ring groove, using a soft faced hammer.

2. Position spider in partially installed bearing. See figure 6-13. NOTE: Spider must be installed so locating lugs are facing toward propeller shaft tube.




Figure 6-12—Removing Bearing from Rear Yoke

3. Hold spider in place to prevent loss of needle rollers and completely install bearing.

4. Install opposite bearing making sure that spider is centered so that needle rollers will not be jammed or dislodged. Check movement of spider in bearings for smoothness.

5. Start a bearing in one side of front yoke.

6. Position yoke and bearing over spider and completely install bearing.




Figure 6-13—Installing Spider in Rear Yoke

7. Install remaining bearing while spider is centered so that needle rollers are not jammed or dislodged. Check for smooth movement of forward yoke.

8. Install snap rings. *NOTE: If snap ring cannot be installed on one side, drive bearing toward other side until snap ring groove is clear of yoke.*

6-10 REMOVAL AND INSTALLATION OF PROPELLER SHAFT BEARING OR TORSIONAL DAMPER

a. Bearing

The propeller shaft bearing is a sealed ball bearing which is lubricated for the life of the bearing. The bearing should not be removed except to replace it with a new one when noisy, worn or excessively loose.

1. With rear propeller shaft separated from front propeller shaft, place rear propeller shaft and bearing assembly in a press so that it is supported under bearing with shaft down.

2. Using a sleeve or shaft slightly smaller than inside diameter of bearing, press universal joint front yoke down through bearing.

3. To install a new bearing, place rear propeller shaft in a press so that it is supported under both sides of front yoke.

4. Start new bearing squarely on yoke. Using a heavy flat plate, press bearing on yoke until it bottoms against shoulder. *CAUTION: Be careful that bearing does not cock as it starts onto yoke.*

b. Torsional Damper

The torsional damper is installed on the rear end of the rear propeller shaft. See Figure 6-14. Its purpose is to reduce torsional vibration of




Figure 6-14—Rear Propeller Shaft Torsional Damper

the drive train to a point where it cannot be noticed. The damper should be good for the life of the rear propeller shaft and should not be removed unless it becomes loose on the propeller shaft.

1. To remove damper, place rear propeller shaft in a press so that it is supported under damper with shaft down.

2. Using a sleeve or shaft slightly smaller than outside diameter of propeller shaft, press shaft down through damper.

3. To install a new damper, place rear propeller shaft in a press so that it is supported under both sides of rear yoke.

4. Lubricate rubber in new damper with soap solution or tire mounting compound. Start damper squarely on rear end of propeller shaft. Using a heavy flat plate, press damper on propeller shaft until it is flush with rear end of shaft. *CAUTION: Do not use oil, grease, or silicone as a lubricant. Oil or grease would cause the rubber to deteriorate, and silicone might allow the damper to turn on the shaft.*

6-11 INSTALLATION OF CARRIER ASSEMBLY, PROPELLER SHAFTS AND TORQUE TUBES

a. Installation of Carrier Assembly

Before installing the carrier assembly, the carrier and axle housing mounting surfaces must be clean and free of any old gasket material. Also, make sure these surfaces are free of any burrs or nicks.

1. Rotate axle housing so that carrier mounting surface is upward and install a new carrier gasket.

2. Install carrier assembly in axle housing using Sling J-6247 as shown in figure 6-10. Install nuts and tighten them evenly and alternately to 50 ft. lbs.

3. Install both axle shaft assemblies (par. 6-6).

b. Checking Front Propeller Shaft

The front propeller shaft runs in a definite location due to the fact that it is held in the splines of the rear propeller shaft by a spring pin. If this propeller shaft is handled carefully during removal and installation, it will not normally be necessary to perform a dial indicator check for straightness.




Figure 6-15—Front Propeller Shaft Run-Out Specifications

However, if there is a noise or vibration at high speeds which might be caused by a bent shaft (par. 6-3, c), or if there is any possibility that the shaft has been damaged due to rough handling or collision, the propeller shaft should be checked for straightness as follows:

1. Support front of propeller shaft on a V-block placed under the seal surface at "A." Support rear of propeller shaft on a V-block placed under the shoulder at "B." See figure 6-15.

2. Mount a dial indicator on a suitable base and check run-out at "C" and "D" located $3\frac{3}{4}$ " outboard from each end of tube. Then check run-out at "E" located near center of tube.

3. Run-out at "C" and "D" must not exceed .006"; run-out at "E" must not exceed .010". However, care must be taken *not* to include indicator variation due to the *shape* of the tube in run-out readings. Indicator fluctuation due to ridges, flat spots, or an oval tube must be ignored.

NOTE: *If the propeller shaft is turned rapidly, it is easier to ignore any surface imperfections and to properly locate the high center of a bent propeller shaft.*

4. If run-out exceeds specifications due to a bent propeller shaft, it is probably more economical to replace the shaft than to attempt straightening it. However, if it is decided to straighten the shaft, mark points of greatest run-out along the length of the tube. By studying these high center marks, the general type and extent of the bend may be readily seen and the straightening procedure planned accordingly.

c. Straightening Front Propeller Shaft

In order to straighten a front propeller shaft, the following tools are necessary; an arbor press, a bending block and two support blocks which are shaped to conform to the tube, and a

support which conforms to the seal sleeve shape. This straightening set-up should be near the checking set-up because the shaft must be re-checked after every bend.

The method used in straightening depends on the type of bend. In general, pressure should be applied at the high center of the bend with the shaft supported at both ends of the bend. Then by checking and bending repeatedly, the high center can be brought down until the indicator reading at this point is approximately the same as that at a point 180 degrees opposite. When bending the shaft, use steady pressure and not shock blows to spring the shaft.

d. Installation of Propeller Shafts and Torque Tubes

1. Check propeller shaft and pinion splines for excessive wear. Remove any nicks or burrs. Inspect front propeller shaft seal surface for nicks, scratches, or a groove. If badly damaged, front propeller shaft must be replaced. Inspect rear universal joint and support bearing for wear or excessive looseness. A worn joint may be repaired (par. 6-9), but a worn bearing must be replaced.

2. Check torque tube flanges and torque tube mounting surface on carrier. Remove any burrs or nicks.

3. Install O-ring seal over pinion to a point just past splines. Be careful not to nick or cut seal on splines. Inspect rear propeller shaft seal surface inside rear coupling. Pack coupling with a good grade of chassis grease, bringing level to inner end of splines.

NOTE: *It is a good practice to grease all splines before assembling.*

4. Install rear torque tube on carrier with brake return spring bracket down. (No gasket is used.) Tighten bolts to 50-60 ft. lbs. Rotate axle housing so that rear torque tube extends in a horizontal direction.

5. Slide complete propeller shaft assembly into front torque tube until support bearing is seated against shoulder. *Be careful of seal surface while sliding propeller shaft into torque tube.*

6. Push front torque tube and complete propeller shaft assembly into place in rear torque tube. If difficulty is encountered in engaging pinion splines, use Socket J-6192 to rotate propeller shaft.

7. Position front torque tube with strut rod bracket down. No gasket is used between front and rear torque tubes, but make sure that bearing retainer plate is in place. Install front to rear torque tube bolts and nuts. Tighten to 65-75 ft. lbs.

8. Connect strut rods to torque tube bracket and tighten bolt and nut to 75 ft. lbs.

9. Install brake lines on strut rods and torque tube.

10. Install rear axle assembly in car (par. 6-4, b).

6-12 DISASSEMBLY OF CARRIER ASSEMBLY

a. Removal and Disassembly of Ring Gear and Case Assembly

1. Using Sling J-6247, place carrier assembly in suitable mounting fixture such as Fixture J-6177. See Figure 6-16.




Figure 6-16—Placing Carrier in Holding Fixture

2. It is advisable to check the existing gear lash with a dial indicator as described in paragraph 6-13, f. This will indicate gear or bearing wear or an error in backlash or preload setting. It will also enable used gears to be reinstalled at original lash setting to avoid changing gear tooth contact.

3. Remove differential bearing pedestal clamp bolts and open pedestals by tapping a wedge in each pedestal slot.

CAUTION: *Do not use excessive force on wedges as pedestal bores may be permanently distorted.*

4. Pull differential bearing supports with Puller J-6553 using the following procedure:

(a) Using a screwdriver, turn expanding screw in puller body in a counterclockwise direction to retract pins, then insert puller body into differential bearing support until reference line on tool is flush with end of support and punch mark is in general direction of hole in support. See Figure 6-17, View A.

(b) Expand pins a slight amount by turning expanding screw with screwdriver in a clockwise direction until a light drag on pins is felt, then move tool as required to engage pins with holes in support. Fully expand pins.

(c) Apply a pulling force on bearing support puller by using either of the following methods:

(1) Place sleeve over puller and install draw bolt with large thrust washer, thrust bearing, and small washer as shown in Figure 6-17, View B; then thread draw bolt in tapped hole in puller body. Using a suitable wrench, apply a reasonable amount of torque to draw bolt; then strike carrier pedestal with a solid hammer blow as shown in Figure 6-17, View B.

(2) Place sleeve over puller and install hydraulic ram screw as shown in Figure 6-17, View C. Place a reasonable load on ram, then strike carrier pedestal a solid hammer blow in direction of heavy arrow.

5. Install Spreader J-6185 shown in figure 6-37. Tighten spreader bolt just enough to free case assembly.

CAUTION: *Do not spread pedestals any farther than necessary or they may be permanently sprung.*

Lift case straight out until side bearings are half-way clear of pedestals. Then take hold at bearings with both hands to prevent bearings from dropping and lift case assembly out. Keep right and left bearings, shims, and supports in sets so that they may be reinstalled in the same positions. Remove spreader tool.




Figure 6-17—Removing Differential Bearing Support

6. Mark ring gear and case, so they may be reassembled in same relative position. Remove ring gear.

7. Drive differential pinion axle spring pin, pinion axle and pinion shield from case. Mark side gears, pinions, and washers so they may be reinstalled in same sides. Remove side gears, pinions, and washers.

8. If a differential bearing is to be replaced, pull bearing outer race from case with Remover J-6552 using the following procedure: (See Figure 6-18)

(a) Insert puller jaws with lips down under edge of outer race.

(b) Carefully thread spreader screw into jaws, making sure that threads are not crossed. Leave spreader screw one full turn away from jaws.

(c) Place retainer ring over jaws, tapping

it down while pulling up spreader screw so that ring fits snugly around jaws, then turn spreader screw tightly against jaws.

(d) Place sleeve over assembled tool. Insert draw bolt through washer, thrust bearing and sleeve. Then thread it into spreader screw and pull bearing outer race.

b. Removal of Pinion and Bearings

1. Check pinion pre-load as described in paragraph 6-13. This will indicate excessive bearing wear or an error in pre-load setting.

2. It is advisable to check the pinion depth setting as described in paragraph 6-13. This will indicate any error in the existing setting and will also enable used parts to be reinstalled at original setting to avoid changing gear tooth contact.

3. Cut out and drive up staked section of pinion bearing lock nut with cape chisel, being




Figure 6-18—Removing Differential Bearing Outer Race

careful not to damage threads on pinion. Hold pinion nut to carrier with Holder J-6245 and turn pinion clockwise through nut using socket J-6192 and Handle J-6246. See figure 6-19.

4. As pinion nut is removed, hold hand under pinion to catch it, as it may fall through. Remove pinion nut O-ring seal from pinion. If necessary, tap pinion out with a soft hammer, being careful to guide pinion with hand to avoid damage to bearing outer races.




Figure 6-19—Removing Pinion Nut

5. If rear pinion bearing is to be replaced or pinion depth setting is to be changed, remove rear bearing from pinion shaft using Remover J-6531 and Holder J-6407 in a press or in a




Figure 6-20—Removing Rear Pinion Bearing

set-up using Ram and Yoke Assembly J-6180 as shown in figure 6-20.

6. Pry pinion oil seal from carrier, being careful not to damage front pinion bearing. If front pinion bearing is to be replaced, drive outer race from carrier using a drift in slots provided for this purpose.

7. If rear pinion bearing is to be replaced, drive outer race from carrier using a drift in slots provided for this purpose.

6-13 ASSEMBLY OF CARRIER ASSEMBLY

a. Installation of Pinion and Bearings

Before installation of pinion and bearings make certain that interior of carrier housing is absolutely clean and dry. Also make certain that parts to be assembled are clean and that pinion bearing shims are not burred. Bearings and oil seals should be lightly lubricated with rear axle lubricant just before assembly.

1. Drive front pinion bearing outer race against shoulder in carrier using Replacer J-6197 with driver handle. See figure 6-21.

2. Drive rear pinion bearing outer race against shoulder in carrier using Replacer J-6255 with driver handle. See figure 6-22.

3. Whenever a new carrier, a new pinion, or




Figure 6-21—Installing Front Pinion Bearing Outer Race




Figure 6-22—Installing Rear Pinion Bearing Outer Race

a new pinion bearing is to be used, a trial assembly must be made in order to determine correct pinion depth setting and correct pinion bearing pre-load. For a starting pinion depth setting, use a shim with a nominal thickness of .048". Place this shim against head of pinion and install rear pinion bearing using Replacer J-6377 and Holder J-6407 with Ring J-6407-2 in a press or as shown in figure 6-23.

4. For a starting pinion bearing pre-load adjustment, use a pair of spacers with a nominal thickness of .435". Place these spacers on pinion and hold pinion assembly in position in carrier. Install front pinion bearing and pinion nut. Hold nut to carrier with Holder J-6245




Figure 6-23—Installing Rear Pinion Bearing

and turn pinion counterclockwise into nut, using Socket J-6192 and Handle J-6246. *Do not install pinion seal at this time.* Torque pinion nut to 80 foot pounds using Torque Wrench J-1313 on outer end of Handle J-6246. (This amounts to an actual 250 ft. lbs. torque at nut.) See figure 6-24.




Figure 6-24—Tightening Pinion Nut

5. Rotate pinion three or four times to seat bearings. Turn pinion slowly with an inch pound torque wrench; bearing pre-load should be 10 to 30 inch pounds. See Figure 6-25. If




Figure 6-25—Checking Pinion Bearing Pre-Load

pre-load is under 10 inch pounds, replace spacer with a thinner one; if pre-load is over 30 inch pounds, remove pinion nut and front bearing and replace pre-load spacer with a thicker one. These spacers are furnished to be used in pairs so that possible thicknesses range from .400" to .470" by thousandths. Service spacers are marked with their thickness in thousandths.

If pre-load is over 30 inch pounds, the approximate number of thousandths to be added to spacer thickness may be determined from the table in Figure 6-26.

If preload in inch pounds is:	Add to pinion spacer thickness:
40	.001"
50	.002"
60	.003"
70	.004"
80	.004"
90	.005"
100	.006"

Note: Correct pinion preload is 10-30 inch pounds.

Figure 6-26—Table for Correcting Excess Pinion Pre-Load

b. Pinion Setting Marks and Setting Gauges.

All Buick ring and pinion gear sets are selectively matched for best operating position and proper tooth contact. After matching, a serial number is etched on one tooth of pinion and on

rear face of gear to aid in keeping matched parts together. See Figure 6-27. Parts having different serial numbers must never be used together.

Ring and pinion gear sets are matched in a special test machine which permits adjustment of pinion depth in ring gear until a point is reached where best operation and proper tooth contact under load is obtained. At this point, the setting of the pinion with reference to the centerline of the ring gear is indicated by the machine. This setting may vary slightly from the design or "nominal" setting due to allowable variation in machining the parts.

This variation in thousandths of an inch over or under the "nominal" setting is etched on the small end of a pinion tooth. See figure 6-27. When a pinion is marked "+" (plus) it means that the rear face of the pinion when pressed in the carrier must be at the "nominal" distance from the centerline of the side bearing pedestals *plus* the amount indicated on the pinion tooth. When a pinion is marked "-" (minus) it means that it must be located at the "nominal" distance *minus* the amount indicated on the pinion tooth.




Figure 6-27—Ring and Pinion Gear Set Markings

The dial indicator type Pinion Setting Gauge J-5647 is used with adapters to provide a fast and accurate method of checking pinion location; it gives a direct reading on a dial indicator that does not require computation or reference tables. See figure 6-28.

Before checking the pinion setting, pinion bearing pre-load must be right because incorrect pre-load will cause a false pinion depth reading.

c. Checking Pinion Setting

Pinion Setting Gauge J-5647 consists of a "master gauge" and an "indicator gauge" upon which a dial indicator is mounted. Adapter Set J-5647-17 is not used when "zeroing the gauge," but is used in place of the discs when checking the pinion setting. See figure 6-28.

1. Make certain that the gauge parts are clean, particularly the center and discs of indicator gauge, the centering holes, indicator pads, disc pads on the master gauge, and the adapter holes and outer surfaces.

2. Install the discs on the "indicator gauge" and install the small contact button on the stem of the dial indicator. Mount the dial indicator on the indicator gauge. See figure 6-28.




Figure 6-28—Pinion Setting Gauge J-5647 and Adapters

3. Place indicator gauge on the master gauge so that the spring loaded center is engaged in the centering hole corresponding to the indicator pad "B," which is used for any of the following gear ratios stamped on pinion: 43-11 (3.91 to 1), 47-14 (3.36 to 1), 42-13 (3.23 to 1), 43-14 (3.07 to 1).

NOTE: Pad "A" is used for certain prior model gear ratios.

4. Center the indicator contact button on the specified indicator pad and lock the indicator by tightening the thumb screw.

5. Hold yoke down firmly, with both discs contacting the horizontal and vertical pads on master gauge, and set the dial indicator at zero ("0").

6. Make sure that differential bearing support bores are free of burrs and that the center of the pinion is clean.

7. Rotate the pinion until the blank tooth between the matching number and the pinion setting mark is slightly counterclockwise of top center (at about 11 o'clock). This tooth is called the gauging tooth (Fig. 6-27) because it is used for locating and gauging during production and should therefore be used for gauging in service.

8. Drive a wedge into each pedestal split and spread them just enough so that Adapters J-5647-17 will slip in. Then place the indicator gauge in the carrier as follows: (see figure 6-29).

(a) Remove discs from indicator gauge and hold it in position in the carrier with pins centered in the pedestal bores.




Figure 6-29—Checking Pinion Setting

(b) Slide long adapter through pedestal bore farthest from pinion and over gauge pin. Then slide short adapter in place on other side.

(c) Be sure that gauge center is engaged in pinion center and that adapters are against shoulders of gauge. Then remove pedestal wedges.

(d) Turn pinion if necessary so that indicator contact button has a good contact with gauging tooth of pinion.

9. Press gauge yoke firmly downward toward pinion and read dial indicator noting whether it is plus (+) or minus (-) as indicated by arrows on surface of yoke.

CAUTION: *This reading does not indicate the thickness of the shim to be used, but only indicates the variation from the "nominal" setting of the gauging face of this pinion.*

10. Recheck indicator "zero setting" on master gauge with discs to make sure it was not changed in handling.

11. If the old ring and pinion gear set is being reinstalled and it has been in use long enough to establish a wear pattern on teeth, the original pinion setting found before removal should be maintained to avoid changing tooth contact.

12. If the ring and pinion set is new, or has not been in use long enough to establish a wear pattern on teeth, the dial indicator reading should be within .0015" of the pinion setting marked on pinion.

13. If pinion setting is not as specified, adjust as follows:

d. Adjustment of Pinion Position

The pinion setting is adjusted by changing the thickness of the shim which is located between the rear pinion bearing inner race and the head of the pinion. These shims are furnished in thicknesses ranging from .040" to .070" by thousandths.

1. Remove pinion assembly and press off rear pinion bearing using Remover J-6184 and Holder J-6274. (Par. 6-12, b.)

2. Remove shim from pinion, wipe dry and measure its thickness with a micrometer. Service shims are marked with their thickness in thousandths. Measure shim anyway, however, as any slight error here will necessitate pulling

pinion and bearing again.

3. Increase or decrease thickness of shim as required to obtain proper pinion setting.

If pinion is marked "+8", but gauge reads "+6", *decrease* thickness of shim by .002". If gauge reads "+10", *increase* thickness of shim by .002".

If pinion is marked "-8", but gauge reads "-6", *increase* the thickness of shim by .002". If gauge reads "-10", *decrease* thickness of shim by .002".

CAUTION: *Whenever a new pinion is to be installed, its depth setting must be gauged. Even though the new pinion has the same depth marking, it may require a different thickness shim because the dimension from the gauging face to the bearing shoulder varies in different pinions.*

4. Change pre-load spacers by same amount that shim thickness was changed. If thickness of shim was *decreased* .002", use spacers with .002" *less* thickness. If thickness of shim was *increased* .002", use spacers measuring .002" *thicker*.

5. Reinstall rear pinion bearing on pinion with new thickness shim. (Par. 6-13, a.) Install a new pinion nut O-ring seal.

6. Lubricate new pinion seal with axle lubricant and install with lip toward bearing, using Installer J-6200. See Figure 6-30. Reinstall




Figure 6-30—Installing Pinion Seal

pinion and bearings carefully in carrier with new thickness pre-load spacers. Install pinion nut and tighten to 80 foot pounds using Torque Wrench J-1313 in outer end of Handle J-6246 as shown in figure 6-24.

7. Recheck pinion setting with gauge. Setting for new pinion must be within .0015" of setting marked on pinion. Setting for used pinion should be within .0015" of original setting (as checked before disassembly).

8. Recheck pinion bearing pre-load with torque wrench. Pre-load must not exceed 40 inch pounds including drag of lubricated new seal. When pinion pre-load and depth settings are correct, stake pinion nut securely.

e. Assembly of Differential Case, Gears and Bearings

1. Drive differential bearing outer races into case, using Replacer J-6263. See figure 6-31.



Figure 6-31—Installing Differential Bearing Outer Race

2. Install side gears, pinions, and washers in case. If same parts are used, replace in original sides. Install pinion axle. Drive spring pin through hole in pinion axle until flush with case.

3. Check matching numbers on ring gear and pinion to make sure the two parts have not been mixed with another gear set. See figure 6-27.




Figure 6-32—Installing Ring Gear on Differential Case

4. After making sure that mating surfaces of case and ring gear are clean and free of burrs, bolt ring gear to case using three Studs J-6251 to align parts. See figure 6-32. If same ring gear and case are used, line up marks so they are assembled in same relative positions.

Do not use lock washers or any substitute bolts.

5. First tighten bolts alternately on opposite sides of the case to 35 foot pounds torque, then tighten in the same manner to 70 foot pounds.

f. Installation and Adjustment of Ring Gear and Case Assembly

1. Before installation of ring gear and case assembly make sure that differential bearing and bearing support surfaces in carrier pedestals are clean and free of burrs. Remove any burrs which might prevent bearings or bearing supports from seating properly.

2. Place case assembly and differential bearings in position in carrier. If same bearings are used, install in original positions. Insert Support Tools J-6194-01 through the pedestal bores into the bearing inner races. Press tools toward each other to seat them, using hand pressure. If support tools are loose, install pedestal clamp bolts and nuts and tighten lightly until support tools can just be moved by twisting them. If support tools are too tight, loosen them as necessary by slightly wedging pedestals open with chisels. See figure 6-33.

3. Rotate the differential assembly three or four times to seat bearing rollers, then manually adjust the whole assembly sideways to get .008" gear backlash. The assembly tools may be tapped lightly with a hammer to seat them. Check backlash as follows:




Figure 6-33—Positioning Differential for Correct Backlash

(a) Mount dial indicator as shown in figure 6-34. Use a small button on indicator stem so that contact can be made near heel end of tooth. Set dial indicator so that indicator stem is as nearly as possible in line with gear rotation and perpendicular to the tooth surface. If stem bears against edge of tooth, or stem is at considerable angle to the line of gear rotation, or at a considerable angle to face of the




Figure 6-34—Checking Backlash with Dial Indicator

tooth, a false indication of backlash will be obtained.

(b) Check gear lash at three or four points around ring gear. Lash must not vary more than .003" around ring gear. If lash varies over .003" check for burrs, uneven bolting conditions, or distorted case flange, and make necessary corrections.

CAUTION: Any gear lash check must be made with pinion locked to carrier to be sure it cannot turn.

(c) Adjust gear lash at the point of minimum lash to .008" for all new gears. If original gear set is being reinstalled, the original lash should be maintained.

4. Measure with a shim between each bearing and its pedestal. Do not remove support tools for measuring. Select shim that measures .002" thicker than largest shim that can be inserted for each side; this should pre-load each differential bearing .002". These shims are furnished to be used singly in thicknesses ranging from .040" to .082" by two thousandths. Service shims are marked with their thickness in thousandths.

5. Remove support tool farthest from ring gear, insert shim for that side, and replace support tool.

6. Place other shim in position for insertion. While keeping a heavy hand pressure on shim, spread carrier pedestals just enough to start shim, using Spreader J-6185.

CAUTION: Do not spread pedestals any farther apart than is absolutely necessary to




Figure 6-35—Installing Differential Bearing Shims

push differential shim into position. If pedestals are sprung too far, they may take a permanent set. See figure 6-35. Leave support tool in position until after shim is started to keep case assembly from dropping out of line.

7. Remove left assembly tool and push shim into final position. Center it first with fingers through pedestal bore, then with a support tool. Remove spreader tool and pedestal wedges.

8. Lubricate support bushings with hypoid gear lubricant. Drive each differential bearing support into its pedestal until seated solidly in the bearing, using Support Tool J-6194-01. See figure 6-36. Tighten pedestal clamp bolts and nuts to 50 foot pounds.

9. Recheck backlash as in step 3. Final backlash must be .007"-.009" at point of minimum

lash, with not more than .003" variation around gear.



Figure 6-36—Installing Differential Bearing Supports

