

SECTION 6-B

REAR AXLE SERVICE PROCEDURES

CONTENTS OF SECTION 6-B

Paragraph	Subject	Page	Paragraph	Subject	Page
6-4	Removal and Installation of Rear Axle Assembly	6-6	6-6	Removal and Installation of Carrier Assembly	6-8
6-5	Removal and Installation of Axle Shaft, Wheel Bearing or Oil Seal	6-7	6-7	Disassembly of Carrier Assembly	6-8
			6-8	Assembly of Carrier Assembly	6-11

6-4 REMOVAL AND INSTALLATION OF REAR AXLE ASSEMBLY

It is not necessary to remove the rear axle assembly for any normal repairs. The axle shafts and the carrier assembly can easily be removed from the car, leaving the rear axle assembly in place. However, if the housing is damaged, the rear axle assembly can be removed and installed using the following procedure.

a. Removal of Rear Axle Assembly

1. Raise rear of car and support securely using car stands under both frame side rails.
2. Mark rear universal joint and pinion flange for proper reassembly. Disconnect rear universal joint by removing two U-bolts. (On 4700, mark flanged ball stud yoke and rear pinion flange for proper alignment at reassembly. Then disconnect rear CV joint from rear axle by removing four pinion flange bolts.) Push rear propeller shaft forward as far as possible, then wire it to the upper control arm frame bracket to support it out of the way.
3. Disconnect brake hose at support bracket. Cover hose and brake pipe openings to prevent entrance of dirt.
4. Disconnect parking brake

cables by removing adjusting nut and sheave. Unclip each cable at two places, disengage from guides, pull each cable free and lay-out forward from rear wheels.

5. Place a jack under center of rear axle housing and raise until shock absorbers are compressed slightly. Disconnect shock absorbers at lower ends.
6. Disconnect track bar at axle ends.
7. Disconnect upper control arm at axle end.
8. Lower jack slightly and disconnect lower control arms at axle end.
9. Lower jack from under axle housing and remove.
10. Roll rear axle assembly out from under car.

b. Installation of Rear Axle Assembly

1. With car resting securely on stands under frame, roll rear axle assembly into place.
2. Place a jack under center of axle housing and raise until aligned with lower control arms. Install lower control arm bolts and nuts. Torque nuts to 95 ft. lbs.
3. Raise jack slightly and connect upper control arm to axle housing. Torque nuts to 95 ft. lbs.
4. Connect track bar to axle housing. Torque nut to 120 ft. lbs.

5. Connect shock absorber lower ends. Torque nuts to 40 ft. lbs.

6. Install parking brake cables through clips and guides. Install sheave and adjusting nut.

7. Adjust parking brake according to procedure in paragraph 9-8.

8. Connect brake hose at support bracket and lock in place with yoke.

9. Bleed both rear wheel cylinders as described in paragraph 9-6.

10. Connect rear universal joint to pinion flange according to alignment marks. Compress bearings using a C-clamp so that bearing snap rings will engage pinion flange without gouging. See Figure 6-70. (On 4700, connect flanged ball stud yoke and rear pinion flange according to alignment marks.)

11. Torque U-bolt nuts to 13 ft. lbs. using an extension such as J-9113 (this corresponds to 15 ft. lbs. without an extension). See Figure 6-71. (On 4700, torque 4 pinion flange bolts to 75 ft. lbs.)

12. With car approximately level, fill rear axle housing to filler plug hole using specified gear lubricant. If axle housing or any rear suspension parts were replaced due to damage, rear universal joint angle must be checked and adjusted as required. See paragraph 6-19.

6-5 REMOVAL AND INSTALLATION OF AXLE SHAFT, WHEEL BEARING, OR OIL SEAL

a. Remove Axle Shaft Assembly

1. Place car stands solidly under rear axle housing so that wheels are clear of floor.
2. Remove rear wheel and brake drum. Both left and right side wheel bolts have right hand threads.
3. Remove nuts holding wheel bearing retainer plate to brake backing plate, leaving bolts in place to support backing plate.
4. Pull out axle shaft assembly using Puller J-6176 with a slide hammer. See Figure 6-5. **CAUTION:** While pulling axle shaft out through seal, support shaft carefully in center of seal to avoid cutting seal lip.
5. Replace two opposite retainer nuts finger tight to hold brake plate in position.

b. Remove and Install Rear Wheel Bearing

The rear wheel bearing and the bearing retaining ring both have a heavy press fit on the axle shaft. Because of this fit, they should be removed or installed separately.

1. Notch wheel bearing retaining ring in 3 or 4 places with a chisel. See Figure 6-6. Retaining ring will expand so that it can be slipped off. **CAUTION:** Axle shaft may be nicked if ring is cut completely through.
2. Press wheel bearing off, using Remover J-6525 either in a press or in a set-up using Ram and Yoke Assembly J-6180 and Adapter J-6258 as shown in Figure 6-7.
3. Install bearing retainer plate. Press new wheel bearing and re-




Figure 6-5—Removing Rear Axle Shaft




Figure 6-6—Removing Rear Wheel Bearing Retaining Ring

taining ring against shoulder on axle shaft using Installer J-9739 either in a press or in a set-up using Ram and Yoke Assembly J-6180 and Holder J-6407 shown in Figure 6-8. **CAUTION:** Bearing retainer plate must be on axle shaft before bearing is installed; retainer gasket can be installed after bearing.

c. Remove and Install Axle Shaft Oil Seal

The oil seal is located inboard of the wheel bearing with its O.D.

tight in the rear axle housing and its sealing lip contacting a ground surface of the axle shaft. See Figure 6-2. Before removing, install 2 nuts finger tight to retain backing plate to axle housing. This protects the brake lines.

1. To remove oil seal, insert Puller J-6199 just through seal and expand. Pull seal with a slide hammer. See Figure 6-9.
2. Before installing apply sealer to O.D. of new seal.
3. Position seal over Installer J-9740 and drive seal straight into housing until installer bottoms against wheel bearing shoulder. See Figure 6-10.

d. Remove and Install Rear Wheel Bolt

1. To remove and install a rear wheel bolt, axle shaft assembly must be out of car. Remove rear wheel bolt by pressing from axle flange.
2. Install new rear wheel bolt by pressing through axle flange. Check new bolt for looseness; if bolt can be moved at all with fingers, axle shaft must be replaced.

e. Install Axle Shaft Assembly

Rear axle shafts are not interchangeable between sides; the right shaft is longer than the left.

1. Apply a coat of wheel bearing grease in wheel bearing recess of housing. Install new outer retainer plate gasket over retainer bolts.
2. Apply gear lubricant to the bearing surface and splines at the inner end of the axle shaft. Apply a coat of wheel bearing grease on the seal surface of the shaft to approximately 6 inches inboard of the shaft. Install axle shaft




Figure 6-7—Removing Rear Wheel Bearing

through seal carefully to avoid cutting seal lip. Drive shaft into position. **NOTE: If the axle to be installed is a positive traction axle, ONLY POSITIVE TRACTION LUBRICANT SHOULD BE USED.**

3. Install retainer nuts and torque to 50 ft. lbs.

4. Install drum and wheel. Torque lug nuts to 70 ft. lbs.

6-6 REMOVAL AND INSTALLATION OF CARRIER ASSEMBLY

a. Remove Carrier Assembly

1. Raise rear of car and support securely under rear axle housing.

2. Mark rear universal joint and pinion flange for proper alignment at reassembly. Then disconnect rear universal joint by removing

two U-bolts. (On 4700, mark flanged ball stud yoke and rear pinion flange for proper alignment at reassembly. Then disconnect rear CV joint by removing 4 pinion flange bolts.) Push rear propeller shaft forward as far as possible, then wire it to the upper control arm frame bracket to support it out of the way.

3. Remove rear wheels and brake drums. Remove axle shaft assemblies as described in paragraph 6-5.

4. Remove carrier to axle housing nuts except two opposite nuts; back these two nuts out until they engage only a few threads.

5. Locate a drain pan under carrier flange, then move carrier forward to drain gear lubricant.

6. Remove carrier assembly

using a transmission jack, if available.

b. Install Carrier Assembly

1. Clean gasket surface of rear axle housing. Apply gasket cement and install new gasket. Make sure mounting surface of carrier is clean and free of any burrs or nicks.

2. Raise carrier assembly with a transmission jack, if available. Install carrier on axle housing. Torque nuts to 50 ft. lbs.

3. Install axle shaft assemblies as described in paragraph 6-5. Install rear drums and wheels. Torque lug nuts to 70 ft. lbs.

4. Connect rear universal joint to pinion flange according to alignment marks. Compress bearings using a C-clamp so that bearing snap rings will engage pinion flange without gouging. See Figure 6-70. (On Riviera, connect flanged ball stud yoke and rear pinion flange according to alignment marks.)

5. Torque U-bolt nuts to 13 ft. lbs. using an extension such as J-9113. See Figure 6-71. (On Riviera torque 4 pinion flange bolts to 75 ft. lbs.).

6. With car approximately level, fill rear axle housing to filler plug hole using specified lubricant.

6-7 DISASSEMBLY OF CARRIER ASSEMBLY

a. Removal and Disassembly of Ring Gear and Case Assembly

1. Place carrier assembly in suitable mounting fixture such as Fixture J-6177.

2. It is advisable to check the existing gear lash with a dial indicator as described in paragraph 6-8, e. This will indicate gear or bearing wear or an error in backlash or preload setting which will help in determining cause of axle noise. It will also enable used gears to be reinstalled at original




Figure 6-8—Installing Rear Wheel Bearing or Retaining Ring




Figure 6-9—Removing Axle Shaft Oil Seal




Figure 6-10—Installing Axle Shaft Oil Seal

lash setting to avoid changing gear tooth contact.

3. Remove differential bearing pedestal clamp bolts and open pedestals by tapping a wedge in each pedestal slot.

CAUTION: Do not use excessive force on wedges as pedestal bores may be permanently distorted.

4. Pull differential bearing supports with Puller J-9744-1 using the following procedure:

(a) Using a screwdriver, turn expanding screw in puller body, J-9744-5 in a counterclockwise direction to retract pins, then insert puller body into differential bearing support until reference line on tool is flush with end of support and punch mark is in general direction of hole in support. See Figure 6-11.




Figure 6-11—Installing Support Puller

(b) Expand pins a slight amount by turning expanding screw with screwdriver in a clockwise direction until a light drag on pins is felt, then move tool as required to engage pins with holes in support. Fully expand pins.

(c) Place bridge J-9744-2 over puller complete with draw bolt, thrust bearing, and washer as shown in Figure 6-12. With a suitable wrench tighten bolt to withdraw bearing support.




Figure 6-12—Removing Differential Bearing Support

5. Install Spreader J-6185 shown in Figure 6-34. Tighten spreader bolt just enough to free case assembly.

CAUTION: Do not spread pedestals any farther than necessary or they may be permanently sprung.

Lift case straight out until side bearings are half-way clear of pedestals. Then take hold at bearings with both hands to prevent bearings from dropping and lift case assembly out. Keep right and left bearings, shims, and supports in sets so that they may be reinstalled in the same positions. Remove spreader tool.

6. Mark ring gear and case, so they may be reassembled in same relative position. Remove ring gear from case. If ring gear is tight, tap it off using a soft hammer; do not pry between ring gear and case.

7. Drive differential pinion axle spring pin and pinion axle from case. Mark side gears, pinions, and washers so they may be reinstalled in same sides. Remove side gears, pinions, and washers.

8. If a differential bearing is to be replaced, pull bearing outer race from case with Remover J-6552 using the following procedure: (See Figures 6-13 and 6-14).

(a) Insert puller jaws with lips down under edge of outer race.




Figure 6-13—Proper Position of J-6552 Parts

(b) Carefully thread spreader screw into jaws, making sure that threads are not crossed. Leave spreader screw one full turn away from jaws.

(c) Place retainer ring and adapter over jaws, tapping them down while pulling up spreader screw so that ring fits snugly around jaws; then turn spreader screw tightly against jaws.

(d) Place sleeve over assembled tool. Insert draw bolt through washer, thrust bearing and sleeve. Then thread it into spreader screw and pull bearing outer race.




Figure 6-14—Installing Sleeve to Remove Bearing Outer Race

b. Removal of Pinion and Bearings

1. Check pinion preload as described in paragraph 6-8. If there is no preload reading, check for looseness of pinion assembly by shaking. Any noticeable looseness indicates worn or defective bearings, requiring replacement. If run long with very loose bearings, ring and pinion gears will be damaged and also need replacing.

2. Install Holder J-8614-01 on pinion flange using two 5/16-18 x 2 bolts with flat washers. (On 4700, install Holder J-8614-01 on pinion flange using Adapters J-21619.) Remove pinion nut using a 5/16 (3/4 drive) socket on Handle J-6246. Remove washer. See Figures 6-15 and 16.

NOTE: Because of differences in castings, it may be necessary to file out slightly slotted bolt holes in holder in order to accommodate J-21619 Adapters.

3. Pull flange from pinion using Puller J-8614-02 in Holder J-8614-01. (On 4700 use Puller J-8614-02 in Holder J-8614-01 with Adapters J-21619.) To install puller, back out puller




Figure 6-15—Removing Pinion Nut

screw, insert puller through holder, and rotate 1/8 turn. See Figures 6-17 and 18.

4. As pinion flange is removed, hold hand under pinion to catch it, as it may fall through. Remove "O" ring seal from pinion. If necessary, tap pinion out with a soft hammer, being careful to guide pinion with hand to avoid damage to bearing outer races.

5. If rear pinion bearing is to be replaced or pinion depth setting is to be changed, remove rear bearing from pinion shaft using Remover J-9746 and Holder J-6407 in a press, or in a set-up using Ram and Yoke Assembly J-6180 as shown in Figure 6-20.




Figure 6-16—Removing Pinion Nut - 4700




Figure 6-17—Removing Pinion Flange

6. Pry pinion oil seal from carrier, being careful not to damage front pinion bearing. If front pinion bearing is to be replaced, drive outer race from carrier using a drift in slots provided for this purpose.

7. If rear pinion bearing is to be replaced, drive outer race from carrier using a drift in slots provided for this purpose.

6-8 ASSEMBLY OF CARRIER ASSEMBLY

Before installation of any parts, examine the wearing surfaces of all parts for scoring or unusual wear. Make certain that the interior of the carrier housing is absolutely clean and dry. Also make certain that the parts to be assembled are absolutely clean




Figure 6-18—Removing Pinion Flange - 4700



Figure 6-19—Installing Pinion Bearing Remover

and that there are no burred edges. Lubricate all parts with the specified rear axle lubricant just before assembly.




Figure 6-20—Removing Rear Pinion Bearing




Figure 6-21—Nominal Pinion Setting Depth

NOTE: If the Buick is equipped with a Positive Traction Differential, only Positive Traction Lube should be used.

CAUTION: If the ring gear and pinion are changed, only factory hypoid lubricant should be used for filling because of its special anti-scoring properties. For this reason the proper lubricant is included in the carton with the replacement gears as received from the Buick warehouses. See paragraph 1-9.

a. Pinion Setting Marks and Setting Gauges

All Buick ring and pinion gear sets are selectively matched for best operating position and proper tooth contact. After matching, a serial number is etched on both the pinion and the ring gear to aid in keeping matched parts together. Parts having different serial numbers must never be used together.

Ring and pinion gear sets are matched in a special test machine which permits adjustment of pinion depth in ring gear until a point is reached where best operation and proper tooth contact under load is obtained. At this point, the setting of the pinion with reference to the centerline of the ring gear is indicated by the machine. This setting may vary slightly from the design or "nominal" setting due to allowable variation in machining the parts.

All production pinions are marked to indicate the variations in thousandths of an inch over or under the "nominal" setting. When a pinion is marked "+" (plus), it means that the pinion, when installed in the carrier, must be at a given distance from the centerline of the side pedestals plus the amount indicated on the pinion to position it at the nominal setting. When a pinion is

marked "-" (minus), it means that it must be located at the given distance minus the amount marked on the pinion to position it at the "nominal" setting. See Figure 6-21.

All service pinions are "nominal" or zero pinions and are therefore unmarked. These service pinions are set directly at a given distance from the centerline of the side pedestals.

Pinion Setting Gauge J-5647 with Adapter J-5647-35, Adapter J-5647-34, Pilot J-5647-37, Gauge Plate J-5647-36, and Stud and Nut Assembly J-8619-13 is used to set pinion depth. See Figure 6-22. It is not necessary to reassemble and install the pinion to determine the correct pinion depth shim since the pinion depth setting gauge arrangement provides in effect, a nominal or zero pinion as a gauging reference.

b. Checking Pinion Depth

NOTE: Before setting pinion depth, the pinion bearing races must be in position and the pinion oil seal must be removed. Install races following instructions in subparagraph c., Steps 1 and 2.

1. Be certain that all parts in pinion setting gauge are clean.
2. Install the disks on the indicator gauge. Install the small contact button on the stem of the dial indicator and mount the dial indicator on the indicator gauge.
3. Place the indicator gauge on the master gauge so that the spring-loaded center is engaged in the centering hole corresponding to the indicator pad "b". See Figure 6-22.
4. Center the indicator contact button on the specified contact pad and lock the indicator by tightening the thumb screw.
5. Hold gauge yoke down firmly with both disks contacting the horizontal and vertical pads on the




Figure 6-22—Pinion Setting Gauge J-5647 and Adapters

master gauge; set dial indicator at zero.

6. Lubricate front and rear pinion bearings which will be used in final reassembly, and position them in their respective races in the carrier. With bearings held in place in races, install Gauge Plate J-5647-36 on rear pinion bearing inner race, and place Pilot J-5647-37 on front pinion bearing with small diameter inside bearing race. Insert Stud J-8619-13 through pilot, and thread it into the gauge plate. See Figure 6-23.

7. Install nut on Stud J-8619-13. Hold stud stationary with wrench positioned on flats on end of stud; tighten nut until a reading of 20

inch pounds is obtained when rotating the gauge plate assembly with an inch pound torque wrench.

8. Be certain that differential support bores are free of burrs. Drive a wedge into each pedestal split and spread them just enough so that Adapters J-5647-35 and 34 can be inserted. Then place indicator gauge in carrier as follows: (See Figure 6-24.)

a. Remove disks from indicator gauge and hold it in position in the carrier with pins centered in the pedestal bores.

b. Slide long adapter through pedestal bore farthest from pinion and over gauge pin. Then slide

short adapter in place on other side.

c. Position the spring-loaded pin of the indicator gauge in the centering hole of Gauge Plate J-5647-36, and position the contact button of dial indicator to bear against machined surface of Gauge Plate. See Figure 6-24.

9. Press gauge yoke down firmly. Record dial indicator reading, and then remove indicator gauge checking "zero setting" on master gauge to be certain this setting was not disturbed by handling. If "zero setting" is still correct, remove gauging set-up and both bearings from carrier.

10. Examine ring gear and pinion for nicks, burrs, or scoring. Any of these conditions will require replacement of the set.

11. The correct pinion shim to be used during pinion reassembly should be selected as follows:

(a) If a production pinion is being reused and pinion is marked "+" (plus), the correct shim will have a thickness equal to the indicator gauge reading found in Step 9 less the amount specified on the pinion.

(b) If a production pinion is being reused and the pinion is marked "-" (minus), the correct shim will have a thickness equal to the indicator gauge reading found in Step 9 plus the amount specified on the pinion.

(c) If a service pinion is being used (no marking), the correct shim will have a thickness equal to the indicator gauge reading found in Step 9.

c. Installation of Pinion Bearings and Pinion

1. Drive front pinion bearing outer race against shoulder on carrier using Replacer J-8611 with driver handle. See Figure 6-25.




Figure 6-23—Installing Gauge Plate in Carrier

2. Drive rear pinion bearing outer race against shoulder in carrier using Replacer J-9745 with driver handle. See Figure 6-26.

3. Place correct shim (as determined in subpar. b) against head of pinion and install rear pinion bearing using Replacer J-6377 and Holder J-6407 with Ring J-6407-2 in a press or as shown in Figure 3-27.

4. For a starting pinion bearing

preload adjustment, use original pinion preload spacers. Place these spacers on pinion and hold

pinion assembly in position in carrier. Oil front pinion bearing and place in position on pinion. Hold pinion in place and drive front pinion bearing over pinion until fully seated using Installer J-21005. See Figure 6-28.

5. Install new "O" ring seal on pinion. Coat O.D. of new pinion seal with sealing compound and




Figure 6-24—Checking Pinion Setting




Figure 6-25—Installing Front Pinion Bearing Outer Race




Figure 6-26—Installing Rear Pinion Bearing Outer Race




Figure 6-27—Installing Rear Pinion Bearing

install seal using Installer J-21005. See Figure 6-29.

6. Fill space between lips of oil seal with wheel bearing grease and apply a thin coat of the same grease on seal surface of pinion flange. Install pinion flange on pinion by tapping with a soft hammer until a few pinion threads project through the flange. Install pinion washer and nut. Hold pinion flange with Holder J-8614-01. (On 4700, hold pinion flange with Holder J-8614-01 and Adapters J-21619.) Torque pinion nut to 80 ft. lbs. using Torque Wrench J-1313 on outer end of Handle J-6246. (This amounts to an actual 250 ft. lbs. torque at nut.) See Figure 6-30.




Figure 6-28—Installing Front Pinion Bearing




Figure 6-29—Installing Pinion Seal

7. Rotate pinion three or four times to seat bearings. Turn pinion slowly with an inch pound torque wrench; bearing preload including drag of new seal should be 15 to 35 inch pounds. See Figure 6-31.

If preload torque is low, reduce total pinion spacer thickness .001" for each added 10 in. lbs. preload needed; if preload is high, increase total pinion spacer thickness .001" for each 10 in. lbs. preload to be subtracted. These spacers are furnished to be used




Figure 6-30—Tightening Pinion Nut




Figure 6-31—Checking Pinion Bearing Preload

in pairs so that possible thicknesses range from .400" to .470" by thousandths. Service spacers are marked with their thickness in thousandths.

d. Assembly of Differential Case, Gears and Bearings

1. Drive differential bearing outer races into case, using Replacer J-9742. See Figure 6-32.
2. Install side gears, pinions, and washers in case. If same parts are used, replace in original sides. Install pinion axle. Drive spring pin through hole in pinion axle until flush with case.




Figure 6-32—Installing Differential Bearing Outer Race

3. Check matching numbers on ring gear and pinion to make sure the two parts have not been mixed with another gear set.

4. After making sure that mating surfaces of case and ring gear are clean and free of burrs, bolt ring gear to case using three Studs J-6251 to align parts. See Figure 6-33. If same ring gear and case are used, line up marks so they are assembled in same relative positions.

Do not use lock washers or any substitute bolts.

5. First tighten bolts alternately on opposite sides of the case to 35 ft. lbs. torque, then tighten in the same manner to 70 ft. lbs.

e. Installation and Adjustment of Ring and Case Assembly

1. Before installation of ring gear and case assembly make sure that differential bearing and bearing support surfaces in carrier pedestals are clean and free of burrs. Remove any burrs which might prevent bearings or bearing supports from seating properly.

2. Place case assembly and differential bearings in position in carrier. If same bearings are used, install in original positions. Insert Support Tools J-9743 through the pedestal bores into the bearing inner races. Press



Figure 6-33—Installing Ring Gear on Differential Case

tools toward each other to seat them, using hand pressure. If support tools are loose, install pedestal clamp bolts and nuts and tighten lightly until support tools can just be moved by twisting them. If support tools are too tight, loosen them as necessary by slightly wedging pedestals open with chisels. See Figure 6-34.

3. Rotate the differential assembly three or four times to seat bearing rollers, then manually adjust the whole assembly sideways to get .008" gear backlash. The assembly tools may be tapped lightly with a hammer to seat them. Check backlash as follows:

(a) Mount dial indicator as shown in Figure 6-35. Use a small button on indicator stem so that contact can be made near heel end of tooth. Set dial indicator so that indicator stem is as nearly as possible in line with gear rotation and perpendicular to the tooth surface. If stem bears against edge of tooth, or stem is at considerable angle to the line of gear rotation, or at a considerable angle to face of the tooth, a false

indication of backlash will be obtained.

(b) Check gear lash at three or four points around ring gear. Lash must not vary more than .003" around ring gear. If lash varies over .003" check for burrs, uneven bolting conditions, or distorted case flange, and make necessary corrections.

CAUTION: Any gear lash check must be made with pinion locked to carrier to be sure it cannot turn.

(c) Adjust gear lash at the point of minimum lash to .008" for all new gears. If original gear set is being reinstalled, the original lash should be maintained.

4. Measure with a shim between each bearing and its pedestal. Do not remove support tools for measuring. Select shim that measures .002" thicker than largest shim that can be inserted for each side; this should preload each differential bearing .002". These shims are furnished to be used singly in thicknesses ranging from .040" to .082" by two




Figure 6-34—Positioning Differential for Correct Backlash




Figure 6-35—Checking Backlash with Dial Indicator

thousandths. Service shims are marked with their thickness in thousandths.

5. Remove support tool farthest from ring gear, insert shim for that side, and replace support tool.

6. Place other shim in position for insertion. While keeping a heavy hand pressure on shim, spread carrier pedestals just enough to start shim, using Spreader J-6185.

CAUTION: Do not spread pedestals any farther apart than is absolutely necessary to push differential shim into position. If pedestals are sprung too far, they may take a permanent set. See Figure 6-36. Leave support tool in position until after shim is started to keep case assembly from dropping out of line.

7. Remove left assembly tool and push shim into final position. Center it first with fingers through pedestal bore, then with a support tool. Remove spreader tool and pedestal wedges.

8. Lubricate support bushings with hypoid gear lubricant. Drive each differential bearing support into its pedestal until seated solidly in the bearing, using Sup-




Figure 6-36—Installing Differential Bearing Shims



Figure 6-37—Installing Differential Bearing Supports

port Tool J-9743. See Figure 6-37. Tighten pedestal clamp bolts and nuts to 50 ft. lbs.

9. Recheck backlash as in Step 3. Final backlash must be .007"-.009" at point of minimum lash, with not more than .003" variation around gear.

10. Add lubricant and fill to level of filler plug opening to 1/4" below.

CAUTION: If the ring gear and pinion are changed only factory hypoid lubricant should be used for filling because of its special anti-scoring properties. For this reason the proper lubricant is included in the carton with the replacement gears as received from the Buick warehouses. See paragraph 1-9.