

SECTION B

350 AND 455 CUBIC INCH V-8 ENGINES

CONTENTS

Division	Subject	Paragraph
I	SPECIFICATIONS AND ADJUSTMENTS:	
	Bolt Torque Specifications	60-1
	General Specifications	60-2
	Engine Dimensions and Fits	60-3
II	DESCRIPTION AND OPERATION:	
	Engine Construction	60-4
III	SERVICE PROCEDURES:	
	Exhaust and Intake Manifold, Cylinder Heads, Valve Train and Lifters	61-1
	Connecting Rod Bearings	61-2
	Crankshaft Bearings and Seals	61-3
	Pistons, Rings, and Connecting Rods	61-4
	Camshaft and Timing Chain	61-5
	Lubrication System and Oil Pump	62-1
	Cooling System and Water Pump	63-1
Engine Mounting, Flywheel and Engine Balancing	63-2	
IV	TROUBLE DIAGNOSIS:	
	Excessive Oil Consumption	63-9
	Noisy Valves and Lifters	63-10
	Cooling System Trouble	63-11

DIVISION I SPECIFICATIONS AND ADJUSTMENTS

60-1 BOLT TORQUE SPECIFICATIONS

Use a reliable torque wrench to obtain the figures listed below. This will prevent straining or distorting the parts as well as preventing thread damage. These specifications are for clean and lightly lubricated threads only. Dry or dirty threads produce friction which prevents accurate measurements of the actual torque. It is important that these specifications be strictly observed. Overtightening can damage threads. This will prevent attainment of the proper torque and will require replacement of the damaged part.

60-1 BOLT TORQUE SPECIFICATIONS

Area	Torque Lb. Ft.
Spark Plugs	15
Crankshaft Bearing Caps to Cylinder Block	350 (95) 455 (110)
Connecting Rods	350 (35) 455 (45)
Cylinder Head to Cylinder Block	350 (75) 455 (100)
Harmonic Balancer to Crankshaft	350 (120 Minimum) 475 (200 Minimum)
Fan Driving Pulley to Harmonic Balancer	23
Flywheel to Crankshaft (Auto. & Manual)	350 (60) 455 (58)
Oil Pan to Cylinder Block	14
Oil Pan Drain Plug	30
Oil Pump Cover to Timing Chain Cover	10
Oil Pump Pressure Regulator Retainer	35
Oil Screen Housing to Cylinder Block	8
Oil Pan Baffle to Cylinder Block	350 (11) 455 (13)
Oil Gallery Plugs	25
Oil Pressure Switch to Cylinder Block	23
Filter Assembly to Pump Cover	13
Timing Chain Cover to Block	29
Water Pump Cover to Timing Chain Cover	7
Fan Driven Pulley	20
Thermostat Housing to Intake Manifold	20
Automatic Choke Cover to Intake Manifold	8
Intake Manifold to Cylinder Head	55
Exhaust Manifold to Cylinder Head	18
Carburetor to Intake Manifold	13
Fuel Pump to Cylinder Block	20
Motor Mount to Cylinder Block	63
Fuel Pump Eccentric and Timing Chain Sprocket to Camshaft	350 (48) 455 (22)
Rocker Arm Cover to Cylinder Head	4
Rocker Arm Shaft to Cylinder Head	25
Delcotron Bracket to Cylinder Head	35
Delcotron Adjusting Bracket to Cylinder Head	22
Delcotron Mounting Bracket Thru Delcotron to Cylinder Head at Pivot Location	35
Starting Motor to Block	35
Starting Motor Brace to Block	11
Starting Motor Brace to Starting Motor	11
Distributor Hold-down Clamp	13
Automatic Lower Flywheel Housing Plate	4
Flywheel Housing to Cylinder Block	35

60B-2

60-2 GENERAL SPECIFICATIONS

a. General

	350-2 SO	350-4 SB	350-4 SP
Code Number Prefix			
Engine Type		90° V-8	
Bore and Stroke	3.800 x 3.850	3.800 x 3.850	3.800 x 3.850
Piston Displacement	350 cu. in.	350 cu. in.	350 cu. in.
Carburetor Type	2 BBL.	4 BBL.	4 BBL.
Compression Ratio	9.0:1	9.0:1	10.25:1
Gasoline Requirements	Regular	Regular	Premium
Brake Horsepower @ RPM	230/4400	285/4600	315/4800
Maximum Torque @ RPM	350/2400	375/3200	410/3200
Taxable Horsepower	46.2	46.2	46.2
Octane Requirement – Motor	85	85	90
Octane Requirement – Research	93	93	99
Cylinder Numbers – Front to Rear			
Left Bank		1-3-5-7	
Cylinder Numbers – Front to Rear			
Right Bank		2-4-6-8	
Firing Order		1-8-4-3-6-5-7-2	

Code Number Prefix	455-4	Stage I	
Engine Type	SR	445-4	455-4
Bore and Stroke	4.3125 x 3.900	SS	SF
Piston Displacement	455 cu. in.	90° V-8	
Carburetor Type	4 BBL	4.3125 x 3.900	4.3125 x 3.900
Compression Ratio	10.0:1	455 cu. in.	455 cu. in.
Gasoline Requirements	Premium	4 BBL	4 BBL
Brake Horsepower @ RPM	350/4600	10.50	10.0:1
Maximum Torque @ RPM	510/2600	Premium	Premium
Taxable Horsepower	59.5	360/4600	370/4600
Octane Requirement – Motor	90	510/2600	510/2800
Octane Requirement – Research	99	59.5	59.5
Cylinder Numbers – Front to Rear		90	90
Left Bank		99	99
Cylinder Numbers – Front to Rear			
Right Bank		1-3-5-7	
Firing Order		2-4-6-8	
		1-8-4-4-6-5-7-2	

60-2 GENERAL SPECIFICATIONS (Cont'd.)**b. Piston and Pin Specifications****Piston**

Material	Cast Aluminum Alloy
Type	Divorced Skirt
Finish	Cam Ground

Piston Pins

Material	Extruded SAE-1018
Type	Pressed In Rod

c. Connecting Rods

Material	(350) Pearlite Malleable Iron Forged — SAE-1053 Steel
Rod Bearing	Removable Steel Backed M/400 Aluminum

d. Ring Specifications

#1 Compression	Cast Iron Molybdenum Coated
#2 Compression	Cast Iron-Lubrited
Oil Control	(350) Uncoated Steel (455) SAE-1070 Steel-Chrome Plated
Oil Ring Expander	(350) Hump Type (455) Abutment Type
Ring Locations	Above Pin

e. Crankshaft Specifications

Material	Nodular Iron
Bearings	5 Replaceable Steel Backed
Bearing Material	#1, #2, #3, and #4 — M/400 #5 — M/100A Durex
Bearing Taking End Thrust	#3

f. Camshaft Specifications

Material	Cast Alloy Iron
Bearings	Steel Backed Babbitt
Number of Bearings	5
Drive	Chain
Number of Links	(350) 54 (455) 48
Crankshaft Sprocket	Sintered Iron
Camshaft Sprocket	Nylon Coated Aluminum

g. Valve Specifications**350 Cu. In.**

Intake Valve Material	SAE 1041 Steel — Aluminized Face and Chrome Flashed Stem
Exhaust Valve Material	21-2 Aluminized Face and Chrome Flashed Stem
Valve Lifter Mechanism	Hydraulic
Valve Spring	Single Helical

400 & 430 Cu. In.

Intake Valve Material	Aluminized Face and Chrome Flash Stem SAE 1041 Steel
Exhaust Valve Material	Aluminized Face and Chrome Flash Stem GN-N82152 (21-4N)
Valve Lifter Mechanism	Hydraulic
Valve Spring	Single Spring With Damper

h. Lubrication System Specifications**Type of Lubrication**

Main Bearings	Pressure
Connecting Rods	Pressure
Piston Pins	Splash
Camshaft Bearing	Pressure
Timing Chain	(350) Splash and Nozzle (455) Drip From Front Cam Bearing
Cylinder Walls	Splash and Nozzle
Oil Pump Type	Gear Driven
Normal Oil Pressure	(350) 37 lbs. @ 2400 RPM (455) 40 lbs. @ 2400 RPM
Oil Pressure Sending Unit	Electrical
Oil Intake	Stationary
Oil Filter System	Full Flow
Filter Type	Throw-Away Element and Can
Crankcase Capacity — With Filter	5 Quarts
Less Filter	4 Quarts

60-2 GENERAL SPECIFICATIONS (Cont'd.)

i. Cooling System Specifications

System Type	Pressure
Radiator Cap Relief Pressure	15 psi
Thermostat	Choke Type Opening at 190°
Water Pump	
Type	Centrifugal
GPM (α RPM)	(350) 10 @ 1000 (455) 15 @ 1000
Drive	V-Belt
Bearings	Double Row
By-Pass Recirculation Type	(350) External (455) Internal

Cooling System Capacities	(350 Cu. In. "A")	(350 Cu. In. LeSabre)	(455 Cu. In.)
With Heater	16.5 qts.	16.2 qts.	19.7 qts.
With Air Conditioning	15.5 qts.	16.6 qts.	20.0 qts.

Fan Diameter and Number of Blades

350 Less AC	18" x 4	Wildcat and Electra 225 Less AC	18" x 4
350 With AC	18" x 7	With AC	20" x 5
G.S. 455 Less AC	18" x 4	Riviera Less AC	18" x 7
G.S. 455 With AC	18" x 7	With AC	20" x 5

Fan Drive	Water Pump Shaft
Less AC	Torque and Temperature Sensitive Clutch
With AC	

60-3 ENGINE DIMENSIONS AND FITS

a. General

	350 Cu. In.	455 Cu. In.
Piston Clearance Limits*		
Top Land027 - .036	.0343 - .0423
Skirt Top0008 - .0014	.0007 - .0013
Skirt Bottom0013 - .0029	.0017 - .0033
Ring Groove Depth		
#1 — Compression Ring1930 - .1855	.2090 - .2165
#2 — Compression Ring1955 - .1880	.2215 - .2190
#3 — Oil Ring1955 - .1880	.1815 - .1890
Ring Width		
#1 — Compression Ring077 - .078	.077 - .078
#2 — Compression Ring077 - .078	.077 - .078
#3 — Oil Ring181 - .187	.023 - .025
Ring Gap		
#1 — Compression Ring010 - .020	.013 - .023
#2 — Compression Ring010 - .020	.013 - .023
#3 — Oil Ring015 - .035	.015 - .055
Piston Pin Length	3.060	3.520
Diameter of Pin9394 - .9397	.9994 - .9997
Clearance		
In Piston	(Selected) .0001 - .0004	.0001 - .0004
In Rod	(Selected Press) .00075- .00125	.00075-.00125
	.040	.060
Direction & Amount Offset in Piston	Major Thrust Side	Major Thrust Side

*All Measurements in Inches Unless Otherwise Specified.

b. Connecting Rod Specifications

	350 Cu. In.	455 Cu. In.
Bearing Length737	.821
Bearing Clearance (Limits)0002 - .0023	.0002 - .0023
End Play — Total for Both Rods006 - .014	.005 - .012

60-3 ENGINE DIMENSIONS AND FITS (Cont'd.)**c. Crankshaft Specifications**

	350 Cu. In.	455 Cu. In.
End Play at Thrust Bearing	.003 — .009	.003 — .009
Main Bearing Journal Diameter	2.9995	3.2500
Crankpin Journal Diameter	2.0000	2.249 — 2.250
Main Bearing Overall Length		
#1	.864	.865
#2	.864	.865
#3	1.057	1.057
#4	.864	.865
#5	.864	1.143
Main Bearing to Journal Clearance	.0004 — .0015	.0007 — .0018

d. Camshaft Specifications**Bearing Journal Diameter**

#1	1.785 — 1.786
#2	1.785 — 1.786
#3	1.785 — 1.786
#4	1.785 — 1.786
#5	1.785 — 1.786

Journal Clearance in Bearings	.005 — .0025 (#1)
e. Valve System Specifications	.005 — .0035 (#2, #3, #4, & #5)

350 Cu. In.

Rocker Arm Ratio	1.55 to 1
Rocker Arm Clearance on Shaft	.0022 — .0037
Valve Lifter Diameter	.8422 — .8427
Valve Lifter Clearance in Crankcase	.0008 — .0023
Valve Lifter Leakdown Rate	12 to 60 Sec. in Test Fixture

Intake Valve

Overall Length	5.024 — 4.994
Head Diameter	1.880 — 1.870
Seat Angle	45°
Stem Diameter	.3725 ± .0005
Clearance in Guide	.0015 — .0025 & .0003 Max. Taper

Valve Spring

Valve Closed — Pounds @ Length	75 ± 5 @ 1.727
Valve Open — Pounds @ Length	180 ± 7 @ 1.340

Exhaust Valve

Overall Length	5.044 — 5.014
Head Diameter	1.505 — 1.495
Seat Angle	45°
Stem Diameter	.3723 Min. and .3730 Max.
Clearance in Guide	.0015 — .0032 & .0002 Max. Taper

Valve Spring

Valve Closed — Pounds @ Length	75 ± 5 @ 1.727
Valve Open — Pounds @ Length	180 ± 7 @ 1.340

400 & 430 Cu. In.

Rocker Arm Ratio	1.54 to 1
Rocker Arm Clearance on Shaft	.0015 — .0030
Valve Lifter Diameter	.8427 — .8422
Valve Lifter Clearance in Crankcase	.0008 — .0023
Valve Lifter Leakdown Rate	12 to 60 Sec. in Test Fixture

Intake Valve

Head Diameter	2.005 — 1.995
Seat Angle	45°
Stem Diameter	.3725 ± .0005 — Max. Allowable Taper to be .0003 with Smallest Dia. @ Valve Head End
Clearance in Guide	.0015 — .0035 & .0003 Max. Taper

Valve Spring

Valve Closed — Pounds @ Length	72 ± 5 @ 1.890
Valve Open — Pounds @ Length	177 ± 7 @ 1.450

Exhaust Valve

Head Diameter	1.625
Seat Angle	45°
Stem Diameter	.3723 Min. and .3730 Max.
Clearance in Guide	.0015 — .0032 & .0002 Max. Taper

Valve Spring

Valve Closed — Pounds @ Length	72 ± 5 @ 1.890
Valve Open — Pounds @ Length	177 ± 7 @ 1.450




Figure 60-200 - 350 Cu. In. V-8 Engine Cross Section (Front View)





Figure 60-201 - 350 Cu. In. V-8 Engine Cross Section (Side View)






Figure 60:203 · 455 Cu. In. (Side Section View)

DIVISION II DESCRIPTION AND OPERATION

60-4 Engine Construction

a. Engine Mounting

For details of engine and transmission mounts refer to Figures 60-261, 60-262, 60-263 and 60-264.

b. Engine Construction

The 350, 455 cu. in. engines, with the exception of cylinder bore size and stroke are very similar. Because of the similarity between the two engines, the service procedures, unless otherwise specified will be combined.

The left bank of cylinders (as viewed from rear) is set slightly forward of the right bank so that connecting rods of opposite sides can be connected to the same crankpin. Starting at the front of the engine, cylinders in the *left* bank are numbered 1-3-5-7 and cylinders in the *right* bank are numbered 2-4-6-8.

The *crankshaft*, cast nodular iron, is supported in the crankcase by five bearings which are identical except number three, which takes end thrust and the rear main which has a different width and material. See Figure 60-205.

The *crankshaft* is counterbalanced by weights cast integral with the crankshaft. Additional counterbalancing is obtained by an offset flywheel flange.

The tin plated *aluminum alloy pistons* have full skirts and are cam ground. Two transverse slots in the oil ring grooves extend through the piston wall and permits drain back of oil collected by the oil ring.

The *camshaft* is supported in the crankcase by five steel-backed babbit-lined bearings. It is driven from the crankshaft by sprockets and chain.

The *cylinder heads* are cast iron and incorporate cast-in valve stem guides and rocker arm shaft pedestals. Right and left cylinder heads are identical and interchangeable, al-




Figure 60-205 - Engine Crankshaft and Bearings

though in service, it is good practice to reinstall the cylinder heads on the side from which they are removed.

The *intake manifold* on the V-8 engine utilizes a low restriction, dual intake manifold. It is bolted to the inner edges of both cylinder heads so that it connects with all inlet ports. Since the intake manifold is cast iron, as is the carburetor throttle body, the manifold incorporates a special exhaust heat passage to warm the throttle body. Fuel-air mixture distribution to each intake port is shown in Figure 60-206.

The *manifold heat control* valve, located on the right exhaust manifold, of 350 cu.in. engines regulates the amount of exhaust gas passing through the intake manifold. A bi-metal spring attached to the control valve shaft tends to gradually open and reduce the amount of exhaust gas warming the throttle body and




Figure 60-206 - Intake Manifold Distribution (350 Shown)

intake manifold by slowly opening the valve. When engine operating temperature is reached a small quantity of exhaust gas continues to warm the throttle body.

Intake manifold heat is necessary when operating the engine in cold

temperatures. Better fuel mixture vaporization, with resulting improved combustion is achieved. The 455 cu. in. engine does not have a heat control valve.

Each *valve* has a spring of ample capacity to insure positive seating throughout the operating speed range. Intake valve heads are 1-7/8" (350 cu.in.) and 2" (455 cu.in.) in diameter and exhaust valves are 1-1/2" (350 cu.in.) and 1-5/8" (455 cu.in.) in diameter. In the 455 STAGE I version, the intake valves are 2-1/8" in diameter; the exhaust valves are 1-3/4" diameter.

The *valve rocker arms* for each bank of cylinders are mounted on a tubular steel shaft supported on the cylinder head by four pedestals. The rocker arms are die cast aluminum with inserts at the push rod sockets and the valve stem contact face. The rocker arm sockets are offset to accommodate the different planes of movement of the valve and the pushrods which pass through the cylinder head to one side of the valves. See figure 60-207.

Hydraulic valve lifters and tubular push rods are used to operate overhead rocker arms and valves of both banks of cylinders from a single camshaft. This system requires no lash adjustment at time of assembly or in service. Construction and operation of hydraulic valve lifters are described below.

In addition to its normal function of a cam follower, each hydraulic valve lifter also serves as an automatic adjuster which maintains zero lash in the valve train under all operating conditions. By eliminating all lash in the valve train and also providing a cushion of oil to absorb operating shocks, the hydraulic valve lifter promotes quiet valve operation. It also eliminates the need for periodic valve adjustment to compensate for wear of parts.

As shown in Figure 60-208 all parts of a hydraulic lifter are housed in the lifter body, which is the cam follower. The body and the plunger are ground to very close limits, then a plunger is selectively fitted to each body to assure free movement with

very little clearance. The push rod seat is free to move with the plunger in the body and, as its name implies, it provides a spherical seat to support the lower end of the push rod.




Figure 60-208 Hydraulic Valve Lifter

The plunger and seat are pressed toward the upper end of the lifter body by a coil spring which also holds a check ball retainer against the lower end of the plunger. When lifter is out of engine, a spring wire retainer holds all parts in the body. The ball retainer holds a spring loaded check ball in position over the lower end of a feed hole in the plunger.

When the valve lifter is installed in the engine, the push rod holds the seat and plunger downward and clear of the plunger retainer at all times. The plunger spring then presses the lifter body down against the camshaft and presses the plunger and seat up against the push rod with an eight pound load; this is enough to take up all lash clearances between parts in the valve train without affecting positive seating of the valve.

Oil is fed to all lifters through




Figure 60-207 Engine Valve Mechanism (455 Shown)

galleries in the crankcase. Oil enters each lifter through grooves and oil holes in the lifter body and plunger, flows down into the chamber below the plunger through the feed hole and around the check ball. The first few cycles of operation after the engine is started forces out all air and completely fills the plunger and lower chamber of each lifter with oil.

At the start of a cycle of valve operation, the lifter body rests on the camshaft base circle. The plunger spring absorbs all lash clearances of the valve train.

As the rotating camshaft starts raising the valve lifter body, oil in the lower chamber and the check ball spring firmly seat the check ball against the plunger to prevent appreciable loss of oil from the lower chamber. The lifting force against the body is then transmitted through the entrapped oil to the check ball and plunger so that the plunger and push rod seat move upward with the body to operate the linkage which opens the engine valve.

As the camshaft rotates further to close the engine valve, the valve spring forces the valve train and lifter to follow the cam down. When the engine valve seats, the valve train parts and lifter plunger stop but the plunger spring forces the body to follow the cam downward .002" to .003" until it again rests on the camshaft base circle. Oil pressure against the check ball from the lower chamber ceases when the plunger stops and allows passage of oil past the check ball into the lower chamber to replace the slight amount of oil lost by "leak-down".

During the valve opening and closing operation a very slight amount of oil escapes through the clearance between plunger and body and returns to the crankcase. This slight loss of oil (called "leak-down") is beneficial in providing a gradual change of oil in the lifter, since fresh

oil enters the lower chamber when pressure is relieved on the check ball at the end of each cycle of operation.

When engine temperature increases and the valve train components expand, the plunger must move to a slightly lower position in the lifter body to assure full closing of the engine valve. When engine temperature decreases and the valve train components contract, the plunger must move to a slightly high position in body to prevent lash clearance in the valve train. In either case, the capacity of the lower chamber changes and the volume of oil present is automatically controlled by passage of oil through the plunger feed hole.

DIVISION III

SERVICE PROCEDURES

6I-1 INTAKE MANIFOLD, CYLINDER HEAD, VALVE TRAIN AND LIFTERS AND ENGINE OIL PAN.

a. Intake Manifold Removal

1. Disconnect battery.
2. Drain coolant from radiator and cylinder block.
3. Remove air cleaner.
 - a. Disconnect breather tube at air cleaner.
 - b. Disconnect heated air pipe at top end of pipe.
 - c. Disconnect air cleaner sensor hose at tee (auto trans only)
 - d. Disconnect hose at elbow from carburetor to air cleaner (Manual Trans Only.)

4. Remove air conditioning mounting bracket bolt (if equipped). Loosen bracket to compressor bolt

and slide bracket outboard.

5. Disconnect water temperature and metal temperature indicator wire from switch.
6. Disconnect throttle linkage at carburetor.
7. Disconnect fuel line at carburetor inlet.
8. Remove manifold attaching bolts and manifold.

b. Intake Manifold Installation

1. Place new intake manifold gasket and rubber manifold seals in position at front and rear rails of cylinder block. Be sure pointed end of seal fits snugly against block and head.

NOTE: Before installing intake manifold seals apply Silastic Rubber or equivalent to ends of seals. See Figure 60-209.



Figure 60-209 Intake Manifold Seal Installation

2. Install one piece manifold gasket and carefully set intake manifold on the engine block dowel pin.
3. Install manifold to cylinder head bolts.

NOTE: New intake manifold gasket and seals must be obtained whenever a manifold is removed.

When installing a manifold, start with the 1 and 2 bolts. See Figure 60-210. Gradually tighten both bolts until snug. Then continue with the rest of the bolts in the sequence shown in Figure 60-210. Torque bolts to 55 lb. ft.




Figure 60-210 Intake Manifold Bolt Tightening Sequence

4. Connect parts removed in Steps 3 thru 9 in subpar. a.

5. Connect battery.

6. Close drain plug and fill radiator to proper level.

C. CYLINDER HEAD REMOVAL

1. Remove intake manifold as outlined in subpar. a.

2. When removing RIGHT cylinder head:

a. Loosen and remove belt (s).

b. Remove wires from Delcotron.

c. If equipped with air conditioning compressor, remove compressor from mounting bracket and position it out of the way with hoses

connected, then remove Delcotron with mounting bracket.

3. When removing LEFT cylinder head:

(a) Remove oil gage rod, or

(b) Remove power steering gear pump with mounting bracket if present, and move it out of the way with hoses attached.

4. Disconnect wires from spark plugs, and remove the spark plug wire clips from the rocker arm cover studs.

5. Remove exhaust pipe to manifold bolts.

6. Disconnect exhaust manifold from head being removed.

7. With air hose and cloths, clean dirt off cylinder head and adjacent area to avoid getting dirt into engine. It is extremely important to avoid getting dirt into the hydraulic valve lifters.

8. Remove rocker arm cover and rocker arm and shaft assembly from cylinder head. Lift out push rods.

NOTE: If lifters are to be serviced, remove them at this time. Otherwise, protect lifters and camshaft from dirt by covering area with a clean cloth.

NOTE: Whenever lifters or push rods are removed, place in a wooden block with numbered holes or similar device to keep them identified as to position in engine.

9. Slightly loosen all cylinder head bolts, then remove bolts and lift off the cylinder head. Remove gasket.

10. With cylinder head on bench, remove all spark plugs for cleaning and to avoid damage during work on the head.

d. Cylinder Head Installation

1. Thoroughly clean off engine block gasket surface and be certain no foreign material has fallen in the cylinder bores, bolt holes, or in the valve lifter area. It is good practice to clean out bolt holes with an air hose.

2. Install new head gasket on cylinder block. Dowels in the block will hold the gasket in place. Always handle gaskets carefully to avoid kinking or damage to the surface treatment of the gasket. The gaskets are coated with a special lacquer to provide a good seal, once the parts have warmed up.

3. Clean gasket surface of cylinder head and carefully set in place on the engine block dowel pins.

4. Clean and lubricate the head bolts with "Perfect Seal" or equivalent sealing compound.

NOTE: Damage to the cylinder block threads can result if bolts are not lubricated with 'Perfect Seal' or equivalent prior to installation or if bolts are tightened excessively. Use an accurate torque wrench when installing head bolts. Uneven tightening of




Figure 60-211 Cylinder Head Bolt Tighten Sequence (350 Shown)

the cylinder head bolts can distort the cylinder bores, causing compression loss and excessive oil consumption.

5. Install head bolts. Tighten the bolts a little at a time about three times around in the sequence shown in Figure 60-211. Give bolts a final torque in the same sequence. Torque to 73 lb.ft. (350 Cu In.) and 100 lb. ft. (455 Cu. In.).

6. Assemble exhaust manifolds to heads. See Figure 60-212. Torque bolts to 18 lb. ft.

7. Wipe rocker arm shaft and bosses on cylinder head with a clean cloth.

8. Install push rods.

9. Tilt the rocker arm toward the push rod and locate the top of each push rod in its rocker arm seat.

10. Draw down the rocker arm and shaft assembly by tightening the bracket bolts a little at a time. Use a reliable torque wrench to torque the bracket bolts to 25 lb. ft. Do not overtighten.

11. Install rocker arm cover and new gasket. Torque bolts to 4 lb. ft.

12. Place spark plug wires in position on rocker arm cover studs and connect spark plug wires.

13. Install intake manifold as outlined in subpar. b.

14. Replace components removed in Steps 2 or 3 (subparagraph c) and tighten belt(s). See Figure 60-258 for correct belt tension.

15. After installation is completed and engine has been warmed up to operating temperature, recheck cylinder head bolt torque. Reinstall rocker arm cover and gasket and torque bolts to 4 lb. ft.

e. Reconditioning Valves and Guides

1. Remove cylinder head per subparagraph c above. Place on clean surface.

2. Using suitable spring compressor, such as J-8062, compress valve spring and remove valve spring cap key. Release tool and remove spring and cap. See Figure 60-214.




Figure 60-212 Exhaust Manifold Installation (350 Left Side Shown)




Figure 60-214 Removing Valve Cap Retainers.

3. Remove valve seals from intake and exhaust valve guides. Seals must be discarded. Remove valves. Place valves in numerical order so that they can be reinstalled in original location.

NOTE: *The 455 cu.in. engines Do Not have exhaust valve guide seals.*

4. Remove all carbon from combustion chambers, piston heads, and valves. When using scrapers or wire brushes for removing carbon, avoid scratching valve seats and valve faces. A soft wire brush (such as J-8358) is suitable for this purpose.

5. Clean carbon and gum deposits from valve guide bores. Use Reamer J-8003.

6. Inspect valve faces and seats for pits, burned spots or other evidences of poor seating. If a valve head must be ground until the outer edge is sharp in order to true up the face, discard the valve because the sharp edge will run too hot. 45° is the correct angle for valve faces.

7. If valve stem has too much clearance in its guide, the guide should be reamed to .006" oversize using J-22612 and then to .010" oversize using Reamer J-9345-1. See Figure 60-215.

NOTE: *.006" oversize valves are occasionally used in production. If clearance in the guide exceeds .006" the guide should be reamed to .010" oversize using J-9345-1. Oversize valves are identified by the oversize marking stamped on the valve head. See Figure 60-216.*

The Parts Department stocks .010" oversize valves for replacement purposes. See Figure 60-216.

8. True up valve seats to 45°. Cutting a valve seat results in lowering the valve spring pressure and increases the width of the seat. The nominal width of the valve seat is 1/16". If a valve seat is over 5/64" wide after truing up it should be narrowed to specified width by the use of 20° and



Figure 60-215 Reaming Valve Guide




Figure 60-216 Oversize Valve Identification

70° stones.

Improper hydraulic valve lifter operation may result if valve and seat have been refinished enough to allow the end of valve stem to raise approximately .050" above normal position. In this case it will be necessary to grind off end of valve stem or replace parts. *The normal height of the valve stem above the valve spring seat surface of the head is 1.926 (350 Cu In) and 2.275 (455 Cu. In.).*

9. Lightly lap the valves into seats with the fine grinding compound. The refacing and reseating operations should leave the refinished surfaces smooth and true so that a minimum of lapping is required. Excessive lapping will groove the valve face preventing a good seat when hot.

IMPORTANT: *New valves should not be lapped under any condition as the .0002" - .0015" aluminum alloy surface will be removed.*

10. Test valves for concentricity with seats and for tight seating. The usual test is to coat the valve face lightly with Prussian blue and turn the valve against seat. If the valve seat is concentric with the valve guide a mark will be made all around the seat, while if the seat is not concentric with the guide, a mark will be made on only one side of the seat. Next, coat the valve seat lightly with Prussian blue. Rotate the valve against the seat to determine if the valve face is concentric with the valve stem, and if the valve is seating all the way around. Both of these tests are necessary to prove that a proper seat is being obtained.

11. Remove any burrs from valve stem with fine stone or crocus cloth.

12. Lubricate valve stems and guides with "Service MS" engine oil and reinstall valves.

13. Install valve seal.

NOTE: *Do Not install exhaust valve guide seals on 455 cu.in. engines.*

a. Start valve seal carefully over valve stem. Push seal down until it touches top of guide.

b. Use installation tool J-22509 to push seal over valve guide until upper inside surface of seal touches top of guide.

NOTE: *COMPRESS SPRINGS ONLY ENOUGH TO INSTALL KEEPERS. EXCESS COMPRESSION CAN CAUSE SPRING RE-*

TAINER TO DAMAGE VALVE SEAL.

14. Install valve spring on the 350 Cu. In. with closely wound coil toward the cylinder head. See Figure 60-217.




Figure 60-217 Valve Spring
(350 cu.in.)

NOTE: The top inside diameter of 350 cu.in. valve springs is .880" - .866" and the bottom inside diameter is .945" - .931". The large diameter must be toward the cylinder head. The valve springs for 455 cu.in. engines may be installed with either end up. See Figure 60-218.




Figure 60-218 Valve Spring
(455 cu.in.)

15. Reinstall valve spring, cap and cap retainer, using same equipment used for removal.

16. Install cylinder head as described in subparagraph d above.

f. Rocker Arm Assembly Removal

1. Remove rocker arm cover and remove four rocker arm and shaft assembly to cylinder head bolts. Remove shaft assembly.

2. Place assembly on clean surface.

3. Remove nylon arm retainers by breaking them below their head with a chisel. See Figure 60-219.



Figure 60-219 Removing
Nylon Retainer

4. Remove rocker arms and springs and clean in suitable solution. Inspect for wear. Remove retainer pieces from inside shaft.

g. Rocker Arm Assembly Installation

1. Install rocker arms and springs on shaft lubricating all parts as they are assembled with engine oil. Each pair of rocker arms must be installed so that the external rib on each arm points away from the rocker arm shaft bolt. See Figure 60-220

2. Center each arm on the 1/4" hole in the shaft. Install new nylon rocker arm retainers in the 1/4" holes using a drift of at least 1/2" dia.

3. Install rocker arm assembly as outlined in subparagraph d.

h. Valve Lifter Service

1. Refer to procedure outlined under "Cylinder Head Removal" (par. 61-1, subpar. c) for lifter removal.

2. Place lifter in a wooden block with numbered holes or similar device to keep them identified as to position in engine.

3. If less than a complete set of lifters are being removed, disassemble one or two and check for dirt or




Figure 220 Rocker Arms Positioned on Shaft

varnish. If this condition exists, it is advisable to remove all lifters for cleaning and inspection. Otherwise, service only those lifters that are not operating properly.

4. Examine the cam contact surface at lower end of lifter body. If this surface is extremely worn, galled, or otherwise damaged, discard the lifter assembly. In this case, examine the mating camshaft lobe for excessive wear or damage.

5. Disassemble each valve lifter by using a push rod to hold down the push rod seat while removing the plunger retainer from the lifter body using Retainer Remover J-5238. See Figure 60-221. Remove push rod seat, oil metering valve, and plunger from lifter body.




Figure 60-221--Removing and Installing Plunger Retainer

6. If a plunger sticks in lifter body, place lifter in large end of Plunger Remover J-4160-A with plunger inward. While holding lifter with thumb, rap the open end of remover against a block of wood with just enough force to jar the plunger from body. See Figure 60-222.

7. Drain oil out of body into waste can and remove the ball retainer, ball, ball spring, and plunger spring. A strainer placed over waste can will prevent dropping these parts into can.

8. Place all parts of each lifter in a separate compartment of a tray.




Figure 60-222 - Removing Stuck Plunger

The body and plunger are selectively fitted to each other and must not be interchanged with parts of other lifters. Keeping all parts of the lifter together until cleaned and inspected will aid in diagnosing cause of improper operation.

9. Rinse the tray full of lifter parts in a pan of kerosene to remove as much oil as possible. This will reduce contamination of the cleaning solvent and extend its effective life.

10. Submerge the tray and parts in the cleaning solvent and leave to soak for approximately one hour. The time required will depend on the varnish on lifter parts and the effectiveness of the solvent.

11. After the varnish has dissolved or has softened sufficiently to permit removal by wiping, raise the tray and allow tray and parts to drain so that solvent will be saved.

12. Rinse the tray of parts in the pan of kerosene to cut the solvent and avoid injury to hands.

13. Working on one lifter at a time and using CLEAN lint-free cloths,

thoroughly wipe off all parts. Clean the plunger and the external and internal surfaces of the body with a hard wiping action to remove any varnish deposits. Rinse the parts in the kerosene using Cleaning Brush J-5099 in the bore of lifter body.

NOTE: To insure absolute cleanliness of a reconditioned lifter assembly, it is advisable to inspect and assemble each lifter before cleaning the next lifter.

14. The following list outlines the inspection of lifter parts. An inspection should be made at this point to determine whether or not a lifter is in need of replacement.

NOTE: The hydraulic valve lifter is serviced as a complete assembly only. If one or more of the valve lifter components are faulty, the complete lifter must be replaced.

(a) *Lifter Body.* Inspect inner and outer surfaces of body for blow holes and scoring. Replace lifter assembly if body is roughly scored or grooved, or has a blow hole extending through the wall in position to permit oil leakage from lower chamber. The prominent wear pattern just above lower end of body should not be considered a defect unless it is definitely grooved or scored; it is caused by side thrust of cam against body while the lifter is moving vertically in its guide.

Inspect the cam contact surface on lower end of lifter body. Replace the lifter assembly if this surface is excessively worn, galled, or otherwise damaged. A lifter body that has been rotating will have a round wear pattern and a non-rotating lifter body will have spalling on the lifter base.

NOTE: All 1970 V-8 engines have valve lifters with a slight spherical shaped base that will allow lifter rotation, which is induced by the tapered lobes on the camshaft producing camshaft thrust rearward, causing lifter rotation.

(b) *Lifter Plunger.* Using a magnify-

ing glass, inspect the check ball seat for defects. Inspect outer surface of plunger for scratches or scores. Small score marks with a rough, satiny finish will cause the plunger to seize when hot but operate normally when cool. Defects in check ball seat or scoring or scratches on outer surface of plunger which may be felt with a fingernail are causes for replacing the lifter assembly. This rule does not apply to the slight edge which may sometimes be present where the lower end of plunger extends below the ground inner surface of the body. This edge is not detrimental unless it is sharp or burred.

A blackened appearance is not a defective condition. Sometimes the discoloration serves to highlight slight grinder chatter marks and give the outer surface of plunger a ridged or fluted appearance. This condition will not cause improper operation, therefore it may be disregarded.

(c) *Push Rod and Seat.* Replace lifter if the area where the push rod contacts the push rod seat is rough, or otherwise damaged. Replace any push rod having a rough or damaged ball end.

(d) *Check Ball.* Using a magnifying glass, carefully examine the check ball for nicks, imbedded material or other defects which would prevent proper seating. Such defects would indicate the cause of intermittently noisy lifter operation.

(e) *Check Ball Spring.* Examine check ball spring for wear or damage. Replace lifter if any spring is distorted or shows evidence of wear.

(f) *Ball Retainer.* Replace lifter if a retainer is cracked or which has a heavily worn area. A small bright spot where the ball contacts the retainer is the normal condition.

(g) *Plunger Spring.* Replace lifter if the plunger spring is distorted or damaged. Exhaustive tests have shown that plunger springs seldom

break down in service.

15. Rinse lifter plunger in the kerosene in middle compartment of cleaning tank and then give it a thorough final rinsing in the kerosene in right compartment.

16. Hold plunger in vertical position with feed hole up, then rinse and install the check ball, check ball spring, ball retainer, spring, and body over the plunger. See parts in Figure 60-223.

17. Rinse push rod seat, metering valve, and plunger retainer place these parts in end of body and degrease with handle of Remover J-5238 until retainer engages groove in body. See Figure 60-221, View B.

18. Wrap the lifter in clean paper or otherwise protect it from dirt while reconditioning the other valve lifters, preparatory to testing all lifters for leakdown rate.

19. Check lifter leakdown rate according to subparagraph i below.

20. Make certain that valve lifter guide holes and adjacent area of cylinder block are clean. Liberally lubricate the camshaft and lifter bores with "Service MS" oil and install lifters. Each lifter must slide freely in its guide hole.

21. Following the procedure outlined in paragraph 61-1, subparagraph d, reassembly engine.

i. Checking Valve Lifter Leakdown Rate

After a hydraulic lifter has been cleaned, inspected, and assembled it must be tested before it is installed in an engine. Lifter Test Fixture J-5790 has been designed to test the leakdown rate of a lifter to determine whether it is within limits which assure satisfactory lifter operation.

The following procedure must be carefully followed to obtain an accurate test.

1. Thoroughly clean the cup of test fixture, install cup on fixture, and fill it to within 1/2" of the top with "Hydraulic Lifter Test Fluid," which is available through Kent-Moore Organization, Inc., under K-M-number J-5268.

2. Remove rubber washer (used for larger lifters) and install Gage Sleeve J-5790-27 in the cup; also install Gage Rod Nose J-5790-13 in the arm.

3. Swing the weight arm up out of the way, raise the ram and place the valve lifter (top side up) in Sleeve J-5790-27. The lifter must be completely covered by the fluid during test.

4. Lower the ram to rest in the lifter push rod seat, then lower the weight arm to rest on the roller of ram as shown in Figure 60-224.

5. Operate the lifter plunger through its full travel to force all air out of the lifter by using a vigorous pumping action on the weight arm. Continue the pumping action until considerable resistance is built up in the lifter and a definite grab point is felt at the top of the stroke, when the indicator pointer is at the bottom of the scale.

Finally, pump vigorously for approximately 10 additional strokes to make sure all air is removed from the lifter.

6. Raise weight arm to allow the lifter plunger to come up to its retainer, then lower the arm to rest on the ram roller. As the pointer starts moving upward start rotating the fluid cup by turning the handle one revolution every two seconds.

7. Use a stop watch to check the time required for pointer to move from the lower to the upper mark on scale where marked "BUICK V-8." The cup must be rotated during this test.

8. The leakdown rate (time between marks) must be between 12 and 60 seconds to assure satisfactory lifter




Figure 60-223--Hydraulic Valve Lifter Parts




Figure 60-224--Checking Lifter Leakdown Rate

performance. A doubtful lifter should be tested three or four times. Replace any lifter which does not test within the specified limits.

9. After all lifters have been tested, place the cover over the test fixture to keep dirt out of the cup and fluid. The fluid should be discarded and the cup should be thoroughly cleaned after a few sets of lifters have been tested.

j. Exhaust Manifold Removal (Left Side)

A. 43,44000 Series 1. Raise front of car and support on stands.

2. Disconnect exhaust pipe from exhaust manifold on both sides of engine and lower. If dual exhaust, disconnect left exhaust pipe and lower.

3. If manual transmission remove equalizer shaft.

4. Remove exhaust manifold to cylinder head bolts.

5. Remove exhaust manifold from beneath the car.

b. 45,000 Series 1. Remove left exhaust pipe from exhaust manifold.

2. Remove exhaust manifold to cylinder head bolts.

3. Remove exhaust manifold from the top of the car.

c. 46-48-49000 Series 1. Raise front of car and support on stands.

2. Disconnect exhaust pipe from exhaust manifold on both sides of engine and lower. If dual exhaust, disconnect left exhaust pipe and lower.

3. If manual transmission, remove equalizer shift.

4. Remove pitman arm from pitman shaft using Tool J-5504. Swing steering linkage forward.

NOTE: Mark location of pitman arm to pitman shaft for reinstallation.

5. Remove exhaust manifold to cylinder head bolts.

6. Remove exhaust manifold from beneath the car.

k. Exhaust Manifold Installation

1. Install manifold by reversing above procedures.

2. Torque exhaust manifold bolts to 18 lb. ft.

3. Torque pitman shaft nut to 140 lb. ft.

NOTE: This Pitman Arm to Steering Shaft FASTENER IS AN IMPORTANT ATTACHING PART IN THAT IT COULD AFFECT THE PERFORMANCE OF VITAL COMPONENTS AND SYSTEMS, AND/OR COULD RESULT IN MAJOR REPAIR EXPENSE. IT MUST BE REPLACED WITH ONE OF THE SAME PART NUMBER OR WITH AN EQUIVALENT PART IF REPLACEMENT BECOMES NECESSARY. DO NOT USE A REPLACEMENT PART OF LESSER QUALITY OR SUBSTITUTE DESIGN. TORQUE VALUES MUST BE USED AS SPECIFIED DURING REASSEMBLY TO ASSURE PROPER RETENTION OF THIS PART.

l. Oil Pan Removal

1. Disconnect battery.

2. Remove fan shroud to radiator tie bar screws.

3. Remove air cleaner and disconnect throttle linkage.

4. Raise car and support on stands.

5. Drain oil.

6. If equipped with manual transmission:

(a) Loosen clutch equalizer bracket

to frame attaching bolts.

(b) Disconnect exhaust crossover pipe at engine.

7. If equipped with automatic transmission:

(a) Remove lower flywheel housing.

(b) Remove shift linkage attaching bolt and swing out of way.

(c) Disconnect exhaust crossover pipe at engine.

8. Disconnect idler arm at frame and push steering linkage forward to cross member.

9. Remove front engine mounting bolts.

10. Raise engine by placing jack under crankshaft pulley mounting.

NOTE: *At this point, on A/C equipped cars, it will be necessary to place a support under the right side of the transmission prior to raising engine. This is necessary to prevent the engine transmission assembly from cocking to the right when being raised.*

11. Remove oil pan bolts and remove pan.

NOTE: *It may be necessary to position crankshaft so 1 and 2 crankpin and counterweight will not interfere with front of oil pan.*

12. Remove rear seal (455 cu.in. engines only).

m. Oil Pan Installation

1. Clean oil pan. Make sure the gasket surfaces on pan and block are clean.

2. Install rear seal (455 cubic inch engines only).

3. Apply non-hardening Permatex to a few spots on a new pan gasket (cork) and install on block. *Make sure seal and gasket are properly fitted.* See Figure 60-224A. (455




Figure 60-224A Oil Pan Gasket and Seal Installation

cu.in. only).

4. Install oil pan. Torque bolts to 14 lb. ft. Do not overtighten.

5. Reverse procedures in subparagraph c.

n. Removal and Inspection of Oil Pump Pipe and Screen Assembly

1. Remove oil pan (subpar. c).

2. Remove oil pump pipe and screen assembly to cylinder block bolts.

3. Clean the screen and housing thoroughly in solvent and blow dry with air stream.

o. Installation of Oil Pump Pipe and Screen Assembly

Install by reversing removal procedure, paying particular attention to the following points.

1. Make sure oil pump pipe flange gasket surface of block is smooth and free of dirt.

2. Use new gasket and tighten bolts to 8 lb. ft. torque. See Figure 60-224B.

3. Install oil pan (subpar. m).

6I-2 CONNECTING ROD BEARINGS

A connecting rod bearing consists of two halves or shells which are interchangeable in rod and cap. When the shells are placed in position, the ends extend slightly beyond the parting surfaces so that when the rod bolts are tightened the shells will be clamped tightly in place to insure positive seating and to prevent turning. *The ends of the bearing shells must never be filed flush with parting surface of rod or cap.* If a rod bearing becomes noisy or is




Figure 60-224B Oil Pickup Pipe and Screen

worn so that clearance on the crankpin is excessive, a new bearing of proper size must be selected and installed since no provision is made for adjustment. *Under no circumstances should the connecting rod or cap be filled to adjust the bearing clearance.*

a. Inspection of Connecting Rod Bearings and Crankpin Journals

After removal of engine oil pan, paragraph 61- 1, subparagraph 1., disconnect two connecting rods at a time from crankshaft and inspect the bearings and crankpin journals. While turning crankpin it is necessary to temporarily reconnect the rods to crankshaft to avoid possibility of damaging the journals through contact with loose rods.

NOTE: Do Not interchange rod caps with rods.

If connecting rod bearings are chipped or scored they should be replaced. If bearings are in good physical condition check for proper

clearance on crankpin as described in subparagraph b, below.

If crankpin journals are scored or ridged the crankshaft must be replaced, or reground for undersize bearings, to insure satisfactory life of connecting rod bearings. Slight roughness may be polished out with fine grit polishing cloth thoroughly wetted with engine oil. Burrs may be honed off with a fine oil stone.

Use an outside micrometer to check crankpins for out- of-round. If crankpins are more than .0015" out-of-round, satisfactory life of new bearings cannot be expected.

b. Checking Clearance and Selecting Replacement Bearings

Service bearings are furnished in standard size and several undersizes (including undersizes for reground crankpins).

The clearance of connecting rod (and crankshaft) bearings may be checked by use of Plastigage Type PG-1 (green) or equivalent which has a range of .001" to .003".

1. Remove connecting rod cap with bearing shell. Wipe oil from bearing and crankpin journal, also blow oil out of hole in crankshaft.

NOTE: *Plastigage is soluble in oil.*

2. Place a piece of Plastigage lengthwise along the bottom center of the lower bearing shell (Figure 60-225, View A), then install cap with shell and tighten bolt nuts to 35 lb. ft. torque. (350 Cu. In.) and 45 lb. ft. (455 Cu. In.)

NOTE: *The rib on edge of cap and the conical boss (455 cu.in. engine) or rib (350 cu.in. engine) on web of rod must be toward rear of engine on all rods in left bank and toward front of engine in right bank.*

3. DO NOT TURN CRANKSHAFT with Plastigage in bearing.




Figure 60-225--Checking Bearing Clearance with Plastigage

4. Remove bearing cap with bearing shell, the flattened Plastigage will be found adhering to either the bearing shell or the crankpin. *Do not remove it.*

5. Using the scale printed on the Plastigage envelope, measure the flattened Plastigage at its widest point. The number within the graduation which most closely corresponds to the width of Plastigage indicates the bearing clearance in thousandths of an inch. See Figure 60-225, View B.

6. The desired clearance with a new bearing is .0002" to .0023". If bearing has been in service it is advisable to install a new bearing if the clearance exceeds .003"; however, if bearing is in good condition and is not being checked because of bearing noise, it is not necessary to replace the bearing.

7. If a new bearing is being selected, try a standard size, then each undersize bearing in turn until one is found that is within the specified limits when checked for clearance with Plastigage.

NOTE: *Each undersize bearing shell has a number stamped on outer surface on or near the tang to indicate amount of undersize. See Figure 60-226.*

8. After the proper size bearing has been selected, clean off the Plastigage, oil the bearing thoroughly, reinstall cap with bearing shell and




Figure 60-226--Location of Undersize Mark on Bearing Shell

tighten bolt nuts to 35 lb. ft. torque (350-Cu In.) and 45 lb. ft. (455 cu. in.). See Note in Step 2.

9. With selected bearing installed and bolts tightened, it should be possible to move connecting rod freely back and forth on crankpin as allowed by end clearance. If rod cannot be moved, either the bearing is too much undersize or a misaligned rod is indicated.

61-3 CRANKSHAFT BEARINGS AND SEALS

a. Replacement of Crankshaft Bearings

A crankshaft bearing consists of two halves or shells which are not alike and not interchangeable in cap and crankcase. The upper (crankcase) half of the bearing is grooved to supply oil to the connecting rod bearings while the lower (bearing cap) half of the shell is not grooved. The two bearing halves must not be interchanged. All crankshaft bearings except the thrust bearing and rear main upper are identical. The thrust bearing (3) is flanged to take end thrust and the rear main upper bearing groove does not extend the full length of the bearing. When the

shells are placed in crankcase and bearing cap, the ends extend slightly beyond the parting surfaces so that when cap bolts are tightened the shells will be clamped tightly in place to insure positive seating and to prevent turning. *The ends of shells must never be filed flush with parting surface of crankcase or bearing cap.* Crankshaft bearings are the precision type which do not require reaming to size. Shims are not provided for adjustment since worn bearings are readily replaced with new bearings of proper size. Bearings for service replacement are furnished in standard size and undersizes. *Under no circumstances should crankshaft bearing caps be filed to adjust for wear in old bearings.*

After removal of oil pan, pipe and screen assembly, oil pan baffle, per paragraph 61-1, subparagraph 1, perform the following removal, inspection and installation operations on each crankshaft bearing in turn so that the crankshaft will be well supported by the other bearings

NOTE: *If crankshaft has been removed to check straightness the following procedure is suggested.*

Rest crankshaft on "V-blocks" at no. 1 and no. 5 main bearing journals. Check indicator runout at No. 2, 3, and 4 main bearing journals. Total indicator readings at each journal should not exceed .003"

While checking runout at each journal note relation of "high" spot (for maximum eccentricity) on each journal to the others.

"High" spot on all journals should come at the same angular location. If "high" spots do not come at nearly the same angular location, crankshaft has a "crook" or "dogleg" in it and is unsatisfactory for service.

1. Since any service condition which affects the crankshaft bearings may also affect the connecting rod bearings, it is advisable to inspect

connecting rod bearings first. If crankpins are worn to the extent that crankshaft should be replaced or reground, replacement of crankshaft bearings only will not be satisfactory.

NOTE: *If replacement of cylinder block or crankshaft is required, always check main bearing clearance with Plastigage to obtain specified limits.*

2. Remove one bearing cap, then clean and inspect lower bearing shell and the crankshaft journal. If journal surface is scored or ridged, the crankshaft must be replaced or reground to insure satisfactory operation with new bearings. Slight roughness may be polished out with fine grit polishing cloth thoroughly wetted with engine oil, and burrs may be honed off with a fine stone.

3. If condition of lower bearing shell and crankshaft journal is satisfactory, check the bearing clearance with Plastigage as described for connecting rod bearing in paragraph 61-2, subparagraph b.

4. When checking a crankshaft bearing with Plastigage, turn crankshaft so that oil hole is up to avoid dripping of oil on Plastigage. Place paper shims in lower halves of adjacent bearings and tighten cap bolts to take the weight of crankshaft off the lower shell of bearing being checked.

NOTE: *Arrow on cap must point to front of engine.*

5. If bearing clearance exceeds .003", it is advisable to install a new bearing; however, if bearing is in good condition and is not being checked because of bearing noise, it is not necessary to replace the bearing.

6. Loosen all crankshaft bearing cap bolts 1/2 turn, and remove cap of bearing to be replaced.

7. Remove upper bearing shell by inserting Bearing Shell Remover and Installer J-8080 in oil hole in

crankshaft, then slowly turning crankshaft so that the tool rotates the shell out of place by pushing against the end without the tang. See Figure 60-227.




Figure 60-227 - Removal and Installation of Crankshaft Bearing Upper Shell

CAUTION: When turning crankshaft with rear bearing cap removed, hold oil seal to prevent it from rotating out of position in crankcase.

8. The crankshaft journal cannot be measured with an outside micrometer when shaft is in place; however, when upper bearing shell is removed the journal may be checked for out-of-round by using a special crankshaft caliper and inside micrometer. The caliper should not be applied to journal in line with oil hole.

If crankshaft journal is more than .0015" out-of-round, the crankshaft should be replaced since the full mileage cannot be expected from bearings used with an excessively out-of-round crankshaft.

9. Before installation of bearing shells make sure that crankshaft journal and the bearing seats in crankcase and cap are thoroughly cleaned.

10. Coat inside surface of upper bearing shell with engine oil and place shell against crankshaft journal so that tang on shell will engage notch in crankcase when shell is rotated into place.

IMPORTANT: Upper bearing shells have an oil groove in their center, while lower shells are not grooved. They must not be interchanged.

11. Rotate bearing shell into place as far as possible by hand, then insert Installer J-8080 in crankshaft oil hole and rotate crankshaft to push shell into place.

CAUTION: Bearing shells should move into place with very little pressure. If heavy pressure is required, shell was not started squarely and will be distorted if forced into place.

12. Place lower bearing shell in bearing cap, then check clearance with Plastigage as previously described.

13. The desired clearance with a new bearing is .0004" to .0015" (350 Cu. In.) and .0007" to .0018" (455 cu. in.). If this clearance cannot be obtained with a standard size bearing, insert an undersize bearing and check again with Plastigage.

NOTE: Each undersize shell has a number stamped on outer surface on or near the tang to indicate amount of undersize.

14. When the proper size bearing has been selected, clean out all Plastigage, oil the lower shell and reinstall bearing cap. Clean the bolt holes and lube bolts, then torque cap bolts to specification given in paragraph 60-1. The crankshaft should turn freely at flywheel rim; however, a very slight drag is permissible if an undersize bearing is used.

15. If the thrust bearing shell is disturbed or replaced it is necessary to line up the thrust surfaces of the bearing shell before the cap bolts are tightened. To do this, move the crankshaft fore and aft the limit of its travel several times (last movement fore) with the thrust bearing cap bolts finger tight.

16. After bearing is installed and tested, loosen all bearing cap bolts 1/2 turn and continue with other

bearings. When bearings have been installed and tested, tighten all bearing cap bolts to specification given in paragraph 60-1.

17. Refer to subparagraph b for replacement of rear bearing oil seals.

18. Install oil pan baffle, pipe and screen assembly, and oil pan following procedure outlined in paragraph 61-1, subparagraph 1.

b. Installation of Rear Bearing Oil Seals

Braided fabric seals are pressed into grooves formed in crankcase and rear bearing cap to rear of the oil collecting groove, to seal against leakage of oil around the crankshaft. See Figure 60-228 or 60-229.




Figure 60-228-- Installing Rear Bearing Oil Seals (350 Cu. In.)




Figure 60-229--Rear Bearing Oil Seal (455 Cu. In.)

The braided fabric seal can be installed in crankcase only when crankshaft is removed; however, the seal can be replaced in cap whenever cap is removed. Remove old seal and place new seal in groove with both ends projecting above parting surface of cap. Force seal into groove by rubbing down with hammer handle or smooth stick until seal projects above the groove not more than 1/16". Cut ends off flush with surface of cap, using sharp knife or razor blade. See Figure 60-228 or 60-229.

CAUTION: *The engine must be operated at slow speed when first started after new braided seal is installed.*

Neoprene composition seals (350 cu.in. only) are placed in grooves in the sides of bearing cap to seal against leakage in the joints between cap and crankcase. The neoprene composition swells in the presence of oil and heat. The seals are undersize when newly installed and may even leak for a short time until the seals have had time to swell and seal the opening. See Figure 60-228.

The neoprene seals are slightly longer than the grooves in the bearing cap. The seals must not be cut to length. Before installation of seals, soak for 1 to 2 minutes in light oil or kerosene. After installation of bearing cap in crankcase, install seal in bearing cap.

After seal is installed, force seals up into the cap with a blunt instrument to be sure of a seal at the upper parting line between the cap and case.

61-4 PISTONS, RINGS, AND CONNECTING RODS

a. Replacement, Disassembly, and Inspection of Piston and Rod Assemblies

1. Remove cylinder heads. (par. 61-1, subpara. c) and oil pan (par. 61-1, subparagraph 1)

2. Examine the cylinder bores above the ring travel. If bores are worn so that a shoulder or ridge exists at the top of the cylinder, remove the ridges with a ridge reamer to avoid damaging rings or cracking ring lands in pistons during removal. See Figure 60-230.




Figure 60-230 Ridge Formed by Rings at Top of Travel

3. Use a silver pencil or quick drying paint to mark the cylinder number on all pistons, connecting rods and caps. Starting at the front end of the crankcase the cylinders in the right bank are numbered 2-4-6-8. Those in the left bank are numbered 1-3- 5-7.

4. With No. 1 crankpin straight down, remove the cap with bearing shell from No. 1 connecting rod, install the *short* Connecting Rod Bolt Guide J-5239-1 on the connecting rod bolt, above crankpin. Install the *long* Connecting Rod Bolt Guide J-5239-2 on remaining stud. Turn guides down fully to hold the upper bearing shell in place while removing piston and rod assembly. See Figure 60-231.

5. Use the long guide to push the piston and rod assembly out of the cylinder, then remove guides and reinstall cap with bearing shell on rod.

6. Remove all other piston and rod assemblies in the same manner.




Figure 60-231 Connecting Rod Bolt Guides Installed

7. Remove compression rings and remove oil ring by removing the two rails, and spacer-expander which are separate pieces in each piston third groove.

8. To remove piston pin:

455 Engine (a) Place piston and rod assembly in press, using Piston Support J-6047-17 (with full radial face up) under the piston.

(b) Place Drive Pin J-6047-4 in upper end of piston pin.

(c) Press pin from rod and piston.

350 Engine (a) Place piston and rod assembly in press, using Piston Support J-6047-5 (with full radial face up) under the piston.

(b) Place Drive Pin J-6047-4 in upper end of piston.

(c) Press pin from rod and piston.

9 (a) Inspect cylinder walls for scoring, roughness, or ridges which indicate excessive wear. Check cylinder bores for taper and out-out-round with an accurate cylinder gage at top, middle and bottom of bore, both parallel and at right angles to the centerline of the engine. The diameter of the cylinder bores at any point may be measured with an inside micrometer or setting the cylinder gage dial at "O" and measuring across the gage contact

points with outside micrometer while the gage is at same "O" setting.

(b) If a cylinder bore is moderately rough or slightly scored but is not out-of-round or tapered, it is usually possible to remedy the situation by honing the bore to fit a standard service piston since standard service pistons are high limit production pistons. If cylinder bore is very rough or deeply scored, however, it may be necessary to rebore the cylinder to fit an oversize piston in order to insure satisfactory results.

(c) If cylinder bore is tapered .005" or more or is out-of-round .003" or more, it is advisable to rebore for the smallest possible oversize piston and rings.

10. Clean carbon from piston surfaces and under side of piston heads. Clean carbon from ring grooves with suitable tool and remove any gum or varnish from piston skirts with suitable solvent.

11. Carefully examine pistons for rough or scored bearing surfaces, cracks in skirt or head cracked or broken ring lands, chipping or uneven wear which would cause rings to seat improperly or have excessive clearance in ring grooves. Damaged or faulty pistons should be replaced.

The pistons are cam ground, which means that the diameter at a right angle to the piston pin is greater than the diameter parallel to the piston pin. When a piston is checked for size, it must be measured with micrometers applied to the skirt at points 90° to the piston pin. See Figure 60-232. The piston should be measured (for fitting purposes) 1/4" below the bottom of the oil ring groove.

12. Inspect bearing surfaces of piston pins and check for wear by measuring worn or unworn surfaces with micrometers. Rough or worn pins should be replaced. Test fit of piston pins in piston bosses. Occasionally pins will be found tight due to gum

or varnish deposits. This may be corrected by removing the deposit with a suitable solvent. If piston bosses are worn out-of-round or oversize, the piston and pin assembly must be replaced. Oversize pins are not practical due to the pin being a press fit in the connecting rod. Piston pins must fit the piston with an easy finger push at 70 F (.0004" to .0007" clearance).

13. Examine all piston rings for scores, chips or cracks. Check compression rings for tension by com-




Figure 60-232--Measuring Piston

paring with new rings. Check gap of compression rings by placing rings in bore at bottom of ring travel. Measure gap with feeler gage. Gap should be between .010" and .020". If gaps are excessive (over .020") it indicates the rings have worn considerably and should be replaced.

b. Reboring Cylinder and Fitting New Pistons

If one or more cylinder bores are rough, scored, or worn beyond limits prescribed under subparagraph a, it will be necessary to smooth or true up such bores to fit new pistons.

If relatively few bores require correction it will not be necessary to rebore all cylinders to the same oversize in order to maintain engine balance, since all oversize service pistons are held to the same weights as standard size pistons. If condi-

tions justify replacement of all pistons, however, all new pistons should be the same nominal size.

Standard size service pistons are high limit or maximum diameter; therefore, they can usually be used with a slight amount of honing to correct slight scoring or excessive clearances in engines having relatively low mileage. All service pistons are diamond bored and selectively fitted with piston pins; pistons are not furnished without pins.

No attempt should be made to cut down oversize pistons to fit cylinder bores as this will destroy the surface treatment and affect the weight. The smallest possible oversize service pistons should be used and the cylinder bores should be honed to size for proper clearances.

Before the honing or reboring operation is started, measure all new pistons with micrometer contacting at points exactly 90 degrees to piston pin (Figure 60-232) then select the smallest piston for the first fitting. The slight variation usually found between pistons in a set may provide for correction in case the first piston is fitted too free.

If wear at top of cylinder does not exceed .005" on the diameter or exceed .003" out-of-round, honing is recommended for truing the bore. If wear or out-of-round exceeds these limits, the bore should be trued up with a boring bar of the fly cutter type, then finish honed.

When reboring cylinders, all crankshaft bearing caps must be in place and tightened to proper torque to avoid distortion of bores in final assembly. Always be sure the crankshaft is out of the way of the boring cutter when boring each cylinder. When taking the final cut with boring bar leave .001" on the diameter for finish honing to give the required clearance specified below.

When honing cylinders use clean

sharp stones of proper grade for the amount of metal to be removed, in accordance with instructions of the hone manufacturer. Dull or dirty stones cut unevenly and generate excessive heat. When using coarse or medium grade stones use care to leave sufficient metal so that all stone marks may be removed with the fine stones used for finishing to provide proper clearance.

When finish honing, pass the hone through the entire length of cylinder at the rate of approximately 60 cycles per minute. This should produce the desired 45 degree cross hatch pattern on cylinder walls which will insure maximum ring life and minimum oil consumption.

It is of the greatest importance that refinished cylinder bores are trued up to have not over .0005" out-of-round or taper. Each bore must be final honed to remove all stone or cutter marks and provide a smooth surface. During final honing, each piston must be fitted individually to the bore in which it will be installed and should be marked to insure correct installation.

After final honing and before the piston is checked for fit, each cylinder bore must be *thoroughly* washed to remove all traces of abrasive and then dried thoroughly. The dry bore should then be brushed clean with a power-driven fibre brush. If all traces of abrasive are not removed, rapid wear of new pistons and rings will result. A satisfactory method of fitting pistons is as follows.

1. Expand a telescope gage to fit the cylinder bore at right angles to the piston pin and between 1-1/2" and 2" from the top. See Figure 60-233.

2. Measure the telescope gage. See Figure 60- 234.

3. Measure the piston to be installed. See Figure 60-232. The piston must be measured at right angles to the piston pin 1/4" below the oil ring




Figure 60-233 Checking Cylinder Bore

groove. The piston must be between .0008" and .0014" (350 Cu. In.) and .0007" to .0013" (455 Cu. In.) smaller than the cylinder bore.




Figure 60-234 Measuring Telescope Gauge

NOTE: Both block and piston must be at very nearly the same temperature when measurements are made or errors due to expansion will occur. A difference of 10° F between parts is sufficient to produce a variation of .0005".

c. Fitting New Piston Rings

When new piston rings are installed without reboring cylinders, the glazed cylinder walls should be slightly dulled, but without increasing the bore diameter, by means of the finest grade of stones in a cylinder hone.

New piston rings must be checked for clearance in piston grooves and for gap in cylinder bores. The cylinder bores and piston grooves must be clean, dry and free of carbon and burrs.

With rings installed, check clearance in grooves by inserting feeler gages between each ring and its *lower* land because any wear that occurs forms a step at inner portion of the lower land.

If the piston grooves have worn to the extent that relatively high steps exist on the lower lands, the piston should be replaced because the steps will interfere with the operation of new rings and the ring clearances will be excessive. Piston rings are not furnished in oversize widths to compensate for ring groove wear.

When fitting new rings to new pistons the side clearance of the compression rings should be .003" to .005" and side clearance of the oil ring should be .0035" to .0095".

To check the end gap of compression rings, place the ring in the cylinder in which it will be used, square it in the bore by tapping with the lower end of a piston, then measure gap with feeler gages. Piston rings should not have less than .010" (350 Cu. In.) and .013" (455 Cu. In.) (compression rings) and .015" (oil ring) gap when placed in cylinder bores. If gap is less than specified, file the ends of rings carefully with a smooth file to obtain proper gap.

d. Assembly and Installation of Piston and Connecting Rod Assemblies

NOTE: Connecting rods may be sprung out of alignment in shipping or handling. Always check a new rod before installing piston and pin.

Check bend and twist on an accurate rod aligning fixture using Guide Pin J-6047-16 for 455 engines, and J-6047-20 for 350 engines, in place of wrist pin. Press V-block firmly and evenly against guide pin to prevent

cocking pin in eye of rod which may be up to .00125" tight on pin.

1. To assemble piston and pin to connecting rod, first place Piston Pin Spacer, J-6047-21, and Piston Support, J-6047-17, or J-6047-5 which-ever applies, in base plate of press.

2. If the piston and rod assembly is to be installed in the *left* bank, the assembly must be made as shown in Figures 60-235 and 60-235A.




Figure 60-235--Left Bank Piston and Rod Assembly (455 cu.in. engines)




Figure 60-235A Left Bank Piston and Rod Assembly (350 cu.in. Engine)

3. If the piston and rod assembly is to be installed in the *right* bank, the assembly must be made as shown in Figure 60-236.




Figure 60-236--Right Bank Piston and Rod Assembly (455 cu.in. Engines)




Figure 60-236A Right Bank Piston and Rod Assembly (350 cu.in. engine)

4. Lubricate piston pin to avoid damage when pressing into connecting rod.

5. Assemble piston and rod on spring loaded guide pin.

6. Install drive pin in upper end of piston pin. Press on drive pin till piston pin bottoms.

7. Remove piston and rod assembly from press. Rotate piston on pin to be sure pin was not damaged during the pressing operation.

8. Install piston rings as shown in Figures 60-237 and 60-238. Position expander ends over piston pin. Install oil ring rail spacer, and oil ring rails. Position gaps in rails "up" on same side of piston as oil spurt hole in connecting rod. Install compression rings in upper two grooves.




Figure 60-237--Piston Rings (350 Cu In.)




Figure 60-238--Piston Rings (455 Cu. In.)

a. Top compressing ring - When installed, the manufacturer's identification mark ("O", "DOT" or "TOP") facing up.

b. Second compression ring - When installed, the manufacturer's identification mark ("O", "DOT" or "TOP") facing up.

c. Oil ring - Can be installed with either rail facing up.

d. Ring gaps - All three ring gaps must be 90° apart. See Figure 60-239.




Figure 60-239 Piston Ring Gap Positioning

NOTE: To make certain expander ring does not overlap a red or blue mark will be visible on ring. See Figure 60-238.

NOTE: The rails and spacer of the oil ring are lightly held together with an oil soluble cement. If parts have separated they may be installed as individual pieces.

9. Make sure cylinder bores, pistons, connecting rod bearings and crankshaft journals are absolutely clean, then coat all bearing surfaces with engine oil.

10. Before installation of a piston and rod assembly in its bore, position the crankpin straight down.

11. Remove cap, and with bearing upper shell seated in connecting rod, install the *long* Guide J-5239-2 on bolt which is on same side of rod as the oil spurt notch in the bearing parting surface. Install short Guide J-5239-1 on the other connecting rod bolt.

These guides hold the upper bearing shell in place and protect the crankpin journal from damage during installation of connecting rod and piston assembly.

12. Make sure the gap in the oil ring rails is "up" toward center of engine and the gaps of the compression rings are positioned as shown in Figure 60-240.




Figure 60-240 Installing Piston with Ring Compressor Installed (350 Shown)

13. Lubricate the piston and rings and install in bore by compressing the rings either with a "wrap around" compressor or a split ring type such as shown in Figure 60-240.

14. Select new connecting rod bearing, if necessary, as described in paragraph 61-2. Otherwise install cap with bearing lower shell on rod and tighten bolt nuts to 35 lb. ft. (350 Cu. In.) and 45 lb. ft. (455 Cu. In.) torque.

15. Install all other piston and rod assemblies in same manner. When piston and rod assemblies are properly installed, the oil spurt holes in the connecting rods will be "up" toward the camshaft, the rib on the edge of the rod cap will be on the same side as the conical boss on the connecting rod web, and these marks, (rib and boss) will be toward the other connecting rod on the same crankpin. See Figure 60-235 and 60-236.

16. Check end clearance between connecting rods on each crankpin using feeler gages. Clearance should be between .005" and .012".

17. Install cylinder head (par. 61-1). Install oil screen and engine oil pan (61-1, subparagraph 1).

IMPORTANT: After installation of new pistons and rings, care should be used in starting the engine and running it for the first hour. Avoid high speeds until the parts have had a reasonable amount of 'break in' time. This practice will avoid unnecessary 'scuffing' of new parts.

61-5 CAMSHAFT AND TIMING CHAIN

a. Timing Chain Cover Removal

1. Drain radiator and block.
2. Disconnect upper and lower radiator hose and heater return hose at water pump, disconnect lower

bolts and brackets and remove radiator.

3. Remove fan, fan pulleys and belt(s).

4. Remove fan driving pulley (crankshaft) and pulley reinforcement.

5. Disconnect fuel lines and remove fuel pump.

6. Remove Delcotron generator and brackets.

7. Remove distributor cap and pull spark plug wire retainers off brackets on rocker arm cover. Swing distributor cap with wires attached out of the way. Disconnect distributor primary lead.

8. Remove distributor. If timing chain and sprockets are not going to be disturbed, note position of distributor rotor for reinstallation in same position.

9. Loosen and slide front clamp on thermostat by-pass hose rearward.

10. Remove harmonic balancer bolt and washer and remove harmonic balancer.

11. Remove bolts attaching timing chain cover to cylinder block. See Figures 60-241 and 60-242. Remove two oil pan to timing chain cover bolts 350 Cu In. and 4 bolts on the 455 Cu. In. Remove timing chain cover assembly and gasket. Thoroughly clean the cover, taking care to avoid damage to the gasket surface.




Figure 60-241 Timing Chain Cover Removal and Installation
(350 cu.in.)

and shedder. Drive from the front toward the rear of the timing chain cover.

2. Coil new packing around opening so ends of packing are at top. Drive in shedder using suitable punch. Stake the shedder in place in at least three places.

3. Size the packing by rotating a hammer handle or similar tool around the packing until the balancer hub can be inserted through the opening.

d. Timing Chain and Sprocket Removal

350 Cu. In. 1. With timing chain cover removed (subpar. a above) temporarily install crankshaft pulley bolt and washer in end of crankshaft. Turn crankshaft so sprockets are positioned as shown in Figure 60-243. Remove harmonic balancer bolt and washer using a sharp blow on the wrench handle, so that the bolt can be started out without changing position of sprockets.

2. Remove front crankshaft oil slinger.

3. Remove bolt and special washer retaining camshaft distributor drive gear and fuel pump eccentric to camshaft forward end. Slide gear and eccentric off camshaft. See Figure 60-244.

4. Use two large screwdrivers to alternately pry the camshaft sprocket then the crankshaft sprocket forward until the camshaft sprocket is free, then remove the camshaft sprocket and chain and finish working crankshaft sprocket off crankshaft.

5. Thoroughly clean the timing chain, sprockets, distributor drive gear, fuel pump eccentric and crankshaft oil slinger.

455 Cu. In. 1. With timing chain cover removed (subpar. a above)

b. Timing Chain Cover Replacement

Reinstall timing chain cover by reversing removal procedure, paying particular attention to the following points.

1. Remove oil pump cover and pack the space around the oil pump gears completely full of petroleum jelly. There must be no air space left inside the pump. Reinstall cover using new gasket. This step is very important as the oil pump may "lose its prime" whenever the pump, pump cover or timing chain cover is disturbed. If the pump is not packed, it may not begin to pump oil as soon as the engine is started.

2. The gasket surface of the block and timing chain cover must be smooth and clean. Use a new gasket and be certain it is positioned

correctly.

3. Position timing chain cover against block and be certain dowel pins engage dowel pin holes before starting bolts.

4. Lubricate the bolt threads before installation and install as shown in Figures 60-241 and 60-242.

5. Install harmonic balancer, bolt and washer. By using a screwdriver or other suitable tool, lock flywheel and torque bolt to (140-160 lb. ft. on 350 cu.in.) and (200-220 lb. ft. on 455 cu.in.) See Figure 60-242A.

c. Crankshaft Oil Seal Replacement

1. Use a punch to drive out old seal




Figure 60-242 Timing Chain Cover Removal and Installation (455 cu.in.)




Figure 60-242A Locking Flywheel to Torque Harmonic Balancer Bolt.(350 cu.in. Shown)




Figure 60-243--Installation of Timing Chain and Sprocket -350 Cu. In.




Figure 60-244 Fuel Pump and Distributor Drive Gear Installation-350 Cu. In.

Temporarily install crankshaft pulley bolt and washer in end of crankshaft. Turn crankshaft so sprockets are positioned as shown in Figure 60-245. Remove crankshaft pulley bolt and washer using a sharp blow on the wrench handle, so that the bolt can be started out without changing position of sprockets.




Figure 60-245 Installation of Timing Chain and Sprocket (455 cu.in.)

2. Remove oil pan per paragraph 6l-1, subparagraph 1.
3. Remove front crankshaft oil slinger.

4. Remove camshaft sprocket bolts.
5. Use two large screwdrivers to alternately pry the camshaft sprocket then the crankshaft sprocket forward until the camshaft sprocket is free, then remove the camshaft sprocket and chain and finish working crankshaft sprocket off crankshaft.
6. Thoroughly clean the timing chain, sprockets, distributor drive gear, fuel pump eccentric and crankshaft oil slinger.

e. Timing Chain and Sprocket Installation

350 Cu. In.

1. Turn crankshaft so that #1 piston is at top dead center.
2. Turn camshaft so with sprocket temporarily installed, timing mark is straight down. See Figure 60-243. Remove Sprocket.
3. Assemble timing chain on sprockets and slide the sprocket and chain assembly on the shafts with the timing marks in their closest together position and in line with the sprocket hubs. See Figure 60-243.
4. Assemble slinger on crankshaft with I.D. against sprocket (concave side toward front of engine). See Figure 60-245A.




Figure 60-245A Oil Slinger Installation

5. Slide fuel pump eccentric on camshaft and Woodruff key with oil groove forward. See Figure 60-244.
6. Install distributor drive gear. See Figure 60-244.
7. Install drive gear and eccentric bolt and retaining washer. Torque to 50 lb. ft.
8. Reinstall timing chain cover (subpar. b above).

455 Cu. In.

1. Turn crankshaft so that #1 piston is at top dead center.
2. Turn camshaft so with sprocket temporarily installed, timing mark is straight down. See Figure 60-245. Remove sprocket.
3. Assemble timing chain on sprockets and slide the sprocket and chain assembly on the shafts with the timing marks in their closest together position and in line with the sprocket hubs. See Figure 60-245.
4. Assemble slinger on crankshaft with I.D. against sprocket (concave side toward front of engine).

See Figure 60-245A.

5. Reinstall oil pan.
6. Install camshaft sprocket bolts. Torque to 22 lb. ft.
7. Reinstall timing chain cover (subpar. b above).

f. Camshaft Service

1. Remove intake manifold as outlined in paragraph 6l-l.
2. Remove rocker arm covers.
3. Remove rocker arm and shaft assemblies, push rods and valve lifters.
4. Remove timing chain cover, timing chain and sprocket, subparagraph d above.
5. Slide camshaft forward out of bearing bores carefully to avoid

marring the bearing surfaces.

6. When replacing camshaft, take particular care to avoid marring the bearing surfaces.
7. Replace valve mechanism as outlined in paragraph 6l-l.
8. Replace intake manifold as outlined in paragraph 6l-l.

Camshaft Bearing Service

Slightly scored camshaft bearings will be satisfactory if the surfaces of camshaft journals are polished and bearings are cleaned up to remove burrs, and the fit of shaft in bearings is free and within the clearance limits of .0015" to .004"

Should the bearing be gauged beyond repair, the bearing will have to be replaced.

To install precision replacement cam bearing, special Tool J-27408 is required. To remove and install replacement bearing proceed as follows:

BEARING REMOVAL

CAUTION: *Extreme care must be exercised during bearing removal and installation, not to damage bearings that are not being replaced.*

1. Remove camshaft and crankshaft.
2. Assemble puller screw to required length.
3. Select proper size expanding collet and back-up nut.
4. Install expanding collet on expanding mandrel. Install back-up nut.
5. Insert this assembly into camshaft bearing to be removed. Tighten back-up nut to expand collet to fit I.D. of bearing.
6. Thread end of puller screw assembly into end of expanding mandrel and collet assembly.

7. Install pulling plate, thrust bearing, and pulling nut on threaded end of puller screw.
8. Bearing can then be removed by turning pulling nut. See Figure 60-245B.

2. Select proper size expanding collet and back-up nut.
3. Install expanding collet on expanding mandrel.
4. Install back-up nut.

9. Install bearing in the same manner as described in Steps 8 and 9 under "Bearing Removal."

NOTE: When installing rear cam bearing, install new welch plug at back of cam bore. Coat O.D. of plug with non-hardening Permatex before installation.




Figure 60-245B - Removing and Installing Camshaft Bearings

62-1 LUBRICATION SYSTEM AND OIL PUMP

The engine lubrication system is of the force-feed type in which oil is supplied under full pressure to crankshaft, connecting rods, and camshaft bearings, and is supplied under controlled volume to the valve lifters, rocker arm bearings, and push rods. All other moving parts are lubricated by gravity flow or splash. See Figure 60-246.

The supply of oil is carried in the lower crankcase (oil pan) which is filled through a filler opening in the right rocker arm cover. A removable oil gage rod on the left side of the crankcase is provided to check oil level.

The *oil pump* is located in the timing chain cover where it is connected by a drilled passage in the cylinder crankcase to an oil screen housing and pipe assembly. The screen is submerged in the oil supply and has ample area for all operating conditions. If the screen should become clogged for any reason, oil may be drawn into the system through the relief valve in the screen.

Oil is drawn into the pump through the *screen and pipe assembly* and a drilled passage in the crankcase which connects to drilled passages in the timing chain cover. *All* oil is discharged from the pump to the oil pump cover assembly. The cover assembly consists of an oil pressure relief valve, an oil filter by-pass valve and a nipple for installation of an oil filter. The spring loaded oil pressure relief valve limits the oil pressure to approximate 40 pounds per square inch. The oil filter by-

CAUTION: Make certain to grip the 5/8" hex end of the puller screw with a wrench to keep it from rotating when the pulling nut is turned. Failure to do this will result in the 'locking up' of all threads in the pulling assembly and possible over expansion of the collet.

9. Repeat the above procedure to remove the remaining bearings, except the front bearing, which may be pulled from the rear of the engine.

NOTE: When removing rear cam bearing, it is mandatory to remove welch plug at the back of cam bore. However, if only the front bearing is being replaced, it is not necessary to remove the engine or welch plug. The front bearing can be removed by using a spacer between the pulling plate and the cylinder block.

BEARING INSTALLATION

1. Assemble puller screw to required length.

5. Place new camshaft bearing on collet and GENTLY hand tighten back-up nut to expand collet to fit bearing.

CAUTION: Do not over tighten back-up nut. A loose sliding fit between collet and bearing surface is adequate.

This will provide just enough clearance to allow for the 'collapse' which will occur when the new bearing is pulled into the engine block.

6. Slide mandrel assembly and bearing into bearing-bore as far as it will go without force.

7. Thread end of puller screw onto the end of the mandrel.

NOTE: Make certain to align oil holes in bearing and block properly. One of the collet separation lines may be used as a reference point.

8. Install pulling plate, thrust bearing and pulling nut on threaded end of puller screw.




Figure 60-246--Schematic Diagram of Engine Oil Flow

pass valve opens when the filter has become clogged to the extent that approximately 15 pounds pressure difference exists between the filter inlet and discharge to by-pass the oil filter and channel unfiltered oil directly to the main oil galleries of the engine.

An AC full flow oil filter is externally mounted to the oil filter cover nipple on the lower right front side of the engine. Normally, all engine oil passes through the filter element, however, if the element becomes restricted, a spring loaded by-pass valve opens as mentioned above.

The main oil galleries run the full length of the crankcase and cut into the valve lifter guide holes to supply oil at full pressure to the lifters, and camshaft bearings.

Holes drilled in the crankshaft carry oil from the crankshaft bearings to

the connecting rod bearings. Pistons and cylinder walls are lubricated by oil forced through a small notch in the bearing parting surface on the connecting rod, which registers with the hole in the crankpin once every revolution. Piston pins are lubricated by splash.

A drilled hole in the camshaft connects the front camshaft bearing journal to the keyslot in the front of the camshaft. Oil flows from the journal into the keyslot over the woodruff key in the space between the key and the camshaft sprocket and fuel pump eccentric.

455 cu. in. A drilled hole in the camshaft connects the front camshaft bearing journal to the front of the camshaft. Oil flows from the journal through a passage to an outlet between the crankshaft sprocket and distributor gear

The oil stream strikes the distributor gear and provided ample lubrication of the timing chain and sprockets by splash.

Each rocker arm and valve is supplied with oil through the tubular push rod. This oil comes from the inside of the lifter, passing around the metering valve and through a hole in the lifter push rod seat. Oil from the push rod passes through a hole in the rocker arm push rod seat, and emerges on top of the push rod seat boss. Part of this oil is metered to the valve stem by means of overflowing onto an external rib on the rocker arm. Gravity carries this oil along the rib to the valve tip. The remaining oil flows down into grooves provided for lubrication of the rocker arm bearing surface. See Figure 60-249.

A. REMOVAL AND INSPECTION OF OIL PUMP COVER AND GEARS

1. Remove oil filter.
2. Remove screws attaching oil pump cover assembly to timing chain cover. Remove cover assembly and slide out oil pump gears.
3. Wash off gears and inspect for wear, scoring, etc Replace any gears not found serviceable.
4. Remove the oil pressure relief valve cap, spring and valve. See Figure 60-250. Oil filter by-pass valve and spring are staked in place and should not be removed.
5. Wash the parts thoroughly and inspect the relief valve for wear or scoring. Check the relief valve spring to see that it is not worn on its side or collapsed. Replace any relief valve spring that is questionable. Thoroughly clean the screen staked in the cover.
6. Check the relief valve in its bore in the cover. The valve should have no more clearance than an easy slip




Figure 60-247--Oil Pump and Filter Assembly




Figure 60-248--Front End Lubrication




Figure 60-249 Overhead Lubrication

fit. If any perceptible side shake can be felt the valve and/or cover should be replaced.

7. Check filter by-pass valve for cracks, nicks, or warping. The valve should be flat and free of nicks or

scratches.

b. Oil Pump Assembly and Installation

1. Lubricate and install pressure relief valve and spring in bore of oil

pump cover. See Figure 60-250. Install cap and gasket. Torque cap to 35 lb. ft. with a reliable torque wrench. Do not over-tighten.

2. Install oil pump gears and shaft in oil pump body section of timing




Figure 60-250 Oil Pump Cover and Pressure-Relief Valve

chain cover to check gear end clearance.

3. Place a straight edge over the gears and measure the clearance between the straight edge and the gasket surface. See Figure 60-251. Clearance should be between .0023" and .0058". If clearance is less than .0018" check timing chain cover gear pocket for evidence of wear.




Figure 60-251 Checking Oil Pump End Clearance

4. If gear end clearance is satisfactory, remove gears and pack gear pocket full of petroleum jelly. Do not use chassis lube.

5. Reinstall gears so petroleum jelly is forced into every cavity of the

gear pocket and between the teeth of the gears. Place *new* gasket in position.

NOTE: *This step is very important. Unless the pump is packed with petroleum jelly it may not prime itself when the engine is started.*

6. Install cover assembly screws. Tighten alternately and evenly. The torque specification is 10 lb. ft.

7. Install filter on nipple.

63-1 WATER PUMP AND COOLING SYSTEM

The engine cooling system is the pressure type, with thermostatic coolant temperature control and water pump circulation.

A single contact temperature sensitive switch is located in the intake manifold. Engine water temperature above 246 causes the set of contacts to close and light a red signal on the instrument panel.

There is also a temperature sensitive switch located in the rear of the left cylinder head (on upper series vehicles). If engine temperature should go above 265 degrees plus or minus 10 degrees, a set of contacts are closed and lights a red "stop

engine" signal on the instrument panel.

A Harrison tube and center type of radiator core of brass and copper is used on all models. The outlet radiator tank houses the transmission oil cooler.

All V-8 engines without air conditioning are equipped with a 18", 4 blade fan except Riviera. The Riviera has an 18", 7 blade fan. Air conditioned and heavy duty cars are equipped with an 18", 7 blade fan (350 cu.in.) and 20", 5 blade fan (455 cu.in.) driven by a torque and temperature sensitive clutch. See Figure 60-254.



Figure 60-254 Fan Clutch

The torque sensitive fan clutch is equipped with a temperature sensitive coil which controls the flow of silicone through the clutch.

During periods of operation when radiator discharge air temperature is low, the fan clutch limits the fan speed to a maximum speed of 1200 RPM.

Operating conditions that produce high radiator discharge air temperatures cause the temperature sensitive coil to turn a shaft which opens a port inside the clutch. This open port allows a greater flow of silicone providing a maximum fan speed of approximately 2600 RPM.

The clutch coil is calibrated so that at road load with an ambient

temperature of approximately 80° F the clutch is just at the point of shift between high and low fan speed.

The cooling system is sealed by a pressure type radiator filler cap which causes the system to operate at higher than atmospheric pressure. The higher pressure raises the boiling point of coolant and increases the cooling efficiency of the radiator. The 15 pound pressure cap used on all series permits a possible increase of approximately 38° F, in boiling point of coolant.

The pressure type radiator filler cap contains a blow off or pressure valve and a vacuum or atmospheric valve. See Figure 60-255. The pressure valve is held against its seat by a spring of pre-determined strength which protects the radiator by relieving the pressure if an extreme case of internal pressure should exceed that for which the cooling system is designed. The vacuum valve is held against its seat by a light spring which permits opening of the valve to relieve vacuum created in the system when it cools off and which otherwise might cause the coolant hoses to collapse.




Figure 60-255 Pressure Type Radiator Cap

The coolant is circulated by a centrifugal pump mounted on the timing chain cover which forms the outlet side of the pump. The fan and pulley(s) are bolted to the forward end of the pump shaft. In this manner both the fan and pump are belt driven by a crankshaft driven pulley integral with harmonic balancer.

The pump shaft is supported on a

double row ball bearing shrunk fit in the aluminum water pump cover. The bearings are permanently lubricated during manufacture and sealed to prevent loss of lubricant and entry of dirt.

The pump is sealed against coolant leakage by a packless non-adjustable seal assembly mounted in the pump cover in position to bear against a ceramic face assembly. See Figure 60-256.




Figure 60-256 Water Pump Assembly (455 cu. in. shown)

The inlet pipe case on the timing chain cover feeds into the passage formed by the cover and the front face of the impeller, which is mounted on the bearing shaft with the vanes facing rearward. Coolant flows through the inlet passage to the low pressure area at the center, where it then flows rearward through holes in the impeller. Vanes on the rotating impeller cause the coolant to flow radially outward into two discharge passages cast in the timing chain cover, and these passages deliver an equal quantity of coolant

to each cylinder bank water jacket.

Cylinder water jackets extend down below the lower limits of piston ring travel and the coolant completely surrounds each cylinder barrel to provide uniform cooling. See Figure 60-257.

The coolant leaves the cylinder heads through the intake manifold that provides a common connection between both heads and the radia-

tor. The intake manifold also houses the "pellet" type radiator thermostat and outlet provides the by-pass passage through which coolant returns to the water pump for recirculation whenever the thermostat valve closes to block circulation through the radiator. This thermostatically operated by-pass type of water temperature control permits the engine to reach its normal operating temperature quickly. The thermostat valve opens at 190 degrees F.




Figure 60-257 Coolant Flow

a. Checking and Filling Cooling System

The engine coolant level should be checked only when the engine is cold. Enough coolant should be added to bring the level to the tip of the "FILL COLD" arrow on the backside of the filler tank.

CAUTION: *Never remove the radiator cap quickly when the radiator is HOT. Sudden release of cooling system pressure may cause the coolant to boil and escape with some force.*

If it becomes necessary to remove the radiator cap when the radiator is hot, rotate the cap slowly counter-

clockwise until a stop is reached. When all system pressure is released, then remove cap.

b. Draining and Flushing the Cooling System

When the cooling system has been drained, reinstall an ethylene glycol type anti-corrosion e cooling system protection solution developed for year around use (General Motors Specification GM 1899-M). *Water alone, methanol, or alcohol type anti-freeze is definitely not recommended.* To drain the cooling system, remove radiator cap, open the drain at the

bottom of the radiator and remove the drain plugs on both sides of cylinder block. If car is air-conditioned equipped, set heater temperature control valve at "HOT" position.

After the cooling system is drained, plugs reinstalled, and drain cock closed, fill the system with clean water. Run the engine long enough to open the thermostat for complete circulation through the system then completely drain the cooling system before sediment has a chance to settle.

c. Conditioning the Cooling System

It is very important to make certain that the cooling system is properly prepared before an anti-freeze solution is installed; otherwise, loss of solution through leakage may occur or seepage may result in damage to the engine. The cooling system should be drained and flushed as described above (subpar. b). All joints should be pressure checked for leakage and corrected.

Inspect the water pump, radiator core, heater core, drain cocks, water jacket plugs, and edge of cylinder head gaskets for evidence of leaks. Tighten all hose clamps in the cooling and heating systems and replace any deteriorated hoses.

d. Using and Testing Anti-Freeze Solutions

Inhibited year around (ethylene glycol type) engine coolant solution which is formulated to withstand two full calendar years of normal operation without draining or adding inhibitors should be used at all times (not less than 0° F, to freeze protection should be provided to protect against corrosion). When adding solution due to loss of coolant for any reason or in areas where temperatures lower than -20° F. may be encountered, a sufficient amount of any of the several brands of year around coolant (Ethylene Glycol base) compatible to GM Specification 1899-M available on the market should be used.

NOTE: *Alcohol base coolants are not recommended for this vehicle at any time.*

If for any reason water is used as a coolant in a emergency, it is extremely important that Buick Heavy Duty Cooling System Protector and Water Pump Lubricant or equivalent be added to the cooling system as soon as possible. If any other cooling system protector is used, be certain it is labeled to indicate that it meets General Motors Specification GM 1894-M. It should be recognized that

this is only a temporary measure. The manufacturer intends that ethylene glycol type coolant solution be used year around in the cooling system of your Buick.

The cooling system should be completely drained and the recommended coolant installed every two years. At this time, also add GM cooling system inhibitor and sealer or equivalent. It is advisable to check the anti-freeze solution at intervals during the winter to make certain that the solution has not been weakened by evaporation or leakage. Use only hydrometers which are calibrated to read both the specific gravity and the temperature. Obtain a table or similar means of converting the freezing point at various temperatures of the solution. Disregarding the temperature of the solution when making the test may cause an error as large as 30° F. Care must be exercised to use the correct float or table for the particular type of anti-freeze being tested.

e. Fan Belt Adjustment and Replacement

A tight fan belt will cause rapid wear of the Delcotron generator and

water pump bearings. A loose belt will slip and wear excessively causing noise, engine overheating and unsteady generator output. A fan belt which is cracked or frayed, or is worn so that it bottoms in the pulleys should be replaced.

The fan belt may be replaced by loosening the generator brace at both ends, slightly loosening the generator mounting bolts, and moving generator inward to provide maximum slack in the belt.

The Delcotron generator must be moved outboard to adjust the fan belt. After the Delcotron generator brace and mounting bolts are securely tightened, the fan belt tension should be checked. See Figure 60-258.

If the power steering oil pump belt is removed it should be adjusted to tension specified, in Figure 60-258.

If the Air Conditioner compressor belt is disturbed it should be adjusted as specified, in Figure 60-258.

f. Radiator Thermostat Inspection and Test




Figure 60-258 Engine Belt Tension Chart

A sticking radiator thermostat will prevent the cooling system from functioning properly. If the thermostat sticks in the open position, the engine will warm up very slowly. If the thermostat sticks in the closed position, overheating will result.

The thermostat may be removed for inspection by partially draining the cooling system and removing the thermostat housing.

If the thermostat valve does not fully close when cold, check for the presence of foreign material that could hold it open. If no foreign material is present and valve still does not close, replace the thermostat.

Test the thermostat for correct opening temperature by immersing the unit and a thermometer in a container of water. While heating the water do not rest either the thermometer or thermostat on bottom of container as this will cause them to register a higher temperature than the water. Agitate the water to insure uniform temperature of water, thermostat and thermometer.

The standard temperature (190°) thermostat valve should start to open at approximately 190° F., and should be fully open at approximately 212° F. If thermostat does not operate at specified temperatures it must be replaced as it cannot be adjusted.

g. Water Pump Repairs

The water pump cover is die cast aluminum into which the water pump bearing outer race is shrunk fit. For this reason the cover, shaft bearing, and hub are not replaceable.

h. Removal of Water Pump

1. Drain coolant into a clean container.
2. Loosen belt or belts, then remove fan blade, and pulley or pulleys from hub on water pump shaft.

Remove belts.

3. Disconnect hose from water pump inlet and heater hose from nipple. Remove bolts, pump assembly, and gasket from timing chain cover.

4. Check pump shaft bearings for end play or roughness in operation. If bearings are not in serviceable condition, the assembly must be replaced.

i. Installation of Water Pump

1. Make sure the gasket surfaces on pump and timing chain cover are clean. Install pump assembly with new gasket. Bolts must be tightened uniformly.

2. Connect radiator hose to pump inlet and heater hose to nipple. Fill cooling system and check for leaks at pump and hose joints.

3. Install fan pulley or pulleys and fan blade, tighten attaching bolts securely. Install belts and adjust for proper tension. See Figure 60-258.

63-2 ENGINE MOUNTING, FLYWHEEL, AND ENGINE BALANCING

a. Removal of Front Mounts

1. Raise car and provide frame support at front of car.
2. Support weight of engine at forward edge of oil pan.
3. Remove mount to engine block bolts. Raise engine slightly and remove mount to mount bracket bolt and nut. Remove mount.

b. Installation of Front Mount

1. Install mount to engine block bolts and torque to 70 lb. ft.
2. Lower engine so mounts rest on frame cross member in normal manner. Install mount to bracket bolt and torque to 55 lb. ft.

3. Remove frame support and lower car.

c. Removal of Rear (transmission) Mount

For details of engine and transmission mounts and transmission support installation refer to Figures 60-261, 60-262, and 60-263.

d. Removal and Replacement of Automatic Transmission Flywheel

1. Remove transmission (GROUP 74).
2. Remove six bolts attaching flywheel to crankshaft flange.
3. Inspect flywheel; if cracked at flywheel bolt holes, replace flywheel.
4. Inspect crankshaft flange and flywheel for burrs. Remove any burrs with a mill file.
5. Install flywheel. Bolt holes are unevenly spaced so all flywheel bolts can be installed with flywheel in correct position. Install bolts and torque evenly to 60 lb. ft.
6. Mount dial indicator on engine block and check flywheel run-out at three attaching bosses. Run-out should not exceed .015".

NOTE: *The crankshaft end play must be held in one direction during this check.*

7. If run-out exceeds .015", attempt to correct by tapping high side with mallet. If this does not correct, remove flywheel and check for burrs between flywheel and crankshaft mounting flange.

e. Replacement of Flywheel or Ring Gear on Manual Transmission Engine

1. Remove transmission and clutch assembly, being certain to mark clutch cover and flywheel so clutch may be reinstalled in original position.
2. Remove flywheel. Flywheel is

located in a predetermined location on crankshaft by attaching bolts, which are unevenly spaced.

3. If ring gear is to be replaced, drill a hole between two teeth and split gear with a cold chisel.

4. Heat and shrink a new gear in place as follows:

a. Polish several spots on ring with emery cloth.

b. Use a hot plate or slowly moving torch to heat the ring until the polished spots turn blue (approximately 600° F.)

CAUTION: Heating the ring in excess of 800° F will destroy the heat treatment.

c. Quickly place ring in position against shoulder of flywheel with chamfered inner edge of ring gear toward flywheel shoulder. Allow ring to cool slowly until it contracts and is firmly held in place.

5. Make certain the flywheel and crankshaft flange are free from burrs that would cause run-out. Install flywheel.

f. Manual Transmission Flywheel Balance

All manual transmission flywheels are balanced at the factory by drilling holes at various points on the flywheel surface. *No attempt should be made to balance a flywheel after the initial factory balance.*

g. Automatic Transmission Flywheel Balance

Clips are available from the Parts Department that will serve as balance weights for automatic transmission flywheels. These clips are secured by their clamping pressure and a series of indentations stamped into the flywheels. See Figure 60-259 for clip installation locations.

If a flywheel is found to be out of balance, it can be corrected in the following manner.




Figure 60-259 Automatic Transmission Flywheel Balance Clip Location (350 cu.in. Shown)

1. Remove lower flywheel housing. Mark the flywheel at four locations, 90° apart.

2. Install one clip at one of the marked locations. Run engine with transmission in neutral and note vibration.

(a) If vibration increases, remove clip and relocate 180° from original location.

(b) If vibration decreases, install another clip next to the original.

(c) If no change is noted, move clip 90° and recheck.

3. Continue this procedure until a reduction in vibration is noted. Fine adjustments can be made by moving the clips, by small increments, to different locations.

CAUTION: Be certain that the tangs on the clip are setting in the stamped grooves on the flywheel. Otherwise, the clip(s) may shift when the flywheel is turned at high speeds.

h. Harmonic Balancer

If the harmonic balancer is suspected of being a cause of vibration, it can be checked and/or balanced

by following the outline below:

a. Using a tachometer, determine the engine speed at which the greatest amount of vibration occurs.

b. Place an amount of body putty or similar material on the inside surface of the fan driving pulley. Run engine at critical speed and note vibration.

c. Repeat Step 2 above using varying amounts of putty at different locations until the vibration is diminished to a minimum.

d. When point of minimum vibration is found, mark the nearest hole drilled in the balancer at that point.

e. Cut a piece of 7/16" drill rod approximately 1/2" long. Use a chisel, upset a small amount of material on the side of the piece of drill rod. See Figure 60-260.




Figure 60-260--Harmonic Balancer - Balance Weight Details

f. Install drill rod into hole marked in Step 4.

g. Additional weight should be added (if necessary) in adjoining holes.




Figure 60-261-Engine and Transmission Mounting 43 and 44000 Series




Figure 60-262--Engine and Transmission Mounting - 45-46-48000 Series




Figure 60-263 Engine and Transmission Mounting - Riviera

DIVISION IV TROUBLE DIAGNOSIS**63-9 EXCESSIVE OIL CONSUMPTION**

Possible Cause	Correction
External Oil Leaks at: Rocker Arm Covers Timing Chain Cover Oil Pan and Gasket Between Oil Pan and Flywheel Housing Intake Manifold Gasket	Tighten attaching bolts. If leaks persist, remove cover (or pan), check sealing surfaces for burrs or scoring, replace gasket, and seal attaching bolts with Permatex #2 or equivalent. Make sure oil level is not overfull.
Improper Reading of Dip Stick	Car may not be level when taking reading. Insufficient oil "drain-back" time allowed after stopping engine (three minutes must be allowed). Dip stick may not be completely pushed down against stop. Dip stick may be bent.
Oil Viscosity too Light	Use recommended S.A.E. viscosity for prevailing temperatures.
Continuous High Speed	At speeds above 60 MPH, increased oil consumption can be expected with any engine. Inform customer of this fact.
High Speed Driving following Normal Slow Speed City Driving	When principal use of automobile is city driving, crankcase dilution from condensation occurs. High speed and temperatures will remove water, resulting in what appears to be rapid lowering of oil level. Inform customer of this fact.
Valve Guides and/or Valve Stem Seals Worn — Excessive Clearance	Ream out guides and install service valves with oversize stems and new valve stem seals. Refer to Paragraph 61-1.
Piston Rings not "broken in"	Allow engine to accumulate at least 4,000 miles before attempting any engine disassembly to correct for oil consumption.

63-10 NOISY VALVES AND LIFTERS

a. Noisy Valve Train

The noise level of the valve mechanism cannot be properly judged where the engine is below operating temperature when the hood is raised, or when the valve rocker arm covers are removed.

Before attempting to judge valve noise level, the engine must be thoroughly warmed up (at least 20 minutes of operation at 1200 to 1500 RPM) to stabilize oil and coolant temperatures and bring all engine parts to a normal state of expansion. When the engine is warmed up, listen for engine noise while sitting in the drivers seat with the hood closed. Run the engine at idle and at various higher speeds. It is advisable to observe the noise level in several engines that have been properly broken in, in order to develop good judgment for checking the noise level in any given engine.

If the preceding check indicates the valve mechanism is abnormally noisy, remove the rocker arm covers so that the various conditions that cause noise may be checked. A piece of heater hose of convenient length may be used to pick out the particular valves or valve train components that are causing abnormal noise. With the engine running at a speed where the noise is pronounced, hold one end of hose to an ear and hold other end about 1/2" from point of contact between rocker arm and valve stem. Mark or record the noisy valves for investigation of following causes.

(1) *Excessive Oil In Crankcase.* Crankcase oil level high enough to allow the crankshaft to churn the oil will cause air bubbles in the lubricating system. Air bubbles entering the hydraulic lifters will cause erratic operation resulting in excessive lash in the valve train. Locate and correct cause of high oil level, then run engine long enough to expel air

from system.

(2) *Sticking, Warped or Eccentric Valves, Worn Guides.* Sticking valves will cause irregular engine operation or missing on a low speed pull and will usually cause intermittent noise.

Pour penetrating oil over the valve spring cap and allow it to drain down the valve stem. Apply pressure to the one side of the valve spring and then the other, and then rotate the valve spring about 1/2 turn. If these operations affect the valve noise, it may be assumed that valves should be reconditioned.

(3) *Worn or scored parts in the valve train.* Inspect rocker arms, push rod ends for scoring. Check for bent push rods. Check valve lifters and camshaft surfaces for scoring. Replace faulty parts.

(4) *Valves and seats cut down excessively.* Noisy and improper valve action will result if a valve and its seat have been refinished enough to raise the end of the valve stem approximately .050" above normal position. In this case it will be necessary to grind off the end of the valve stem or replace parts. The normal height of the valve stem above the valve spring seat is 1.925 inches, for 350 cu.in. engines and 2.2275 inches for 455 cu.in. engines.

(5) *Faulty Hydraulic Valve Lifters.* If the preceding suggestions do not reveal the cause of noisy valve action, check operation of valve lifters as described in paragraph 61-1, subparagraph c.

b. Noisy Valve Lifters

When checking hydraulic valve lifters, remember that grit, sludge, varnish or other foreign matter will seriously affect operation of these lifters. If any foreign substance is found in the lifters or engine where it may be circulated by the lubrication system, a thorough cleaning job must be done to avoid a repetition of lifter trouble.

To help prevent lifter trouble, the engine oil and oil filter must be changed as recommended in Group 00. The engine oil must be heavy-duty type (MS marked on container) and must also conform to General Motors Specification 6041-M to avoid detrimental formation of sludge and varnish. A car owner should be specifically advised of these requirements when the car is delivered. Faulty valve lifter operation usually appears under one of the following conditions:

(1) *Rapping noise only when engine is started.* When engine is stopped, any lifter on a camshaft lobe is under pressure of the valve spring; therefore, leak down or escape of oil from the lower chamber can occur. When the engine is started a few seconds may be required to fill the lifter, particularly in cold weather. If noise occurs only occasionally, it may be considered normal requiring no correction. If noise occurs daily, however, check for (a) oil too heavy for prevailing temperatures (b) excessive varnish in lifter.

(2) *Intermittent Rapping Noise.* An intermittent rapping noise that appears and disappears every few seconds indicates leakage at check ball seat due to foreign particles, varnish, or defective surface of check ball or seat. Recondition, clean, and/or replace lifters as necessary.

(3) *Noise at idle and low speed.* If one or more valve lifters are noisy on idle at up to approximately 25 MPH but quiet at higher speeds, it indicates excessive leakdown rate or faulty check ball seat on plunger. With engine idling, lifters with excessive leakdown rate may be spotted by pressing down on each rocker arm above the push rod with equal pressure. Recondition or replace noisy lifters.

(4) *Generally noisy at all speeds.* Check for high oil level in crankcase. See subparagraph a (1) above. With engine idling, strike each rocker arm

above push rod several sharp blows with a mallet; if noise disappears, it indicates that foreign material was keeping check ball from seating. Stop engine and place lifters on camshaft base circle. If there is lash clearance in any valve train, it indicates a stuck lifter plunger, worn lifter body lower end, or worn camshaft lobe.

(5) *Loud noise at normal operating temperature only.* If a lifter develops a loud noise when engine is at normal operating temperature, but is quiet when engine is below normal temperature, it indicates an excessively fast leakdown rate or scored lifter plunger. Recondition or replace lifter.

63-II COOLING SYSTEM TROUBLE

a. Cooling System Trouble Diagnosis

If the radiator is filled too full when cold, expansion when hot will overflow the radiator and coolant will be lost through the overflow pipe. Adding unnecessary water will weaken the anti-freeze solution and raise the temperature at which freezing may occur.

If the cooling system requires frequent addition of water in order to maintain the proper level in the radiator, check all units and connections in the cooling system for evidence of leakage. Inspection should be made with cooling system cold. Small leaks which may show dampness or dripping can easily escape detection when the engine is

hot, due to the rapid evaporation of coolant. Tell-tale stains of grayish white or rusty color, or dye stains from anti-freeze, at joints in cooling system are almost always sure signs of small leaks even though there appears to be no damage.

Air or gas entrained in the cooling system may raise the level in radiator and cause loss of coolant through the overflow pipe. Air may be drawn into the cooling system through leakage at the water pump seal. Gas may be forced into the cooling system through leakage at the cylinder head gasket even though the leakage is not sufficient to allow water to enter the combustion chamber. The following quick check for air leaks on suction side of pump or gas leakage from engine may be made with a piece of rubber tubing and a glass bottle containing water.

1. With cooling system cold, add water to bring coolant to proper level.
2. Block open the radiator cap pressure valve, or use a plain cap, and be sure radiator cap is on tight. Attach a suitable length of rubber hose to overflow pipe.
3. Run engine in neutral at a safe high speed until the engine reaches a constant operating temperature.
4. Without changing engine speed, put the free end of rubber hose into a bottle of water, avoiding kinks or low bends that might block the flow of air.


5. Watch for air bubbles in water bottle. A continuous flow of bubbles indicates that air is being sucked into the cooling system, or exhaust gas is leaking into the cooling system past the cylinder head gasket.

b. Cooling System Overheating

It must be remembered that the Buick pressure system operates at higher temperatures than systems operating at atmospheric pressure. Depending on the pressure in cooling system, the temperature of permanent type anti-freeze may go considerably above 212 F without danger of boiling.

In cases of actual overheating the following conditions should be checked:


1. Excessive water loss.
2. Slipping or broken fan belt.
3. Radiator thermostat stuck, radiator air passages clogged, restriction in radiator core, hoses, or water jacket passages.
4. Improper ignition timing.
5. Shortage of engine oil or improper lubrication due to internal conditions.
6. Dragging brakes.



J-9510-1	PISTON PIN REMOVER AND INSTALLER SUPPORT
J-9510-2	PISTON PIN REMOVER AND INSTALLER PILOT
J-9510-3	PISTON PIN REMOVER AND INSTALLER
J-5538-12	PISTON PIN REMOVER AND INSTALLER SPRING
J-8062	VALVE SPRING COMPRESSOR
J-22197	VIBRATION DAMPER INSTALLER
J-21742	ENGINE FRONT COVER ALIGNMENT GAUGE
J-6978-04	VIBRATION DAMPER & CRANKSHAFT GEAR INSTALLER
J-5239-1 & 2	CONNECTING ROD BOLT GUIDE SET
J-22891	VALVE SPRING COMPRESSOR
J-22549-2	SHIFT TUBE INSTALLER

60-343


Figure 60-265 - Special Tools - 250 Cu. In. L-6



- J 4160-A HYDRAULIC VALVE LIFTER PLUNGER REMOVER
- J 5099 HYDRAULIC VALVE LIFTER BODY CLEANING BRUSH
- J 5238 HYDRAULIC VALVE LIFTER PLUNGER RETAINER REMOVER & INSTALLER
- J 6647 PISTON RING COMPRESSOR 3-7/8
- J 5830-1 VALVE GUIDE REAMER .003 OVERSIZE
- J 5830-2 VALVE GUIDE REAMER .015 OVERSIZE
- J-5830-3 VALVE GUIDE REAMER .030 OVERSIZE
- J 7316 BELT TENSION GAUGE
- J 8080 MAIN BEARING SHELL REMOVER
- J 8358 CARBON REMOVING BRUSH


60-168B

Figure 60-266 · Special Tools · 250 Cu. Inc. L-6



J 4160-A	HYDRAULIC VALVE LIFTER PLUNGER REMOVER
J 5099	HYDRAULIC VALVE LIFTER BODY CLEANING BRUSH
J 5238	HYDRAULIC VALVE LIFTER PLUNGER RETAINER REMOVER & INSTALLER
J 5601	PISTON RING COMPRESSOR 3-3/4"
J 5250	TIMING CHAIN COVER OIL SEAL INSTALLER
J 22612	VALVE GUIDE REAMER .006 OVERSIZE
J 9345-1	BELT TENSION GAUGE
J 8080	MAIN BEARING SHELL REMOVER
J 8358	CARBON REMOVING BRUSH
J-8003	VALVE GUIDE REAMER 11/32"
J 5239	CONNECTING ROD BOLT GUIDE SET
J 21158	PISTON RING COMPRESSOR (455 CU. IN.)
J 22965	PISTON RING COMPRESSOR (350 CU. IN.)

Figure 60-267 - Special Tools - 350 and 455 Cu. In.



- J 5268 HYDRAULIC VALVE LIFTER TESTER OIL - ONE GALLON
- J 5790 HYDRAULIC VALVE LIFTER LEAKDOWN TESTER
- J 6047 PISTON PIN ASSEMBLY TOOL SET
Details J 6047-1, J 6047-5 and J 6047-20
- J 8062 VALVE SPRING COMPRESSOR

60-169A

Figure 60-268 - Special Tools 350 and 455 Cu. In.