

GUIDE-MATIC

WARNING: IF EQUIPPED WITH AIR CUSHION RESTRAINT SYSTEM, DO NOT ATTEMPT ANY ADJUSTMENT, REPAIR OR REMOVAL OF ANY ACCESSORY OR COMPONENTS WHICH WOULD REQUIRE REMOVAL OR DISCONNECTING OF ANY COMPONENT OF THE AIR CUSHION RESTRAINT SYSTEM UNTIL THE DISCONNECTION PROCEDURE IS COMPLETED. THIS PROCEDURE MUST BE FOLLOWED TO PREVENT ACCIDENTAL DEPLOYMENT OF THE SYSTEM WHICH COULD RESULT IN PERSONAL INJURY AND/OR DAMAGE TO THE SYSTEM'S COMPONENTS.

A.C.R.S. DISCONNECTION PROCEDURE

1. Turn ignition switch to "LOCK" position. Disconnect the negative battery cable from the battery and tape end.

CONTENTS

DESCRIPTION AND OPERATION:

System Description	9H-1
Automatic Operation.....	9H-2
Manual Operation	9H-2
Low Beam - Operation	9H-2

DIAGNOSIS:

Electrical Diagnosis Guide	9H-2
----------------------------------	------

MAINTENANCE AND ADJUSTMENTS:

Aiming Adjustment.....	9H-3
Testing Dim and Hold Sensitivity on Car	9H-3

MAJOR REPAIR: (Not Applicable)

SPECIFICATIONS: (Not Applicable)

DESCRIPTION AND OPERATION

SYSTEM DESCRIPTION

The Guide-Matic system allows the driver to obtain automatic switching of the vehicle headlight beams in response to light from approaching vehicle headlights. Provision is also made for the driver to obtain manual control or constant low beam if desired. It is available for all A-B-C and E Series as a dealer-installed option.

The system consists of a photo-amplifier, power relay, foot switch, sensitivity control (driver control), and interconnecting wire harness.

The photo-amplifier combines a light sensing photocell and transistorized DC amplifier into one unit with sufficient power to operate a power relay for switching the headlight beams. Mounting location is on the left front fender, so the amber-colored lens has an unobstructed view of approaching vehicle headlights. Road signs, back reflection from the vehicle's own headlights, and other miscellaneous light requires the vertical and horizontal "viewing range" of the photocell to be rather narrow. The amber-colored lens picks up light and focuses it through a small opening onto the photocell to form an optical system to accomplish this. Since the "viewing range" is narrow, aim of the photo-amplifier is very important. Proper operation requires that the unit be properly aimed vertically and horizontally, as outlined under "Aiming Adjustment".

The photo-amplifier is adjusted and sealed at the factory. If a malfunction occurs, the assembly must be replaced. A model-serial number label is attached on the bottom of the assembly for field identification.

The power relay is a sealed, single pole, double throw, 12-volt DC relay which provides the heavy-duty contacts for switching the headlight beams. The high beams are connected to the "normally closed" contacts. It is mounted under the carpet on the toe pan just above the foot switch.

The power relay contains a diode for dampening purposes to protect the photo-amplifier. Observe proper polarity when connecting to prevent burn-out of diode and subsequent ruining of photo-amplifier. Replace relay only with same part number replacement.

The foot switch is the same as the regular foot dimmer switch, except for an added "momentary contact" grounding switch. Operating the switch in the normal manner provides either "Automatic" control of headlight beams or "low beam" only. In "Automatic" position, a slight pressure on top of the switch closes the grounding switch to provide an "overriding" high beam (regardless of light on the photo-amplifier) for signaling purposes, or to determine "Automatic" position.

The sensitivity control (driver control) is located on the lower instrument panel to the left of the steering column. Rotating the control knob provides a range of sensitivity

control and is the only means of adjusting sensitivity in the field.

An in-line 4-ampere (SFE-4) fuse is located near the foot switch in the interconnecting wire harness. If this fuse opens, the system will revert to manual control of headlight beams by means of the foot switch. If service cannot be obtained immediately, removing the fuse will enable the driver to manually control the headlight beams.

AUTOMATIC OPERATION

Turn headlights on, rotate driver control knob to approximately center of rotation, and place foot switch in "Automatic" position. If there is no light ahead, the headlights will be on high beam. No warm-up time is required.

When light from an approaching vehicle's headlights reaches a predetermined level at the photocell's sensing surface, the amplifier will trigger (pull on) the power relay, causing it to switch (dim) the headlights from high to low beam. At the same time, the photocell sensitivity is increased to "hold" sensitivity to keep headlights on low beam when the approaching driver reduces light by switching to low beam.

If the driver desires his lights to switch when the approaching vehicle is farther away or nearer, he may adjust the driver control. If the approaching driver fails to dim, he may signal him by momentarily putting a slight pressure on top of the foot switch to "override" his headlights to high beam. When he removes the pressure, his headlights will revert to low beam if there is still sufficient light ahead.

When the approaching car passes and light is removed from the photocell, the amplifier removes the signal voltage from the power relay coil, causing it to "drop out" and switch back to high beam.

If the road surface is highly reflective (snow, gravel, etc.), the unit may be held on low beam by reflections of its own headlights. If this occurs, slowly rotate driver control counterclockwise until lights return to high beam. This is maximum usable sensitivity for the particular road surface.

MANUAL OPERATION

Rotate driver control knob to extreme counterclockwise position (Off). The foot switch will now operate conventionally, switching headlights from high to low beam. High beam position will represent "Automatic" position of the foot switch.

LOW BEAM OPERATION

Place foot switch in "low beam" position. Headlights will remain on low beam until foot switch is changed to "Automatic" position. Overriding action is not available, since power relay is disconnected from the photo-amplifier.

DIAGNOSIS

ELECTRICAL DIAGNOSIS GUIDE

PERFORM FOLLOWING CHECKS IN SEQUENCE TO DETERMINE CAUSE AND CORRECTION, AND PREVENT UNNECESSARY SERVICE WORK

Check position of driver control knob.

ROTATED TO "OFF" POSITION

Check with owner for understanding of proper operation.

NOT IN "OFF" POSITION

Place car where light strikes photo-amplifier.

Set driver control knob to approximately center position. Operate engine at fast idle and turn on headlights (no warm-up required).

HEADLIGHTS NOT ON LOW BEAM IN BOTH POSITIONS OF FOOT SWITCH

Check for loose connections or blown fuse (near driver control).

Disconnect dark green wire at foot switch.

LOW BEAM IN BOTH POSITIONS OF FOOT SWITCH

Replace shorted foot switch.

HIGH BEAM IN ONE POSITION OF FOOT SWITCH

Disconnect photo-amplifier and connect 12-volt test bulb between ground and left blue wire in 5 way interconnecting harness connector.

BULB DOES NOT LIGHT

Check continuity of blue wire through power relay and light switch (possible loose connection).

BULB LIGHTS

Connect 12-volt test bulb between battery positive terminal and dark green wire in 5 way interconnecting harness connector.

Rotating Driver Control Knob Does Not Turn Bulb On and Off

Check for loose connection at driver control two (2) way connector or malfunctioned driver control.

Rotating Driver Control Knob Turns Bulb On and Off

Connect jumper between battery positive terminal and gray wire in 5 way interconnecting harness connector.

Headlights on Low Beam In Both Positions of Foot Switch

Replace malfunctioned photo-amplifier.

Check for malfunctioned power relay; replace if malfunctioned

Check for malfunctioned foot switch; replace if malfunctioned

HEADLIGHTS ON LOW BEAM IN BOTH POSITIONS OF FOOT SWITCH

Place foot switch in "Automatic" position (use override procedure to find "Automatic" position).

"AUTOMATIC" POSITION CANNOT BE FOUND

Check for disconnected dark green wire at foot switch (override).

Ground dark green wire at foot switch.

If "Automatic" position of foot switch (high beam) can now be found, replace malfunctioned foot switch.

If "Automatic" position cannot be found, replace malfunctioned photo-amplifier assembly.

"AUTOMATIC" POSITION CAN BE FOUND

Leave in "Automatic" position and cover photo-amplifier with black cloth.

HEADLIGHTS DO NOT SWITCH TO HIGH BEAM

Disconnect photo-amplifier at 5 way connector.

If headlights switch to high beam, replace malfunctioned photo-amplifier.

HEADLIGHTS SWITCH TO UPPER BEAM

Uncover photo-amplifier. Let headlights switch to low beam.

Rotate driver control ring to "Off" position. Headlights should switch to high beam.

Headlights Do Not Switch to High Beam

Check driver control for malfunctioning connection to ground or malfunctioned control. Replace control assembly if malfunctioned.

Headlights Switch to High Beam

Check vertical aim adjustment and dim and hold sensitivity as final check, as outlined in notes.

MAINTENANCE AND ADJUSTMENTS

AIMING ADJUSTMENT

The unit must be aimed straight ahead in the horizontal plane. If necessary to readjust horizontal aim, unit must be removed and mounting holes reoperated to allow repositioning.

Accurate vertical aim is essential to proper performance of the Guide-Matic. If the photo-amplifier is aimed too low, reflected road light from the vehicle's own headlights can cause the Guide-Matic to be slow in returning headlights to upper beam or hold them on low beam. The unit

must be aimed as low as possible, however, to provide maximum tolerance for car loading. The aiming procedure outlined here should be rechecked on new cars that have been driven at least 2,000 miles.

1. Photo-amplifier vertical aiming should be performed with vehicle unloaded, trunk empty, except for spare tire, gas tank at least half full, and tires at correct pressure.
2. Locate vehicle on level floor (level within 1/4 inch fore and aft).
3. Rock car sideways to equalize springs.
4. Install leveling device J-22837 available from Kent-Moore Corporation. Be sure the two notches are seated over top front edge of casting, and the lower extrusion is seated on extruded platform on lower part of lens.
5. Adjust aiming screw with an allen wrench until level bubble is centered. Always make final adjustment while turning screw clockwise.

TESTING "DIM" AND "HOLD" SENSITIVITY ON CAR

The individual controls for "Dim" and "Hold" are located in the photo-amplifier and are adjusted and sealed at the factory so they are not accessible in the field. However, a sensitivity check can be made to determine if sensitivity is within the limits of the driver control to provide the driver with at least a minimum acceptable "Dim" and "Hold" sensitivity. This will prevent unnecessary replacement and give the technician a more positive assurance the unit is working properly. Sensitivity Tester No. J-22630 has been developed by Kent-Moore Corporation, 28635 Mound Road, Warren, Michigan, for this purpose.

1. Preparation for Test

a. Sensitivity Tester No. J-22630 consists of a test bulb (53), an adapter tube with filter and bail for securing test bulb to photo-amplifier, and a means of controlling and regulating battery voltage applied to the test bulb.

b. Install tester.

Be sure notch on front edge of adapter tube is located at bottom of photo-amplifier lens (to clear aiming pad on lens). Also, push rubber sleeve surrounding bulb all the way into rear opening in adapter tube.

c. Connect long leads from tester to battery. Observe polarity - red to positive and black to negative.

d. Cover photo-amplifier and test bulb with black cloth.

e. Rotate driver control knob completely counterclockwise.

f. Turn on headlights and operate engine at fast idle. Headlights should be on upper beam.

2. Test Procedure

a. Adjust sensitivity tester voltage control knob until pointer reads 7.0 volts.

b. Slowly rotate driver control knob clockwise just to point where headlights switch to lower beam.

c. Check accuracy of driver control adjustment by rotating sensitivity tester voltage control knob counterclock-

wise until headlights switch to upper beam. Then slowly rotate sensitivity tester control knob clockwise just to point where headlights switch to lower beam. Control knob pointer should be registering between 6.5 and 7.0 volts.

d. If reading does not agree, repeat steps a, b, and c.

e. Slowly rotate sensitivity tester voltage control knob counterclockwise just to point where headlights switch to upper beam. Control knob pointer should register from 1.5 to 2.5 volts less than reading obtained for switching to lower beam in step c.

f. If this minimum "Dim" and "Hold" sensitivity can be obtained at any position of the driver control knob rotation range, the unit is acceptable for sensitivity and you may proceed to step g. If "Dim" (switching to lower beam) cannot be adjusted (step b), check for open ground circuit to driver control or malfunctioned driver control. If okay, replace malfunctioned photo-amplifier. If "Dim" and "Hold" sensitivity readings are close together (approximately 1/2 to 3/4 volt apart), replace malfunctioned photo-amplifier.

g. Turn off engine, disconnect sensitivity tester, and reconnect any wires previously disconnected.




Figure 9H-1 Guide-Matic Schematic