

## SECTION 11-G

### REAR WINDOW DEFROSTER

#### CONTENTS OF SECTION 11-G

Paragraph	Subject	Page
11-26	Rear Window Defroster	11-137

#### 11-26 REAR WINDOW DEFROSTER

The rear window defroster is available as a factory or dealer installed accessory on all models except estate wagons and convertibles. The rear window defroster is used to remove frost or vapor from the rear window. A blower located on the rear self is operated by a two speed switch located on the instrument panel. See Figure 11-180. The 4400-4600 4800 blower switch is located on the upper edge of the instrument panel and is labeled accessory. See Figure 11-181. When this lever is pushed forward from the center or Off position, the blower is set at high speed; pulling the lever rearward from the off position sets blower at low speed.

The 4700 rear window defroster




Figure 11-179—Rear Window Defroster Switch—4700 Series

switch is located at the upper edge of the console between the headlight and windshield washer switches. See Figure 11-179.




Figure 11-180—Rear Window Defroster




Figure 11-181—Rear Window Defroster Blower and 4400-4600-4800 Switch Installation