

SECTION A

ACCESSORIES ALL SERIES

CONTENTS

Division	Paragraph	Subject	Page
I		SPECIFICATIONS AND ADJUSTMENTS (Not Applicable)	
II		DESCRIPTION AND OPERATION (Not Applicable)	
III	150-4 150-5	SERVICE PROCEDURES: Removal and Installation Obvious Upon Inspection. See Illustrations.	
IV		TROUBLE DIAGNOSIS: (Not Applicable)	

INDEX OF ILLUSTRATIONS

Figure Number	Description	Page
150-1	45-46-48000 Series Four Note Horn	150-3
150-2	49000 Series Four Note Horn	150-4
150-3	43-44000 Series Rear Window Defroster	150-5
150-4	45-46-48000 Series Rear Window Defroster	150-6
150-5	49000 Series Rear Window Defroster	150-7
150-6, 7, 8	All Series Guide-Matic	150-8, 9, 10




Figure 150-1-45-46-48000 Series Four Note Horn





Figure 150-2—49000 Series Four Note Horn



150-31

Figure 150-3-43-44000 Series Rear Window Defroster




Figure 150-4-45-46-48000 Series Rear Window Defroster

DEALER INSTALLATION

- 1-PAINT AIR OUTLET GRILLE TRIM COLOR.
- 2-BLOWER MOTOR & GRILLE MOUNTING HOLES ARE PROVIDED IN METAL SHELF PANEL (8). LOCATE FROM UNDER SIDE & PIERCE THRU INSULATION & K.B. BOARD WITH A SHARP TOOL. USING ABOVE HOLES, ALIGN TEMPLATE PROVIDED. CUT OUT OPENINGS IN K.B. BOARD & INSULATION AS INDICATED.
- 3-INSTALL BLOWER MOTOR & GRILLE AS SHOWN IN VIEW "E".




Figure 150-5-49000 Series Rear Window Defroster




Figure 150-6—All Series Guide-Matic

