

SECTION A

43-44000 RADIATOR AND GRILLE

CONTENTS

| Division | Subject | Paragraph |
|----------|--|-----------|
| I | SPECIFICATIONS AND ADJUSTMENTS: Radiator Mounting | 130-1 |
| II | DESCRIPTION AND OPERATION: | |
| III | SERVICE PROCEDURES: Removal and Installation Obvious Upon Inspection. See Illustrations. | |
| IV | TROUBLE DIAGNOSIS: | |

DIVISION I SPECIFICATIONS AND ADJUSTMENTS

130-1 RADIATOR MOUNTING

The radiator mounting is a four-point system using rubber inserts on "U" shaped brackets (for the lower mounting). The radiator upper mounting points are part of the upper radiator panel. The lower brackets mount on the lower portion of the radiator mounting panel.

INDEX OF ILLUSTRATIONS

| Figure Number | Description | Page |
|---------------|---|-------|
| 130-1..... | 43-44000 Standard, Air Conditioning and Heavy Duty Cooling; Radiator and Support Assembly..... | 130-3 |
| 130-2..... | 43-44000 Grille, Ornaments, Horns and Headlamp..... | 130-4 |
| 130-3..... | 43-44000 Grille, Hood Bumper, Hood Latch and Support..... | 130-5 |




Figure 130-1 - 43-44000 Standard, Air Conditioning and Heavy Duty Cooling, Radiator and Support Assembly





Figure 130-2—43-44000 Grille, Ornaments, Horns and Headlamp



130-21

Figure 130-3 - 43-44000 Grille, Hood Bumper, Hood Latch and Support