

SECTION A

43-44000 RADIATOR AND GRILLE

CONTENTS

Division	Subject	Paragraph
I	SPECIFICATIONS AND ADJUSTMENTS: Radiator Mounting	130-1
II	DESCRIPTION AND OPERATION:	
III	SERVICE PROCEDURES: Removal and Installation Obvious Upon Inspection. See Illustrations.	
IV	TROUBLE DIAGNOSIS:	

DIVISION I SPECIFICATIONS AND ADJUSTMENTS

130-1 RADIATOR MOUNTING

The radiator mounting is a four-point system using rubber inserts on "U" shaped brackets (for the lower mounting). The radiator upper mounting points are part of the upper radiator panel. The lower brackets mount on the lower portion of the radiator mounting panel.

INDEX OF ILLUSTRATIONS

Figure Number	Description	Page
130-1.....	43-44000 Standard, Air Conditioning and Heavy Duty Cooling; Radiator and Support Assembly.....	130-3
130-2.....	43-44000 Radiator Overflow Reservoir and Tubes.....	130-4
130-3.....	43-44000 Grill, Ornament, Horns, and Headlamp	130-5
130-4.....	43-44000 Grille, Hood Bumper, Hood Latch and Support.....	130-6





Figure 130-1 - 43-44000 Standard, Air Conditioning and Heavy Duty Cooling, Radiator and Support Assembly



130-30

Figure 130-2 · 43-44000 Radiator Overflow Reservoir and Tubes




Figure 130-4 - 43-44000 Grille, Hood Bumper, Hood Latch and Support