

GROUP 0

INTRODUCTION – GENERAL INFORMATION

CONTENTS OF GROUP 0

Subject	Page	Subject	Page
Introduction.....	0-1	General Specifications.....	0-3
Warranty.....	0-2	Car and Engine Serial Numbers.....	0-3
1961 Special Car Models.....	0-3		

INTRODUCTION

This manual is divided into major *Groups*, *Sections*, and *Paragraphs* as explained below. The purpose of this arrangement is to bring related subjects closely together in accordance with the usual methods of performing service operations, and consequently to present information in a logical and easily understood order.

Any desired subject in this manual may be

located by reference to the alphabetical index at back of manual.

Any desired subject also may be located by turning to the first page of the appropriate *Group* where contents of the *Group* are listed. Where the *Group* is divided into *Sections* the first page of each *Section* lists the contents of the *Section*.

1. GROUPS. The manual is divided into the consecutively numbered major *Groups* shown on the preceding title page. To locate the first page of a *Group*, bend the manual until the black tab on first page of group can be seen in line with the *Group* title on title page.

The first page lists the contents of the *Group*.

2. SECTIONS. Large *Groups* are divided into appropriate *Sections* as shown on first page of the group. *Sections* bear the *Group* number and letters A, B, C, etc., in alphabetical order.

The first page of each *Section* lists the contents of section.

3. PARAGRAPHS. Each *Group* is divided into appropriate *Paragraphs* which are numbered consecutively within the *Group*, whether or not the group is divided into sections.

Paragraph titles and page numbers are listed on the first page of each *Section* if used, or on first page of the *Group* if sections are not used.

4. SUB-PARAGRAPHS. Where necessary for clarity, or distinction between models, *Paragraphs* are divided into appropriately titled *Sub-paragraphs*. These are usually lettered in alphabetical order within the paragraph.

5. PAGE AND ILLUSTRATION NUMBERS. Pages and illustrations are numbered consecutively within each *Group*. The number consists of the *Group* number followed by the *Page* or *Figure* number. Page numbers are printed in the upper *outer* corners of all pages.

6. CROSS REFERENCES. All references to information in other parts of manual are made by *Paragraph Number*, to avoid the necessity of first referring to the alphabetical index for location. *Paragraph* references are usually given in parentheses, for example: (par. 7-15) refers to the 15th paragraph in *Group 7*, "Chassis Suspension".

7. SPECIAL TOOLS. Unless otherwise indicated, all special tools identified by tool numbers in the manual are available through Kent-Moore Organization, Inc., General Motors Building, Detroit 2, Michigan.

MANUFACTURER'S WARRANTY

On new Buick motor vehicles, purchased by the Dealer issuing this Policy from Buick Motor Division, General Motors Corporation (the Manufacturer), Manufacturer gives Dealer the warranty quoted below. On each new Buick motor vehicle sold by Dealer, Dealer, as seller thereof and not as agent of Manufacturer, gives Purchaser a like warranty.

"The Manufacturer warrants each new motor vehicle, including all equipment or accessories (except tires) supplied by the Manufacturer, chassis or part manufactured by it to be free from defects in material and workmanship under normal use and service, its obligation under this warranty being limited to making good at its factory any part or parts thereof which shall, within ninety (90) days after delivery of such vehicle to the original purchaser or before such vehicle has been driven 4,000 miles, whichever event shall first occur, be returned to it with transportation charges prepaid and which its examination shall disclose to its satisfaction to have been thus defective; this warranty being expressly in lieu of all other warranties, expressed or implied, and all other obligations or liabilities on its part, and it neither assumes nor authorizes any other person to assume for it any other liability in connection with the sale of its vehicles.

This warranty shall not apply to any vehicle which shall have been repaired or altered outside of an authorized Buick Service Station in any way so as in the judgment of the Manufacturer to affect its stability and reliability, nor which has been subject to misuse, negligence or accident.

The Manufacturer has reserved the right to make changes in design or add any improvements on motor vehicles and chassis at any time without incurring any obligation to install same on motor vehicles and chassis previously purchased.

1961 SPECIAL MODELS

Model	Designation
4019	4 Door Sedan
4035	Estate Wagon
4119	4 Door Sedan
4135	Estate Wagon

GENERAL SPECIFICATIONS 4000-4100

Wheelbase	112.0
Tread - Front	56.0
Tread - Rear	56.0
Length Over-all	188.4
Width Over-all at widest point	71.3
Height Over-all, Roof to Road	52.6
Front Overhang	30.96
Rear Overhang	45.41

IDENTIFICATION NUMBERS

The vehicle identification number is stamped on cowl to frame brace in engine compartment. The first digit of the number indicates the series ("0" for 4000 series, "1" for series 4100). The next digit is a letter designating the year ("H" for 1961). The third prefix is a number indicating the assembly plant at which the car was built (1 - Flint, 2 - South Gate). The remaining group of 6 digits is the individual car serial number. This number is also stamped on the crankcase just forward of the right cylinder head and constitutes the legal engine number. On this same crankcase surface (stamped upside down when viewed

from the front of the engine) is the engine production code number. This number, along with the vehicle identification number (car serial number) is used to identify the engine on product reports, etc. The production code number is prefaced by H on 1961 standard compression ratio 215 cubic inch displacement engines, and by LH on low compression ratio engines. The production code number does not constitute a legal engine number for registration, titles, etc. A 1/4" long dash (—) after the production code number indicates a .010" oversize cylinder bore engine.